USER GUIDE

Chromium Single Cell V(D)J Reagent Kits



FOR USE WITH

Chromium Single Cell 5' Library & Gel Bead Kit, 16 rxns PN-1000006

Chromium Single Cell 5' Library & Gel Bead Kit, 4 rxns PN-1000014

Chromium Single Cell 5' Library Construction Kit, 16 rxns PN-1000020

Chromium Single Cell V(D)J Enrichment Kit, Human T Cell, 96 rxns PN-1000005

Chromium Single Cell V(D)J Enrichment Kit, Human B Cell, 96 rxns PN-1000016

Chromium Single Cell V(D)J Enrichment Kit, Mouse T Cell, 96 rxns PN-1000071

Chromium Single Cell V(D)J Enrichment Kit, Mouse B Cell, 96 rxns PN-1000072

Chromium Single Cell A Chip Kit, 48 rxns PN-1000152 (America & Asia Pacific), PN-120236 (Europe, Middle East & Africa)

Chromium Single Cell A Chip Kit, 16 rxns PN-1000151 (America & Asia Pacific), PN-1000009 (Europe, Middle East & Africa)

Chromium i7 Multiplex Kit, 96 rxns PN-120262



Notices

Document Number

CG000086 • Rev M

Legal Notices

© 2020 10X Genomics, Inc (10x Genomics). All rights reserved. Duplication and/or reproduction of all or any portion of this document without the express written consent of 10x Genomics, is strictly forbidden. Nothing contained herein shall constitute any warranty, express or implied, as to the performance of any products described herein. Any and all warranties applicable to any products are set forth in the applicable terms and conditions of sale accompanying the purchase of such product. 10x Genomics provides no warranty and hereby disclaims any and all warranties as to the use of any third-party products or protocols described herein. The use of products described herein is subject to certain restrictions as set forth in the applicable terms and conditions of sale accompanying the purchase of such product. A non-exhaustive list of 10x Genomics' marks, many of which are registered in the United States and other countries can be viewed at: www.10xgenomics.com/trademarks. 10x Genomics may refer to the products or services offered by other companies by their brand name or company name solely for clarity, and does not claim any rights in those third party marks or names. 10x Genomics products may be covered by one or more of the patents as indicated at: www.10xgenomics.com/patents. The use of products described herein is subject to 10x Genomics Terms and Conditions of Sale, available at www.10xgenomics.com/legal-notices, or such other terms that have been agreed to in writing between 10x Genomics and user. All products and services described herein are intended FOR RESEARCH USE ONLY and NOT FOR USE IN DIAGNOSTIC PROCEDURES.

Instrument & Licensed Software Updates Warranties

Updates to existing Instruments and Licensed Software may be required to enable customers to use new or existing products. In the event of an Instrument failure resulting from an update, such failed Instrument will be replaced or repaired in accordance with the 10x Limited Warranty, Assurance Plan or service agreement, only if such Instrument is covered by any of the foregoing at the time of such failure. Instruments not covered under a current 10x Limited Warranty, Assurance Plan or service agreement will not be replaced or repaired.

Support

Email: support@10xgenomics.com 10x Genomics 6230 Stoneridge Mall Road Pleasanton, CA 94588 USA

Document Revision Summary

Document Number CG000086

Title Chromium Single Cell V(D)J Reagent Kits User Guide

Revision Revision L to M

Revision Date February 2020

Specific Changes:

• Updated to include additional Chromium Single Cell Chip A Kit part numbers.

• Updated Chip loading instructions on page 29.

General Changes:

• Updated for general minor consistency of language and terms throughout.

Table of Contents

Introduction	6
Chromium Single Cell V(D)J Reagent Kits	7
Chromium Accessories	12
Recommended Thermal Cyclers	12
Additional Kits, Reagents & Equipment	13
Protocol Steps & Timing	15
Stepwise Objectives	16
Tips & Best Practices	19
Step 1	25
GEM Generation & Barcoding	26
1.1 Prepare Reaction Mix	27
1.2 Load Chromium Chip A	29
1.3 Run the Chromium Controller	30
1.4 Transfer GEMs	30
1.5 GEM-RT Incubation	31
Step 2	32
Post GEM-RT Cleanup	33
2.1 Post GEM-RT Cleanup – Dynabeads	34
Step 3	36
cDNA Amplification & QC	37
3.1 cDNA Amplification	38
3.2 cDNA Cleanup – SPRIselect	39
3.3 cDNA QC & Quantification	40
Step 4	41
Target Enrichment from cDNA	42
4.1 Target Enrichment 1	43
4.2 Post Target Enrichment 1 Cleanup – SPRIselect	44
4.3 Target Enrichment 2	45
4.4 Post Target Enrichment 2 Double Sided Size Selection – SPRIselect	46
4.5 Post Target Enrichment QC & Quantification	47

Step 5	48
Enriched Library Construction	49
5.1 Fragmentation, End Repair & A-tailing	50
5.2 Adaptor Ligation	51
5.3 Post Ligation Cleanup – SPRIselect	52
5.4 Sample Index PCR	53
5.5 Post Sample Index PCR Cleanup – SPRIselect	54
5.6 Post Library Construction QC	55
Step 6	56
5' Gene Expression (GEX) Library Construction	57
6.1 GEX Fragmentation, End Repair & A-tailing	58
6.2 GEX Post Fragmentation, End Repair & A-tailing Double Sided Size Selection – SPRIselect	59
6.3 GEX Adaptor Ligation	60
6.4 GEX Post Ligation Cleanup – SPRIselect	61
6.5 GEX Sample Index PCR	62
6.6 GEX Post Sample Index PCR Double Sided Size Selection – SPRIselect	63
6.7 GEX Post Library Construction QC	64
Sequencing	65
Troubleshooting	68
GEMs	69
Chromium Controller Errors	71
Appendix	72
Post Library Construction Quantification	73
Agilent TapeStation Traces	74
Oligonucleotide Sequences	75

Introduction

Chromium Single Cell V(D)J Reagent Kits
Chromium Accessories
Recommended Thermal Cyclers
Additional Kits, Reagents & Equipments
Protocol Steps & Timing
Stepwise Objectives

Chromium Single Cell V(D)J Reagent Kits

Chromium Single Cell 5' Library and Gel Bead Kit, 16 rxns PN-1000006


Chromium Single Cell 5' Library Kit, 16 rxns PN-1000002 (store at -20°C)

Chromium Single Cell 5' Reagents Module 1			Chromium Single Cell 5' Reagents Module 2		
	#	PN		#	PN
RT Reagent Mix	1	220089	Fragmentation Enzyme Blend	1	220107
RT Enzyme Mix B	1	2000010	Fragmentation Buffer	1	220108
Additive A	1	220074	Ligation Buffer	1	220109
Poly-dT RT Primer	1	2000007	DNA Ligase	1	220110
Buffer Sample CleanUp 1	2	220020	Adaptor Mix	1	220026
Amplification Master Mix	2	220125	SI-PCR Primer	1	220111
oDNA Primer Mix	1	220106	Amplification Master Mix	1	220125
CDNA Additive	1	220067			
DxGenomics.com		10x	10xGenomics.com		10

Chromium Single Cell 5' Gel Bead Kit, 16 rxns PN-1000003 (store at -80°C)



Dynabeads™ MyOne™ SILANE PN-2000048 (store at 4°C)



Chromium Single Cell 5' Library and Gel Bead Kit, 4 rxns PN-1000014


Chromium Single Cell 5' Library Kit, 4 rxns PN-1000011 (store at -20°C)

Chromium Single Cell 5' Reagents Module 1			Chromium Single Cell 5' Reagents Module 2		
	#	PN		#	PN
RT Reagent Mix	1	220089	Fragmentation Enzyme Blend	1	22013
RT Enzyme Mix B	1	2000021	Fragmentation Buffer	1	22010
Additive A	1	220074	Ligation Buffer	1	22010
Poly-dT RT Primer	1	2000007	DNA Ligase	1	22013
Buffer Sample CleanUp 1	1	220020	Adaptor Mix	1	22002
Amplification Master Mix	1	220125	SI-PCR Primer	1	22011
oDNA Primer Mix	1	220106			
cDNA Additive	1	220067			
10xGenomics.com		10x	10xGenomics.com		1


Chromium Single Cell 5' Gel Bead Kit, 4 rxns PN-1000010 (store at -80°C)



Dynabeads™ MyOne™ SILANE PN-2000048 (store at 4°C)



Chromium Single Cell 5' Library Construction Kit, 16 rxns PN-1000020 (store at -20°C)



Chromium Single Cell V(D)J Enrichment Kits, Human (store at -20°C)

Human T Cell, 96 rxns PN-1000005




Human B Cell, 96 rxns PN-1000016




Chromium Single Cell V(D)J Enrichment Kits, Mouse (store at -20°C)

Mouse T Cell, 96 rxns PN-1000071



Mouse B Cell, 96 rxns PN-1000072



Chromium Chip A Single Cell Kit, 48 rxns PN-1000152 (America & Asia Pacific) (store at ambient temperature) PN-120236 (Europe, Middle East & Africa)



Chromium Chip A Single Cell Kit, 16 rxns PN-1000151 (America & Asia Pacific) (store at ambient temperature) PN-1000009 (Europe, Middle East & Africa)



Chromium Chip A Single Cell Kit PN is region specific and should be used based on customer's geographical location.

Chromium i7 Multiplex Kit, 96 rxns PN-120262 (store at -20°C)

Chromium
i7 Multiplex Kit

PN

Chromium i7 Sample Index 1 220103

Chromium Accessories

Product	PN (Kit)	PN (Item)
10x Vortex Adapter	120251	330002
10x Chip Holder	120252	330019
10x Magnetic Separator	120250	230003

Recommended Thermal Cyclers

Thermal cyclers used must support uniform heating of 100 μ l emulsion volumes.

Supplier	Description	Part Number
BioRad	C1000 Touch Thermal Cycler with 96-Deep Well Reaction Module	1851197
Eppendorf	MasterCycler Pro	North America 950030010 International 6321 000.019
Thermo Fisher Scientific	Veriti 96-Well Thermal Cycler	4375786

Additional Kits, Reagents & Equipment

The items in the table below have been validated by 10x Genomics and are highly recommended for the Chromium Single Cell V(D)J protocol. Substituting materials may adversely affect system performance.

Supplier	Description		Part Number (US)	
Plastics				
Eppendorf	PCR Tubes 0.2 ml 8-tube strips DNA LoBind Tubes, 1.5 ml DNA LoBind Tubes, 2.0 ml	Choose either Eppendorf, USA Scientific or	951010022 022431021 022431048	
USA Scientific	TempAssure PCR 8-tube strip	Thermo Fisher Scientific PCR	1402-4700	
Thermo Fisher Scientific	MicroAmp 8-Tube Strip, 0.2 ml MicroAmp 8-Cap Strip, clear	8-tube strips.	N8010580 N8010535	
Rainin	Tips LTS 200UL Filter RT-L200FLR Tips LTS 1ML Filter RT-L1000FLR Tips LTS 20UL Filter RT-L10FLR	Tips LTS 1ML Filter RT-L1000FLR		
Kits & Reagents				
Thermo Fisher Scientific	Nuclease-free Water		AM9937	
Millipore Sigma	Ethanol, Pure (200 Proof, anhydrous)	Ethanol, Pure (200 Proof, anhydrous)		
Beckman Coulter	SPRIselect Reagent Kit	B23318		
Bio-Rad	10% Tween 20	1662404		
Ricca Chemical Company	Glycerin (glycerol), 50% (v/v) Aqueous Solu	3290-32		
Qiagen	Qiagen Buffer EB	19086		
Equipment				
VWR	Vortex Mixer Divided Polystyrene Reservoirs		10153-838 41428-958	
Eppendorf	Eppendorf ThermoMixer C Eppendorf SmartBlock 1.5 ml, Thermobloc (alternatively, use a temperature-controlled		5382000023 5360000038	
Rainin	Pipet-Lite Multi Pipette L8-50XLS+ Pipet-Lite Multi Pipette L8-200XLS+ Pipet-Lite Multi Pipette L8-10XLS+ Pipet-Lite Multi Pipette L8-20XLS+ Pipet-Lite LTS Pipette L-2XLS+ Pipet-Lite LTS Pipette L-10XLS+ Pipet-Lite LTS Pipette L-20XLS+ Pipet-Lite LTS Pipette L-100XLS+ Pipet-Lite LTS Pipette L-100XLS+ Pipet-Lite LTS Pipette L-200XLS+ Pipet-Lite LTS Pipette L-1000XLS+		17013804 17013805 17013802 17013803 17014393 17014388 17014392 17014384 17014391 17014382	

Additional Kits, Reagents & Equipment

The items in the table below have been validated by 10x Genomics and are highly recommended for the Chromium Single Cell V(D)J protocol. Substituting materials may adversely affect system performance.

Supplier	Description		Part Number (US)
Quantification & Quality Contr	rol		
Agilent	2100 Bioanalyzer Laptop Bundle High Sensitivity DNA Kit 4200 TapeStation High Sensitivity D5000 ScreenTape High Sensitivity D5000 Reagents	Choose Bioanalyzer, TapeStation or Qubit based on availability & preference.	G2943CA 5067-4626 G2991AA 5067-5592 5067-5593
Thermo Fisher Scientific	Qubit 4.0 Fluorometer Qubit dsDNA HS Assay Kit		Q33226 Q32854
KAPA Biosystems	KAPA Library Quantification Kit for Illumina	Platforms	KK4824

Protocol Steps & Timing

Day	Steps & Tilling	Timing Stop & Store
	Cell Preparation	
	Dependent on Cell Type	~1-1.5 h
3 h	Step 1 – GEM Generation & Barcoding	
	 1.1 Prepare Reaction Mix 1.2 Load Chromium Single Cell A Chip 1.3 Run the Chromium Controller 1.4 Transfer GEMs 1.5 GEM-RT Incubation 	20 min 10 min 6.5 min 3 min 55 min 500 4°C ≤72 h or -20°C ≤1 week
	Step 2 – Post GEM RT Cleanup	
	2.1 Post GEM-RT Cleanup – Dynabead	45 min
6 h	Step 3 – cDNA Amplification & QC*	
	3.1 cDNA Amplification3.2 cDNA Cleanup3.3 cDNA Quantification & QC	50 min 15 min 50 min 4°C ≤72 h or −20°C ≤1 week
	*After cDNA Amplification & QC, for Target Enrichment & Enriched Lik Expression Library Construction proceed directly to step 6.	orary Construction proceed to steps 4-5. For 5' Gene
	Step 4 – Target Enrichment from cDNA	
	 4.1 Target Enrichment 1 4.2 Post Target Enrichment 1 Cleanup – SPRIselect 4.3 Target Enrichment 2 4.4 Post Target Enrichment 2 Double Sided Size Selection SPRIselect 4.5 Post Target Enrichment QC & Quantification 	40 min 20 min 4°C ≤72 h 4°C ≤72 h or −20°C ≤1 week 40 min 40 min 30 min 4°C ≤72 h 4°C ≤72 h 4°C ≤72 h 500 500 500 500 500 500 500 500 500 50
	Step 5 – Enriched Library Construction	
8 h plus* *Time dependent on Stop options used and protocol steps executed (steps 4-5 only/ steps 4,5 & 6)	 5.1 Fragmentation, End Repair & A – tailing 5.2 Adaptor Ligation 5.3 Post Ligation Cleanup – SPRIselect 5.4 Sample Index PCR 5.5 Post Sample Index PCR Cleanup – SPRIselect 5.6 Post Library Construction QC 	45 min 25 min 20 min 40 min 20 min 50 min 50 min
	Step 6 – 5' Gene Expression (GEX) Library Construct	ion
	 6.1 GEX Fragmentation, End Repair & A-tailing 6.2 GEX Post Fragmentation, End Repair & A-tailing Doub Sided Size Selection – SPRIselect 6.3 GEX Adaptor Ligation 6.4 GEX Post Ligation Cleanup – SPRIselect 6.5 GEX Sample Index PCR 6.6 GEX Post Sample Index PCR Double Sided Cleanup – SPRIselect 	45 min 30 min 25 min 20 min 40 min 30 min 4°C ≤72 h 510P 4°C ≤72 h or −20°C long-term
	6.7 GEX Post Library Construction QC	50 min


Stepwise Objectives


The Single Cell V(D)J protocols offer comprehensive, scalable solutions for measuring immune repertoire information and gene expression from the same cell. Profile full-length (5' UTR to constant region), paired T-cell receptor (TCR), or B-cell immunoglobulin (Ig) transcripts from 100-10,000 individual cells per sample. GemCode Technology samples a pool of ~750,000 barcodes to separately index each cell's transcriptome. It does so by partitioning thousands of cells into nanoliter-scale Gel Beads-in-emulsion (GEMs), where all generated cDNA share a common 10x Barcode. Libraries are generated and sequenced and 10x Barcodes are used to associate individual reads back to the individual partitions. This document outlines the protocol to generate an enriched T-cell library and/or an enriched B-cell library, and/or a 5' Gene Expression library from amplified cDNA from the same cells.


Step 1 GEM Generation & Barcoding

GEMs are generated by combining barcoded Single Cell 5' Gel Beads, a Master Mix with cells, and Partitioning Oil on Chromium Chip A. To achieve single cell resolution, cells are delivered at a limiting dilution, such that the majority (~90 – 99%) of generated GEMs contains no cell, while the remainder largely contain a single cell.

Immediately following **GEM** generation, the Gel Bead is dissolved and any co-partitioned cell is lysed. Oligonucleotides containing (i) an Illumina R1 sequence (read 1 sequencing primer), (ii) a 16 nt 10x Barcode, (iii) a 10 nt unique molecular identifier (UMI), and (iv) 13 nt template switch oligo (TSO) are released and mixed with the cell lysate and a Master Mix containing reverse transcription (RT) reagents and poly(dT) RT primers. Incubation of the GEMs produces 10x Barcoded, full-length cDNA from polyadenylated mRNA.








Step 2 Post GEM-RT Cleanup & QC

GEMs are broken and pooled after GEM-RT reaction mixtures are recovered. Silane magnetic beads are used to purify the 10x Barcoded first-strand cDNA from the post GEM-RT reaction mixture, which includes leftover biochemical reagents and primers. After cleanup a user may decide to pursue target enrichment directly from first-strand cDNA, in which case, consult Demonstrated Protocol - Chromium Single Cell V(D)J Reagent Kits-Direct Target Enrichment (Document CG000166). Otherwise, users should proceed to cDNA amplification in this protocol.


Step 3 cDNA Amplification & QC

10x Barcoded, full-length cDNA is amplified via PCR with primers against common 5' and 3' ends added during GEM-RT. Amplification generates sufficient material to construct multiple libraries from the same cells, e.g. both T cell and/or B cell enriched libraries (steps 4 and 5) and 5' Gene Expression libraries (step 6).



Step 4
Target Enrichment from cDNA

Full-length V(D)J segments (10x Barcoded) are enriched from amplified cDNA via PCR amplification with primers specific to either the TCR or Ig constant regions. If both T and B cells are expected to be present in the partitioned cell population, TCR and Ig transcripts can be enriched in separate reactions from the same amplified cDNA material. P5 is added during enrichment.




Step 5
Enriched Library
Construction

Enzymatic fragmentation and size selection are used to generate variable length fragments that collectively span the V(D)J segments of the enriched TCR or Ig transcripts prior to library construction.

P7, a sample index, and an Illumina R2 sequence (read 2 primer sequence) are added via End Repair, A-tailing, Adaptor Ligation, and Sample Index PCR. The final libraries contain the P5 and P7 priming sites used in Illumina sequencing.


Step 6 5' Gene Expression (GEX) Library Construction

Enzymatic fragmentation and size selection are used to optimize the cDNA amplicon size prior to 5' Gene Expression library construction. P5, P7, a sample index, and Illumina R2 sequence (read 2 primer sequence) are added via End Repair, A-tailing, Adaptor Ligation, and Sample Index PCR. The final libraries contain the P5 and P7 priming sites used in Illumina sequencers.




Step 7 Sequencing

Illumina-ready sequencing libraries can be sequenced at the recommended depth & run parameters. Illumina sequencer compatibility, sample indices, library loading and pooling for sequencing are summarized in step 7.





Chromium Single Cell 5' Gene Expression Library



See Appendix for Oligonucleotide Sequences

Tips & Best Practices



Icons



includes additional guidance

Signifies critical step requiring accurate execution



Troubleshooting section includes additional guidance

Emulsion-safe Plastics

 Use validated emulsion-safe plastic consumables when handling GEMs as some plastics can destabilize GEMs.

Cell Concentration

- Recommended starting point is to load ~1700 cells per reaction, resulting in recovery of ~1000 cells, and a multiplet rate of ~0.8%. The optimal input cell concentration is 700-1,200 cells/µl.
- The presence of dead cells in the suspension may also reduce the recovery rate.
 Consult the 10x Genomics Single Cell Protocols Cell Preparation Guide and the Guidelines for Optimal Sample Preparation flowchart (Documents CG00053 and CG000126 respectively) for more information on preparing cells.
- Refer to the 10x Genomics Support website for more information regarding cell type specific sample preparation, for example, the Demonstrated Protocol for Enrichment of CD3+ T Cells from Dissociated Tissues for Single Cell RNA Sequencing and Immune Repertoire Profiling (Document CG000123).

Multiplet Rate (%)	# of Cells Loaded	# of Cells Recovered
~0.4%	~870	~500
~0.8%	~1,700	~1,000
~1.6%	~3,500	~2,000
~2.3%	~5,300	~3,000
~3.1%	~7,000	~4,000
~3.9%	~8,700	~5,000
~4.6%	~10,500	~6,000
~5.4%	~12,200	~7,000
~6.1%	~14,000	~8,000
~6.9%	~15,700	~9,000
~7.6%	~17,400	~10,000

General Reagent Handling

- Fully thaw and thoroughly mix reagents before use.
- Keep all enzymes and Master Mixes on ice during setup and use. Promptly move reagents back to the recommended storage after use.
- Calculate reagent volumes with 10% excess of 1 reaction values.
- Cover Partitioning Oil tubes and reservoirs to minimize evaporation.
- If using multiple chips, use separate reagent reservoirs for each chip during loading.
- Thoroughly mix samples with the beads during bead-based cleanup steps.

50% Glycerol Solution

- Purchase 50% glycerol solution from Ricca Chemical Company, Glycerin (glycerol), 50% (v/v) Aqueous Solution, PN-3290-32.
- Prepare 50% glycerol solution:
 - i. Mix an equal volume of water and 99% Glycerol, Molecular Biology Grade.
 - ii. Filter through a 0.2-µm filter.
 - iii. Store at –20°C in 1-ml LoBind tubes. 50% glycerol solution should be equilibrated to room temperature before use.

Pipette Calibration

- Follow manufacturer's calibration and maintenance schedules.
- Pipette accuracy is particularly important when using SPRIselect reagents.

Chromium Chip Handling

- Minimize exposure of reagents, chips, and gaskets to sources of particles and fibers, laboratory wipes, frequently opened flip-cap tubes, clothing that sheds fibers, and dusty surfaces.
- Execute steps without pause or delay, unless indicated. When multiple chips are to be used, load, run, and collect the content from one chip before loading the next.
- Fill all unused input wells in rows labeled 1, 2, and 3 on a chip with an appropriate volume of 50% glycerol solution before loading the used wells. DO NOT add glycerol to the Recovery Wells.
- Avoid contacting the bottom surface of the chip with gloved hands and other surfaces.
 Frictional charging can lead to inadequate priming of the channels, potentially leading to either clogs or wetting failures.
- Minimize the distance that a loaded chip is moved to reach the Chromium Controller.
- Keep the chip horizontal to prevent wetting the gasket with oil, which depletes the input volume and may adversely affect the quality of the resulting emulsion.

10x Chip Holders

- 10x Chip Holders encase Chromium Chips.
- The holder lid flips over to become a stand, holding the chip at 45 degrees for optimal recovery well content removal.
- Squeeze the black sliders on the back side of the holder together to unlock the lid and return the holder to a flat position.



Chromium Chip & Holder Assembly

- Align notch on the chip (upper left corner) and the holder.
- Insert the left-hand side of the chip under the guide. Depress the right-hand side of the chip until the spring-loaded clip engages.
- Close the lid before dispensing reagents into the wells.



Chromium Chip A Loading

- Place the assembled chip and holder flat on the bench with the lid closed.
- Dispense against the side of the wells.
- Bubble formation is normal and does not affect performance.
- When dispensing Gel Beads into the chip, wait for the remainder to drain into the bottom of the pipette tips and dispense again to ensure complete transfer.
- Refer to Load Chromium Chip A for specific instructions.



Gel Bead Handling

- Use one tube of Gel Beads per sample.
 DO NOT puncture the foil seals of tubes not used at the time.
- Equilibrate the Gel Beads strip to room temperature before use.
- Store unused Gel Beads at -80°C and avoid more than 10 freeze-thaw cycles.
 DO NOT store Gel Beads at -20°C.



- Attach a 10x Vortex Adapter to the top of standard laboratory vortexers to vortex the Gel Bead strips.
- After vortexing, remove the Gel Bead strip from the adapter. Flick the Gel Bead strip
 in a sharp, downward motion to maximize Gel Bead recovery. Confirm there are no
 bubbles at the bottom of the tubes.
- If the required volume of beads cannot be recovered, place the pipette tips against the sidewalls and slowly dispense the Gel Beads back into the tubes. DO NOT introduce bubbles into the tubes and verify that the pipette tips contain no leftover Gel Beads.
 Withdraw the full volume of beads again by pipetting slowly.

10x Gasket Attachment

- After reagents are loaded, attach the gasket by holding the tongue (curved end, to the right) and hook it on the left-hand tabs of the holder. Gently pull the gasket toward the right and hook it on the two right-hand tabs.
- DO NOT touch the smooth side of the gasket. DO NOT press down on the top of the gasket after attachment.
- Keep the assembly horizontal to avoid wetting the gasket with Partitioning Oil.



10x Magnetic Separator

- Offers two positions of the magnets (high and low) relative to a tube, depending on its orientation. Flip the magnetic separator over to switch between high (magnet•High) or low (magnet•Low) positions.
- If using MicroAmp 8-Tube Strips, use the high position (magnet•High) only throughout the protocol.



cDNA Amplification PCR Cycle Numbers

- Follow cycle number recommendations for high and low RNA content cells based on Targeted Cell Recovery and cell sample.
- Cycle numbers in the table below have been optimized assuming that the sample has >80% T and/or B cells. Samples with lower fraction of T and/or B cells may require additional cycle number optimization and/or may be enriched to increase the fraction of T or B cells. Refer to the Demonstrated Protocol for Enrichment of CD3+ T Cells from Dissociated Tissues for Single Cell RNA Sequencing and Immune Repertoire Profiling (Document CG000123).
- If the fraction of T and/or B cells in a cell sample is known, adjust PCR cycle number based on that fraction to ensure sufficient product generation.

Tutorial – Optimizing cDNA Amplification PCR Cycle Numbers					
Examples Sample A:	Recommended starting point for cycle number optimization.				
Primary cells with 15% T cell fraction. Targeted Cell Recovery is 10,000 cells. Only 1,500 (15%) cells are T cells. Total PCR cycles – 16.	Targeted Cell Recovery	<u>Low RNA</u> <u>Content Cells</u> Total Cycles	<u>High RNA</u> <u>Content Cells</u> Total Cycles		
Sample B: Cell line with high RNA content. Targeted Cell Recovery is 10,000 cells.	100–500	18	16		
Total PCR cycles – 11.	501-2,000	16	14		
Sample C: Cell mix with 90% low RNA content and	2,001–6,000	14	12		
10% high RNA content B cells. Targeted Cell Recovery is 10,000 cells. 90% B cells are low RNA content. Total PCR cycles – 13.	6,001–10,000	13	11		

Enzymatic Fragmentation

 Ensure enzymatic fragmentation reactions are prepared on ice and then loaded into a thermal cycler pre-cooled to 4°C prior to initiating the Fragmentation, End Repair, and A-tailing incubation steps.


SPRIselect Cleanup & Size Selection

- After aspirating the desired volume of SPRIselect reagent, examine the pipette tips before dispensing to ensure the correct volume is transferred.
- Pipette mix thoroughly as insufficient mixing of sample and SPRIselect reagent will lead to inconsistent results.
- Use fresh preparations of 80% Ethanol.

Tutorial — SPRIselect Reagent: DNA Sample Ratios

SPRI beads selectively bind DNA according to the ratio of SPRIselect reagent (beads).

Example: Ratio = $\frac{\text{Volume of SPRIselect reagent added to the sample}}{\text{Volume of DNA sample}} = \frac{50 \, \mu l}{100 \, \mu l} = 0.5X$



After the first SPRI, supernatant is transferred for a second SPRI while larger fragments are discarded (green). After the second SPRI, fragments on beads are eluted and kept while smaller fragments are discarded (blue). Final sample has a tight fragment size distribution with reduced overall amount (black).

Tutorial — Double Sided Size Selection

Step a – First SPRIselect: Add 50 μl SPRIselect reagent to 100 μl sample (0.5X).

Ratio = $\frac{\text{Volume of SPRIselect reagent added to the sample}}{\text{Volume of DNA sample}} = \frac{50 \, \mu l}{100 \, \mu l} = 0.5X$

Step b – Second SPRIselect: Add 30 μl SPRIselect reagent to supernatant from step a (0.8X).

Ratio = $\frac{\text{Total Volume of SPRI select reagent added to the sample (step a + b)}}{\text{Original Volume of DNA sample}} = \frac{50 \ \mu \text{l} + 30 \ \mu \text{l}}{100 \ \mu \text{l}} = 0.8 \text{X}$

Sample Indices in Sample Index PCR

- Choose the appropriate sample index sets to ensure that no sample indices overlap in a multiplexed sequencing run.
- Each well in the i7 Sample Index plate contains a unique mix of 4 oligos.
- The sample indices can therefore be used in any combination.
- Each sample index set is base-balanced to avoid monochromatic signal issues when it is the sole sample loaded on an Illumina sequencer.

Step 1

GEM Generation & Barcoding

- **1.1** Prepare Master Mix
- **1.2** Load Chromium Chip A
- **1.3** Run the Chromium Controller
- **1.4** Transfer GEMs
- **1.5** GEM-RT Incubation

1.0 GEM Generation & Barcoding

GET START	ED!				
Action		Item	10x PN	Preparation & Handling	Storage
Equilibrate to Room Temperature		Chromium Single Cell 5' Gel Beads	220112	Equilibrate to room temperature 30 min before loading the chip.	-80°C
	•	RT Reagent Mix	220089	Vortex, verify no precipitate, centrifuge briefly.	-20°C
	•	Poly-dT RT Primer	2000007	Vortex, verify no precipitate, centrifuge briefly.	-20°C
	•	Additive A	220074	Vortex, verify no precipitate, centrifuge briefly.	-20°C
Place on Ice		RT Enzyme Mix B	2000010/ 2000021	Centrifuge briefly before adding to the mix.	-20°C
Obtain		Partitioning Oil	220088	-	Ambient
		Chromium Chip A	-	nerica & Asia Pacific) ope, Middle East & Africa)	Ambient
			Use the indic	ated region-specific PN only.	
		10x Gasket	370017/ 3000072	See Tips & Best Practices.	Ambient
		10x Chip Holder	330019	See Tips & Best Practices.	Ambient
		10x Vortex Adapter	330002	See Tips & Best Practices.	Ambient
e		50% glycerol solution If using <8 reactions	-	See Tips & Best Practices.	-



Firmware Version 2.0 or higher is required in the Chromium Controller or the Single Cell Chromium Controller used for the Single Cell V(D)J protocols.

1.1 Prepare Reaction Mix

a. Prepare Master Mix on ice. Pipette mix 15x and centrifuge briefly.

			•	
Master Mix Add reagents in the order listed	PN	1X (μl)	4X + 10% (µl)	8X + 10% (μl)
RT Reagent Mix	220089	50.0	220.0	440.0
Poly-dT RT Primer	2000007	5.9	26.0	51.9
Additive A	220074	2.4	10.6	21.1
RT Enzyme Mix B	2000010/ 2000021	10.0	44.0	88.0
Total	-	68.3	300.6	601.0

b. Add 68.3 µl Master Mix into each tube of a PCR 8-tube strip on ice.

Cell Suspension Volume Calculator Table (for step 1.2)

Volume of Cell Suspension Stock per reaction (µl) | Volume of Nuclease-free Water per reaction (µl)

Cell Stock	Tai gotou ooti itoootoi j										
Concentration (Cells/µl)	500	1000	2000	3000	4000	5000	6000	7000	8000	9000	10000
100	8.7 23.0	17.4 14.3	n/a								
200	4.4 27.3	8.7 23.0	17.4 14.3	26.1 5.6	n/a						
300	2.9	5.8 25.9	11.6 20.1	17.4 14.3	23.2	29.0 2.7	n/a	n/a	n/a	n/a	n/a
400	2.2	4.4 27.3	8.7 23.0	13.1	17.4 14.3	21.8	26.1 5.6	30.5 1.2	n/a	n/a	n/a
500	1.7	3.5	7.0 24.7	10.4	13.9 17.8	17.4 14.3	20.9	24.4	27.8 3.9	31.3 0.4	n/a
600	1.5	2.9	5.8 25.9	8.7 23.0	11.6	14.5 17.2	17.4 14.3	20.3	23.2	26.1 5.6	29.0
700	1.2	2.5 29.2	5.0 26.7	7.5 24.2	9.9 21.8	12.4 19.3	14.9	17.4 14.3	19.9 11.8	22.4 9.3	24.9
800	1.1	2.2 29.5	4.4	6.5	8.7 23.0	10.9	13.1	15.2 16.5	17.4 14.3	19.6 12.1	21.8
900	1.0	1.9	3.9 27.8	5.8 25.9	7.7 24.0	9.7 22.0	11.6	13.5 18.2	15.5 16.2	17.4 14.3	19.3 12.4
1000	0.9	1.7	3.5 28.2	5.2 26.5	7.0 24.7	8.7 23.0	10.4	12.2 19.5	13.9 17.8	15.7 16.0	17.4 14.3
1100	0.8	1.6	3.2 28.5	4.7	6.3	7.9 23.8	9.5 22.2	11.1	12.7 19.0	14.2 17.5	15.8 15.9
1200	0.7	1.5	2.9	4.4	5.8 25.9	7.3 24.4	8.7 23.0	10.2	11.6	13.1	14.5 17.2
1300	0.7	1.3	2.7 29.0	4.0 27.7	5.4 26.3	6.7 25.0	8.0 23.7	9.4 22.3	10.7 21.0	12.0 19.7	13.4 18.3
1400	0.6	1.2 30.5	2.5 29.2	3.7 28.0	5.0 26.7	6.2 25.5	7.5 24.2	8.7 23.0	9.9 21.8	11.2 20.5	12.4 19.3
1500	0.6	1.2 30.5	2.3 29.4	3.5 28.2	4.6 27.1	5.8 25.9	7.0 24.7	8.1 23.6	9.3 22.4	10.4	11.6
1600	0.5	1.1	2.2	3.3	4.4	5.4 26.3	6.5	7.6 24.1	8.7 23.0	9.8 21.9	10.9
1700	0.5	1.0	2.0	3.1	4.1 27.6	5.1 26.6	6.1	7.2 24.5	8.2 23.5	9.2 22.5	10.2
1800	0.5	1.0	1.9	2.9	3.9 27.8	4.8	5.8 25.9	6.8	7.7 24.0	8.7 23.0	9.7
1900	0.5	0.9	1.8	2.7 29.0	3.7	4.6	5.5	6.4	7.3	8.2	9.2
2000	0.4	0.9	1.7	2.6	3.5	4.4	5.2	6.1	7.0	7.8	8.7
Grev hoxes:	31.3	30.8	30.0	29.1	28.2	27.3	26.5	25.6	24.7	23.9	23.0


Grey boxes: Yellow boxes: Volumes that would exceed the allowable water volume in each reaction

Indicate a low transfer volume that may result in higher cell load variability

Blue boxes: Optimal range of cell stock concentration to maximize the likelihood of achieving the desired cell recovery target

1.2 Load Chromium Chip A

See Tips & Best Practices for chip handling instructions. When loading the chip, raising and depressing the pipette plunger should each take ~5 sec. Dispense against the side of the well, as illustrated below. Avoid contact with the bottom of the well. Bubble formation is normal and does not affect performance.





- a. Assemble Chromium Chip A in a 10x Chip Holder See Tips & Best Practices
- b. Dispense 50% Glycerol Solution into Unused Chip Wells (if < 8 samples per chip)
- i. 90 μ l to unused wells in row labeled 1.
- ii. 40 μ l to unused wells in row labeled 2.
- iii. 270 µl to unused wells in row labeled 3.

DO NOT add 50% glycerol solution to the top row of Recovery Wells. DO NOT use any substitute for 50% glycerol solution.

c. Prepare Master Mix + Cell Suspension

Refer to the Cell Suspension Volume Calculator Table and add the appropriate volume of nuclease-free water first, followed by corresponding volume of single cell suspension to Master Mix for a total of 100 μ l in each tube. Gently pipette mix the single cell suspension before adding to the Master Mix.

d. Load Row Labeled 1

Gently pipette mix the Master Mix + Cell Suspension and using the same pipette tip, dispense $90~\mu l$ against the side of each well in row labeled 1.

e. Prepare Gel Beads

Snap the Gel Bead strip into a 10x Vortex Adapter. Vortex **30 sec**. Remove the Gel Bead strip and flick in a sharp, downward motion to ensure maximum recovery. Confirm there are no bubbles at the bottom of the tubes and liquid levels look even.

f. Load Row Labeled 2

Puncture the foil seal of the Gel Bead tubes. Slowly aspirate $40~\mu l$ Gel Beads. Dispense against the side of each well in row labeled 2.

g. Load Row Labeled 3



Dispense 270 μ l Partitioning Oil against the side of each well in **row labeled 3** by pipetting two aliquots of 135 μ l from a reagent reservoir. Failure to add Partitioning Oil can damage the Chromium Controller.

h. Attach 10x Gasket

Align the notch with the top left-hand corner. Ensure the gasket holes are aligned with the wells. Avoid touching the smooth gasket surface. DO NOT press down on the gasket.

Keep horizontal to avoid wetting the gasket.



1.3 Run the Chromium Controller

- **a.** Press the eject button on the Controller to eject the tray.
- **b.** Place the assembled chip with the gasket in the tray. Press the button to retract the tray.
- **c.** Confirm the Chromium Chip A program on screen. Press the play button.



d. At completion of the run (~6.5 min), the Controller will chime. Immediately proceed to the next step.





1.4 Transfer GEMs

- a. Place a tube strip on ice.
- **b.** Press the eject button of the Controller and remove the chip.
- c. Discard the gasket. Open the chip holder. Fold the lid back until it clicks to expose the wells at 45 degrees.



- **d.** Check the volume in rows 1-3. Abnormally high volume in any well indicates a clog.
- e. Slowly aspirate 100 μl GEMs from the lowest points of the Recovery Wells in the top row without creating a seal between the pipette tips and the bottom of the wells.
- f. Withdraw pipette tips from the wells. GEMs should appear opaque and uniform across all channels. Excess Partitioning Oil (clear) in the pipette tips indicates a potential clog.
- g. Over the course of ~20 sec, dispense GEMs into the tube strip on ice with the pipette tips against the sidewalls of the tubes.
- h. If multiple chips are run back-to-back, cap/ cover the GEM-containing tube strip and place on ice for no more than 1 h.

Expose Wells at 45 Degrees







1.5 GEM-RT Incubation

Use a thermal cycler that can accommodate at least 100 μ l volume. A volume of 125 μ l is the preferred setting on Bio-Rad C1000 Touch. In alternate thermal cyclers, use highest reaction volume setting.

a. Incubate in a thermal cycler with the following protocol.

Lid Temperature	Reaction Volume	Run Time	
53°C	125 μl	~55 min	
Step	Temperature	Time	
1	53°C	00:45:00	
2	85°C	00:05:00	
3	4°C	Hold	



b. Store at 4°C for up to 72 h or at -20°C for up to a week, or proceed to the next step.

Step 2

Post GEM-RT Cleanup

2.1 Post GEM-RT Cleanup – Dynabeads

Step 2 Post GEM-RT Cleanup

2.0 Post GEM-RT Cleanup

GET STARTED!							
Action		Item	10x PN	Preparation & Handling	Storage		
Equilibrate to Room Temperature		Additive A	220074	Thaw, vortex, verify no precipitate, centrifuge briefly.	-20°C		
		Dynabeads MyOne SILANE	2000048	Vortex thoroughly (≥30 sec) immediately before adding to the mix. If still clumpy, pipette mix to resuspend completely. DO NOT centrifuge before use.	4°C		
Thaw at 65°C	•	Buffer Sample Clean Up 1	220020	Thaw for 10 min at 65°C at max speed on a thermomixer. Verify there are no visible crystals. Cool to room temperature.	-20°C		
Obtain	\bigcirc	Recovery Agent	220016	-	Ambient		
		Qiagen Buffer EB	-	Manufacturer's recommendations.	-		
		Bio-Rad 10% Tween 20	-	Manufacturer's recommendations.	-		
		10x Magnetic Separator	230003	-	Ambient		
		Prepare 80% Ethanol Prepare 15 ml for 8 reactions.	-	Prepare fresh.	-		

Step 2 Post GEM-RT Cleanup

2.1 Post GEM-RT Cleanup – Dynabeads

a. Add 125 μl Recovery Agent to each sample (post GEM-RT incubation) at room temperature. DO NOT pipette mix or vortex the biphasic mixture. Wait 2 min.

The resulting biphasic mixture contains Recovery Agent/Partitioning Oil (pink) and aqueous phase (clear), with no persisting emulsion (opaque).

If biphasic separation is incomplete:

Firmly secure the cap on the tube strip, ensuring that no liquid is trapped between the cap and the tube rim. Mix by inverting the capped tube strip 5x, centrifuge briefly, and proceed to step b. DO NOT invert without firmly securing the caps.



A smaller aqueous phase volume indicates a clog during GEM generation.

b. Slowly remove 125 μ l Recovery Agent/ Partitioning Oil (pink) from the bottom of the tube. DO NOT aspirate any aqueous sample.



Biphasic Mixture



1

c. Prepare Dynabeads Cleanup Mix.

		Dynabeads Cleanup Mix Add reagents in the order listed	PN	1X (μl)	4X + 10% (µl)	8X + 10% (μl)
		Nuclease-free Water		5	22	44
	•	Buffer Sample Clean Up 1	220020	182	801	1602
	1 /	Dynabeads MyOne SILANE Vortex thoroughly (≥30 sec) immediately before adding to the mix.				
Resuspend clump		Aspirate the full liquid volume with a pipette tip to verify that the beads have not settled in the bottom of the tube. If clumps are present, pipette mix to resuspend completely. DO NOT centrifuge before use.	2000048	8	35	70
		Additive A	220074	5	22	44
		Total	-	200	880	1760

- **d.** Vortex and add **200 μl** to each sample. Pipette mix 5x (pipette set to 200 μl).
- e. Incubate 10 min at room temperature.

Add Dynabeads Cleanup Mix

Step 2 Post GEM-RT Cleanup

f. Prepare Elution Solution I. Vortex and centrifuge briefly.

Elution Solution I Add reagents in the order listed	PN	1X (μl)	10X (µl)
Buffer EB	-	98	980
10% Tween 20	-	1	10
Additive A	220074	1	10
Total	-	100	1000

- g. At the end of 10 min incubation, place on a 10x Magnetic Separator•High position (magnet•High) until the solution clears.
 - A white interface between the aqueous phase and Recovery Agent is normal.
- **h.** Remove the supernatant.
- i. Add 300 µl 80% ethanol to the pellet while on the magnet. Wait 30 sec.
- j. Remove the ethanol.
- k. Add 200 µl 80% ethanol to pellet. Wait 30 sec.
- l. Remove the ethanol.
- m.Centrifuge briefly. Place on the magnet-Low.
- n. Remove remaining ethanol. Air dry for 2 min.
- o. Remove from the magnet. Immediately add 35.5 µl Elution Solution I.
- **p.** Pipette mix (pipette set to 30 μ l) without introducing bubbles. Pipette mix 15x. If beads still appear clumpy, continue pipette mixing until fully resuspended.
- q. Incubate 1 min at room temperature.
- r. Place on the magnet•Low until the solution clears.
- **s.** Transfer $35 \mu l$ sample to a new tube strip.

Step 3

cDNA Amplification & QC

- **3.1** cDNA Amplification
- **3.2** cDNA Cleanup SPRIselect
- **3.3** cDNA QC & Quantification



3.0 cDNA Amplification & QC

GET STARTE	:D!			
Action	Item	10x PN	Preparation & Handling	Storage
Equilibrate to Room	cDNA Additive	220067	Vortex, centrifuge briefly.	-20°C
Temperature	oDNA Primer Mix	220106	Vortex, centrifuge briefly.	-20°C
	Beckman Coulter SPRIselect Reagent	-	Manufacturer's recommendations.	-
	Agilent Bioanalyzer High Sensitivity Kit If used for QC and quantification	-	Manufacturer's recommendations.	-
	Agilent TapeStation ScreenTape and Reagents If used for QC and quantification	-	Manufacturer's recommendations.	-
	Qubit dsDNA HS Assay Kit If used for quantification	-	Manufacturer's recommendations.	-
Place on ice	Amplification Master Mix	220125	Vortex, centrifuge briefly.	-20°C
Obtain	Qiagen Buffer EB	-	Manufacturer's recommendations.	-
	10x Magnetic Separator	230003	-	Ambient
	Prepare 80% Ethanol Prepare 15 ml for 8 samples	-	Prepare fresh.	-

3.1 cDNA Amplification

a. Prepare cDNA Amplification Mix on ice. Vortex and centrifuge briefly.

cDNA Amplification Mix Add reagents in the order listed	PN	1Χ (μl)	4Χ + 10% (μl)	8X + 10% (μl)
Nuclease-free Water	-	8	35	70
Amplification Master Mix	220125	50	220	440
cDNA Additive	220067	5	22	44
oDNA Primer Mix	220106	2	9	18
Total	-	65	286	572

- b. Add 65 µl cDNA Amplification Mix to 35 µl sample (Post GEM-RT Cleanup).
- c. Pipette mix 5x (pipette set to 90 µl). Centrifuge briefly.
- d. Incubate in a thermal cycler with the following protocol.

Lid Temperature	Reaction Volume	Run Time
105°C	100 μl	~25-50 min
Step	Temperature	Time
1	98°C	00:00:45
2	98°C	00:00:20
3	67°C	00:00:30
4	72°C	00:01:00
5	Go to Step 2, see table be	low for total # of cycles
6	72°C	00:01:00
7	4°C	Hold



The optimal number of cycles is a trade-off between generating sufficient final mass for library construction and minimizing PCR amplification artifacts. Cycle numbers were optimized assuming that sample includes >80% T or B cells. If testing cells types with a known fraction of T and/or B cells, adjust cycle number based on that fraction to generate sufficient product. See Tips and Best Practices for examples.

Recommended starting point for cycle number optimization.

Targeted Cell Recovery	Primary Cells Total Cycles	Cell Lines Total Cycles
100 – 500	18	16
501 – 2,000	16	14
2,001 – 6,000	14	12
6,001 – 10,000	13	11



e. Store at 4°C for up to 72 h or proceed to the next step.

3.2 cDNA Cleanup – SPRIselect


- a. Vortex to resuspend the SPRIselect reagent. Add **60 μl** SPRIselect reagent **(0.6X)** to each sample and pipette mix 15x (pipette set to 150 μl).
- b. Incubate 5 min at room temperature.
- c. Place on the magnet•High until the solution clears.
- **d.** Remove the supernatant.
- e. Add 200 μ l 80% ethanol to the pellet. Wait 30 sec.
- f. Remove the ethanol.
- g. Repeat steps e and f for a total of 2 washes.
- h. Centrifuge briefly and place on the magnet•Low.
- i. Remove any remaining ethanol. Air dry for 2 min.
- j. Remove from the magnet. Add 45.5 µl Buffer EB. Pipette mix 15x.
- k. Incubate 2 min at room temperature.
- I. Place the tube strip on the magnet•High until the solution clears.
- m. Transfer 45 µl sample to a new tube strip.



n. Store at 4°C for up to 72 h or at -20°C for up to a week, or proceed to the next step.

3.3 cDNA QC & Quantification


a. Run 1 μ l undiluted sample (Dilution Factor 1) on an Agilent Bioanalyzer High Sensitivity chip.





For 5' Gene Expression Library Construction proceed directly to step 6 after step 3.3.

b. If proceeding to 5' GEX Library Construction (step 6), determine cDNA yield for each sample. Example calculation below.



Alternate Quantification Methods:

- Agilent TapeStation. See Appendix for representative traces
- Qubit Fluorometer and Qubit dsDNA HS Assay Kit.

Step 4

Target Enrichment from cDNA

- **4.1** Target Enrichment 1
- **4.2** Post Target Enrichment 1 Cleanup SPRIselect
- **4.3** Target Enrichment 2
- **4.4** Post Target Enrichment 2 Double Sided Size Selection SPRIselect
- **4.5** Post Target Enrichment QC & Quantification

4.0 Target Enrichment from cDNA

GET STARTE	ED!				
Action		Item	10x PN	Preparation & Handling	Storage
Equilibrate to		For Human Samples (Cr	noose B or T-cell p	rimers based on desired enrichmen	t products)
Room Temperature	•	Human T Cell Mix 1	2000008	Vortex, centrifuge briefly.	-20°C
		Human T Cell Mix 2	2000009	Vortex, centrifuge briefly.	-20°C
		Human B Cell Mix 1	2000035	Vortex, centrifuge briefly.	-20°C
		Human B Cell Mix 2	2000036	Vortex, centrifuge briefly.	-20°C
		For Mouse Samples (Che	oose B or T-cell pr	imers based on desired enrichment	products)
	•	Mouse T Cell Mix 1	2000075	Vortex, centrifuge briefly.	-20°C
		Mouse T Cell Mix 2	2000079	Vortex, centrifuge briefly.	-20°C
		Mouse B Cell Mix 1	2000080	Vortex, centrifuge briefly.	-20°C
		Mouse B Cell Mix 2	2000081	Vortex, centrifuge briefly.	-20°C
		For all Samples			
		cDNA Additive	220067	Vortex, centrifuge briefly.	-20°C
		Beckman Coulter SPRIselect Reagent	-	Manufacturer's recommendations.	-
		Agilent Bioanalyzer High Sensitivity Kit If used for QC and quantification	-	Manufacturer's recommendations.	-
		Agilent TapeStation ScreenTape and Reagents If used for QC and quantification	-	Manufacturer's recommendations.	-
		Qubit dsDNA HS Assay Kit If used for quantification	-	Manufacturer's recommendations.	-
Place on Ice		Amplification Master Mix	220125	Vortex, centrifuge briefly.	–20°C
Obtain		Qiagen Buffer EB	-	-	Ambient
		10x Magnetic Separator	230003	See Tips & Best Practices.	Ambient
		Prepare 80% Ethanol Prepare 15 ml for 8 reactions	-	See Tips & Best Practices.	Ambient

4.1 Target Enrichment 1

- a. Add 33 μl nuclease-free water into a tube strip on ice and then transfer 2 μl sample (post cDNA Amplification & QC, step 3.3) to the same tube for a total of 35 μl.
- b. Prepare Target Enrichment 1 Reaction Mix on ice. Vortex and centrifuge briefly.

PN	1Χ (μl)	4X + 10% (μl)	8X + 10% (μl)
-	5	22	44
220125	50	220	440
220067	5	22	44
Human 2000008/ Mouse 2000075			
or Human 2000035/ Mouse 2000080	5	22	44
-	65	286	572
	- 220125 220067 Human 2000008/ Mouse 2000075 or Human 2000035/	- 5 220125 50 220067 5 Human 2000008/ Mouse 2000075 or Human 2000035/ Mouse 2000080	10% (μl) - 5 22 220125 50 220 220067 5 22 Human 2000008/ Mouse 2000075 or Human 2000035/ Mouse 2000080

- c. Add **65** µl Target Enrichment 1 Reaction Mix to each tube containing **35** µl sample.
- d. Pipette mix 5x (pipette set to 90 µl). Centrifuge briefly.
- e. Incubate in a thermal cycler with the following protocol.

Lid Temperature	Reaction Volume	Run Time	
105°C	100 µl	~20-30 min	
Step	Temperature	Time	
1	98°C	00:00:45	
2	98°C	00:00:20	
3	67°C	00:00:30	
4	72°C	00:01:00	
5 Different cycle numbers for T & B cells	T Cell: Go to Step 2, B Cell: Go to Step 2	9x (total 10 cycles) 2, 5x (total 6 cycles)	
6	72°C	00:01:00	
7	4°C	Hold	





f. Store at 4°C for up to 72 h or proceed to the next step.

4.2 Post Target Enrichment 1 Cleanup – SPRIselect

- **a.** Vortex to resuspend the SPRIselect reagent. Add **80 µl** SPRIselect reagent **(0.8X)** to each sample. Pipette mix 15x (pipette set to 150 µl).
- b. Incubate 5 min at room temperature.
- c. Place tube strip on the magnet•High until the solution clears.
- **d.** Remove the supernatant.
- e. Add 200 µl 80% ethanol to the pellet. Wait 30 sec.
- f. Remove the ethanol.
- g. Repeat steps e and f for a total of 2 washes.
- h. Centrifuge briefly. Place on the magnet•Low.
- i. Remove remaining ethanol. Air dry for 2 min.
- j. Remove from the magnet. Add 35.5 µl Buffer EB. Pipette mix 15x.
- k. Incubate 2 min at room temperature.
- I. Place on the magnet•Low until the solution clears.
- m. Transfer 35 µl sample to a new tube strip.



n. Store at 4°C in for up to 72 h or at -20°C for up to a week, or proceed to the next step.

4.3 Target Enrichment 2

a. Prepare Target Enrichment 2 Reaction Mix on ice. Vortex and centrifuge briefly.

Target Enrichment 2 Reaction Mix Add reagents in the order listed	PN	1Χ (μl)	4X + 10% (μl)	8X + 10% (μl)
Nuclease-free Water	-	5	22	44
Amplification Master Mix	220125	50	220	440
CDNA Additive	220067	5	22	44
T Cell Mix 2	Human 2000009/ Mouse 2000079 or Human 2000036/	5	22	44
B Cell Mix 2	Mouse 2000081			
Total	-	65	286	572

- c. Add **65** µl Target Enrichment 2 Reaction Mix to each tube containing **35** µl sample.
- d. Pipette mix 5x (pipette set to $90~\mu l$). Centrifuge briefly.
- e. Incubate in a thermal cycler with the following protocol.

Lid Temperature	Reaction Volume	Run Time
105°C	100 µl	~25-30 min
Step	Temperature	Time
1	98°C	00:00:45
2	98°C	00:00:20
3	67°C	00:00:30
4	72°C	00:01:00
5 Different cycle numbers for T & B cells		, 9x (total 10 cycles) 2, 7x (total 8 cycles)
6	72°C	00:01:00
7	4°C	Hold





f. Store at $4^{\circ}C$ for up to 72 h or proceed to the next step.

4.4 Post Target Enrichment 2 Double Sided Size Selection – SPRIselect

- a. Vortex to resuspend SPRIselect reagent. Add 50 μ l SPRIselect reagent (0.5X) to each sample. Pipette mix 15x (pipette set to 145 μ l).
- b. Incubate 5 min at room temperature.
- c. Place on the magnet•High until the solution clears. DO NOT discard supernatant.
- d. Transfer 145 µl supernatant to a new tube strip.
- e. Vortex to resuspend SPRIselect reagent. Add **30 μl** SPRIselect reagent (**0.8X**) to each sample. Pipette mix 15x (pipette set to 150 μl).
- f. Incubate 5 min at room temperature.
- g. Place on the magnet•High until the solution clears.
- h. Remove 170 µl supernatant. DO NOT discard any beads.
- i. Add 200 µl 80% ethanol. Wait 30 sec.
- j. Remove the ethanol.
- **k.** Repeat steps i and j for a total of 2 washes.
- I. Centrifuge briefly. Place on the magnet•Low.
- **m.** Remove remaining ethanol wash. DO NOT over-dry beads to ensure maximum elution efficiency.
- n. Remove from the magnet. Add 45.5 µl Buffer EB. Pipette mix 15x.
- o. Incubate 2 min at room temperature.
- p. Place on the magnet•Low until the solution clears.
- **q.** Transfer $45 \mu l$ sample to a new tube strip.





r. Store at 4°C for up to 72 h or at -20°C for up to 1 week, or proceed to the next step.

4.5 Post Target Enrichment QC & Quantification

a. Run 1 μ l sample at 1:5 dilution (Dilution Factor 5) on an Agilent Bioanalyzer High Sensitivity chip.

Samples of RNA-rich cells may require additional dilution in nuclease-free water. The number of distinct peaks may vary. Higher molecular weight product (2,000-9,000 bp) may be present. This does not affect sequencing.






b. Determine yield for each sample. Example calculation below.

EXAMPLE CALCULATION

i. Select Region

Under the "Electropherogram" view choose the "Region Table". Manually select the region of $\sim 200 - \sim 9000$ bp.



iii. <u>Calculate</u>

Concentration: 5195.81 pg/µl

Dilution Factor: 5

Enriched Product Conc.

 $\frac{\text{Conc.} (\text{pg/}\mu\text{l}) \times \text{Dilution Factor}}{1000 (\text{pg/}\text{ng})} = \frac{5195.81 \times 5}{1000} = 26 \text{ ng/}\mu\text{l}$

Example Calculation for Carrying Forward
50 ng Sample for Enriched Library Construction

Volume for 50 ng = $\frac{50 \text{ ng}}{26 (\text{ng/µl})} = \frac{1.9 \text{ µl}}{1.9 \text{ µl}}$


Enriched Library Construction Sample =1.9 μ l + 18.1 μ l nuclease-free water =20 μ l total

If <50 ng available, carry forward 20 μ l sample (2-50 ng) into Enriched Library Construction.



DO NOT exceed a mass of 50 ng in the 20 µl carry forward volume.

ii. Note Concentration [pg/µl]



Alternate Quantification Methods:

· Qubit Fluorometer and Qubit dsDNA HS Assay Kit.

Step 5

Enriched Library Construction

- **5.1** Fragmentation, End Repair & A-tailing
- **5.2** Adaptor Ligation
- **5.3** Post Ligation Cleanup SPRIselect
- **5.4** Sample Index PCR
- **5.5** Post Sample Index PCR Cleanup SPRIselect
- **5.6** Post Library Construction QC



5.0 Enriched Library Construction

GET START	ED!				
Action		Item	10x PN	Preparation & Handling	Storage
Equilibrate to Room Temperature		Fragmentation Buffer	220108	Thaw, vortex, verify no precipitate, centrifuge briefly.	–20°C
		Adaptor Mix	220026	Vortex, centrifuge briefly.	-20°C
		Ligation Buffer	220109	Thaw, vortex, verify no precipitate, centrifuge briefly.	-20°C
		SI-PCR Primer	220111	Vortex, centrifuge briefly.	-20°C
		Chromium i7 Sample Index Plate	220103	-	-20°C
		Beckman Coulter SPRIselect Reagent	-	Manufacturer's recommendations.	-
		Agilent Bioanalyzer High Sensitivity Kit If used for QC	-	Manufacturer's recommendations.	-
		Agilent TapeStation ScreenTape and Reagents If used for QC	-	Manufacturer's recommendations.	-
Place on Ice	•	Fragmentation Enzyme Blend	220107/ 220130	Centrifuge briefly.	-20°C
		DNA Ligase	220110/ 220131	Centrifuge briefly.	-20°C
		Amplification Master Mix	220125	Vortex, centrifuge briefly.	-20°C
Obtain		Qiagen Buffer EB	-	-	Ambient
		10x Magnetic Separator	230003	See Tips & Best Practices.	Ambient
		Prepare 80% Ethanol Prepare 15 ml for 8 reactions	-	Prepare fresh.	Ambient

5.1 Fragmentation, End Repair & A-tailing

- a. Determine the volume for 50 ng mass of sample (see example calculation at step 4.5). Dispense the sample volume in a tube strip on ice. If the volume required for 50 ng is less than 20 μ l, adjust the total volume of each sample to 20 μ l with nuclease-free water. If the volume for 50 ng exceeds 20 μ l, carry only 20 μ l sample into library construction.
- b. Prepare a thermal cycler with the following incubation protocol.

Lid Temperature	Reaction Volume	Run Time
65°C	50 μl	~35 min
Step	Temperature	Time
Pre-cool block Pre-cool block prior to preparing the Fragmentation Mix	4°C	Hold
Fragmentation	32°C	00:02:00
End Repair & A-tailing	65°C	00:30:00
Hold	4°C	Hold



- c. Vortex Fragmentation Buffer. Verify there is no precipitate.
- d. Prepare Fragmentation Mix on ice. Pipette mix and centrifuge briefly.

Fragmentation Mix Add reagents in the order listed	PN	1Χ (μl)	4X + 10% (μl)	8X + 10% (μl)
Nuclease-free Water	-	15	66	132
Fragmentation Buffer	220108	5	22	44
Fragmentation Enzyme Blend	220107/ 220130	10	44	88
Total	-	30	132	264

- e. Add 30 μl Fragmentation Mix into each tube containing 20 μl sample.
- f. Pipette mix 15x (pipette set to 30 µl) on ice. Centrifuge briefly.
- **g.** Transfer into the pre-cooled thermal cycler (4°C) and press "SKIP" to initiate the protocol.

5.2 Adaptor Ligation

a. Prepare Adaptor Ligation Mix. Pipette mix and centrifuge briefly.

Adaptor Ligation Mix Add reagents in the order listed	PN	1X (μl)	4X + 10% (μl)	8X + 10% (μl)
Nuclease-free Water	-	17.5	77	154
Ligation Buffer	220109	20	88	176
ONA Ligase	220110/ 220131	10	44	88
Adaptor Mix	220026	2.5	11	22
Total	-	50	220	440

- **b.** Remove the sample from the thermal cycler.
- c. Add 50 μl Adaptor Ligation Mix to 50 μl sample. Pipette mix 15x (pipette set to 90 μl). Centrifuge briefly.
- d. Incubate in a thermal cycler with the following protocol.

Lid Temperature	Reaction Volume	Run Time
30°C	100 μl	15 min
Step	Temperature	Time
1	20°C	00:15:00
2	4°C	Hold

5.3 Post Ligation Cleanup – SPRIselect

- a. Vortex to resuspend SPRIselect Reagent. Add 80 μ l SPRIselect Reagent (0.8X) to each sample. Pipette mix 15x (pipette set to 150 μ l).
- b. Incubate 5 min at room temperature.
- c. Place on the magnet•High until the solution clears.
- **d.** Remove the supernatant.
- e. Add 200 µl 80% ethanol to the pellet. Wait 30 sec.
- f. Remove the ethanol.
- g. Repeat steps e and f for a total of 2 washes.
- h. Centrifuge briefly. Place on the magnet•Low.
- i. Remove any remaining ethanol. Air dry for 2 min.
- j. Remove from the magnet. Add $30.5~\mu l$ Buffer EB. Pipette mix 15x. If beads still appear clumpy, continue pipette mixing until fully resuspended.
- k. Incubate 2 min at room temperature.
- I. Place on the magnet•Low until the solution clears.
- m. Transfer 30 μl sample to a new tube strip.

5.4 Sample Index PCR



- a. Choose the appropriate sample index sets to ensure that no sample indices overlap in a multiplexed sequencing run.
 Record the 10x Sample Index name (PN-220103 Chromium i7 Sample Index Plate well ID) used.
- b. Prepare Sample Index PCR Mix.

Sample Index PCR Mix Add reagents in the order listed	PN	1Χ (μl)	4X + 10% (μl)	8X + 10% (μl)
Nuclease-free Water	-	8	35	70
Amplification Master Mix	220125	50	220	440
SI-PCR Primer	220111	2	9	18
Total	-	60	264	528

- c. Add $60 \mu l$ Sample Index PCR Mix to $30 \mu l$ sample.
- d. Add 10 μ l of an individual Chromium i7 Sample Index to each well and record the well ID. Pipette mix 5x (pipette set to 90 μ l). Centrifuge briefly.
- e. Incubate in a thermal cycler with the following protocol.

Lid Temperature	Reaction Volume	Run Time
105°C	100 μl	~30 min
Step	Temperature	Time
1	98°C	00:00:45
2	98°C	00:00:20
3	54°C	00:00:30
4	72°C	00:00:20
5	Go to step 2, 8x (total 9 cycles)	
6	72°C	00:01:00
7	4°C	Hold



f. Store at 4° C for up to 72 h or proceed to the next step.

5.5 Post Sample Index PCR Cleanup – SPRIselect


- a. Vortex to resuspend the SPRIselect reagent. Add **80 µl** SPRIselect Reagent **(0.8X)** to each sample. Pipette mix 15x (pipette set to 150 µl).
- b. Incubate 5 min at room temperature.
- c. Place the magnet•High until the solution clears.
- d. Remove the supernatant.
- e. Add 200 µl 80% ethanol to the pellet. Wait 30 sec.
- f. Remove the ethanol.
- **g.** Repeat steps e and f for a total of 2 washes.
- h. Centrifuge briefly. Place on the magnet•Low.
- i. Remove remaining ethanol. Air dry for 2 min.
- j. Remove from the magnet. Add 35.5 µl Buffer EB. Pipette mix 15x.
- k. Incubate 2 min at room temperature.
- I. Place on the magnet•Low until the solution clears.
- m. Transfer $35 \mu l$ to a new tube strip.




n. Store at 4°C for up to 72 h or at -20°C for long-term storage.

5.6 Post Library Construction QC

a. Run 1 µl sample at 1:10 dilution on an Agilent Bioanalyzer High Sensitivity chip.





b. Determine the average fragment size from the trace. This will be used as the insert size for library quantification.

Alternate QC Method:

Agilent TapeStation. See Appendix for representative traces

See Appendix for Post Library Construction Quantification

Step 6

5' Gene Expression (GEX) Library Construction

- 6.1 GEX Fragmentation, End Repair & A-tailing
- **6.2** GEX Post Fragmentation, End Repair & A-tailing Double Sided Size Selection SPRIselect
- **6.3** GEX Adaptor Ligation
- **6.4** GEX Post Ligation Cleanup SPRIselect
- 6.5 GEX Sample Index PCR
- **6.6** GEX Post Sample Index Double Sided Size Selection SPRIselect
- **6.7** GEX Post Library Construction QC

6.0 5' Gene Expression (GEX) Library Construction

GET START Action	ED!	Item	10x PN	Preparation & Handling	Storage
Equilibrate to Room Temperature		Fragmentation Buffer	220108	Thaw, vortex, verify no precipitate, centrifuge briefly.	-20°C
		Adaptor Mix	220026	Vortex, centrifuge briefly.	-20°C
		Ligation Buffer	220109	Thaw, vortex, verify no precipitate, centrifuge briefly.	-20°C
		SI-PCR Primer	220111	Vortex, centrifuge briefly.	-20°C
		Chromium i7 Sample Index Plate	220103	-	-20°C
		Beckman Coulter SPRIselect Reagent	-	Manufacturer's recommendations.	-
		Agilent Bioanalyzer DNA 1000 kit If used for QC	-	Manufacturer's recommendations.	-
		Agilent TapeStation ScreenTape and Reagents If used for QC	-	Manufacturer's recommendations.	-
Place on Ice	•	Fragmentation Enzyme Blend	220107/ 220130	Centrifuge briefly.	-20°C
		DNA Ligase	220110/ 220131	Centrifuge briefly.	-20°C
		Amplification Master Mix	220125	Vortex, centrifuge briefly.	-20°C
Obtain		Qiagen Buffer EB	-	-	Ambient
		10x Magnetic Separator	230003	See Tips & Best Practices.	Ambient
		Prepare 80% Ethanol Prepare 15 ml for 8 reactions	-	Prepare fresh.	Ambient

6.1 GEX Fragmentation, End Repair & A-tailing

- a. Determine the volume for **50 ng** mass of sample (see example calculation at step 3.3). Dispense the sample volume in a tube strip **on ice**. If the volume required for **50 ng** is less than **20 \mul**, adjust the total volume of each sample to **20 \mul** with nuclease-free water. If the volume for **50 ng** exceeds **20 \mul**, carry only **20 \mul** sample into library construction.
- b. Prepare a thermal cycler with the following incubation protocol.

Lid Temperature	Reaction Volume	Run Time
65°C	50 μl	~35 min
Step	Temperature	Time
Pre-cool block Pre-cool block prior to preparing the Fragmentation Mix	4°C	Hold
Fragmentation	32°C	00:05:00
End Repair & A-tailing	65°C	00:30:00
Hold	4°C	Hold

- c. Vortex Fragmentation Buffer. Verify there is no precipitate.
- d. Prepare Fragmentation Mix on ice. Pipette mix and centrifuge briefly.

Fragmentation Mix Add reagents in the order listed	PN	1Χ (μl)	4X + 10% (μl)	8X + 10% (μl)
Nuclease-free Water	-	15	66	132
Fragmentation Buffer	220108	5	22	44
Fragmentation Enzyme Blend	220107/ 220130	10	44	88
Total	-	30	132	264

- e. Add 30 µl Fragmentation Mix into each tube containing 20 µl sample.
- f. Pipette mix 15x (pipette set to 30 µl) on ice. Centrifuge briefly.
- **g.** Transfer into the pre-cooled thermal cycler (4°C) and press "SKIP" to initiate the protocol.

6.2 GEX Post Fragmentation, End Repair & A-tailing Double Sided Size Selection – SPRIselect

- a. Vortex to resuspend SPRIselect Reagent. Add 30 μ l SPRIselect Reagent (0.6X) to each sample. Pipette mix 15x (pipette set to 75 μ l).
- b. Incubate 5 min at room temperature.
- c. Place on the magnet•High until the solution clears. DO NOT discard supernatent.
- **d.** Transfer **75** μ**l** supernatant to a new tube strip.
- e. Add 10 μ l SPRIselect reagent (0.8X) to each sample. Pipette mix 15x (pipette set to 75 μ l).
- f. Incubate 5 min at room temperature.
- g. Place on the magnet•High until the solution clears.
- h. Remove 80 µl supernatant. DO NOT discard any beads.
- i. With the tube strip still on the magnet, add 125 μ l 80% ethanol to the pellet. Wait 30 sec.
- j. Remove the ethanol.
- **k.** Repeat steps i and j for a total of 2 washes.
- I. Centrifuge briefly. Place on the magnet •Low.
- m. Remove the ethanol. DO NOT over-dry beads to ensure maximum elution efficiency.
- n. Remove from the magnet. Add 50.5 µl Buffer EB. Pipette mix 15x.
- o. Incubate 2 min at room temperature.
- p. Place on the magnet•High until the solution clears.
- **q.** Transfer $50 \mu l$ sample to a new tube strip.

6.3 GEX Adaptor Ligation

a. Prepare Adaptor Ligation Mix. Pipette mix and centrifuge briefly.

Adaptor Ligation Mix Add reagents in the order listed	PN	1X (μl)	4Χ + 10% (μl)	8X + 10% (µl)
Nuclease-free Water	-	17.5	77	154
Ligation Buffer	220109	20	88	176
ONA Ligase	220110/ 220131	10	44	88
Adaptor Mix	220026	2.5	11	22
Total	-	50	220	440

- **b.** Add **50** μ l Adaptor Ligation Mix to **50** μ l sample. Pipette mix 15x (pipette set to 90 μ l). Centrifuge briefly.
- c. Incubate in a thermal cycler with the following protocol.

Lid Temperature	Reaction Volume	Run Time
30°C	100 μl	15 min
Step	Temperature	Time
1	20°C	00:15:00
2	4°C	Hold

6.4 GEX Post Ligation Cleanup – SPRIselect

- a. Vortex to resuspend SPRIselect Reagent. Add 80 μ l SPRIselect Reagent (0.8X) to each sample. Pipette mix 15x (pipette set to 150 μ l).
- b. Incubate 5 min at room temperature.
- c. Place on the magnet•High until the solution clears.
- d. Remove the supernatant.
- e. Add 200 µl 80% ethanol to the pellet. Wait 30 sec.
- f. Remove the ethanol.
- g. Repeat steps e and f for a total of 2 washes.
- h. Centrifuge briefly. Place on the magnet•Low.
- i. Remove any remaining ethanol. Air dry for 2 min.
- j. Remove from the magnet. Add 30.5 µl Buffer EB. Pipette mix 15x.
- k. Incubate 2 min at room temperature.
- I. Place on the magnet•Low until the solution clears.
- m. Transfer 30 µl sample to a new tube strip.

6.5 GEX Sample Index PCR

- **a.** Choose the appropriate sample index sets to ensure that no sample indices overlap in a multiplexed sequencing run.
- **b.** Record the 10x Sample Index name (PN-220103 Chromium i7 Sample Index Plate well ID) used, especially if running more than one sample.
- c. Prepare Sample Index PCR Mix. Pipette mix and centrifuge briefly.

Sample Index PCR Mix Add reagents in the order listed	PN	1Χ (μl)	4X + 10% (μl)	8X + 10% (µl)
Nuclease-free Water	-	8	35	70
Amplification Master Mix	220125	50	220	440
SI-PCR Primer	220111	2	9	18
Total	-	60	264	528

- d. Add 60 µl Sample Index PCR Mix to 30 µl sample.
- e. Add 10 μ l of an individual Chromium i7 Sample Index to each well and record their assignment. Pipette mix 5x (pipette set to 90 μ l). Centrifuge briefly.
- f. Incubate in a thermal cycler with the following protocol.

Reaction Volume	Run Time
100 μl	~40 min
Temperature	Time
98°C	00:00:45
98°C	00:00:20
54°C	00:00:30
72°C	00:00:20
Go to step 2, see table	e below for # cycles
72°C	00:01:00
4°C	Hold
	100 µl Temperature 98°C 98°C 54°C 72°C Go to step 2, see table 72°C

The table recommends starting point for optimization. If less than 50 ng was carried into 5' Gene Expression Library Construction, refer to the product yield calculation example in step 3.3 to determine the mass input into Library Construction.

Input into Library Construction	Total Sample Index Cycles
1 - 25 ng	16
26 - 50 ng	14



g. Store at $4^{\circ}C$ for up to $72\ h$ or proceed to the next step.

6.6 GEX Post Sample Index PCR Double Sided Size Selection – SPRIselect


- a. Vortex to resuspend SPRIselect reagent. Add 60 μ l SPRIselect reagent (0.6X) to each sample. Pipette mix 15x (pipette set to 150 μ l).
- b. Incubate 5 min at room temperature.
- c. Place on the magnet•High until the solution clears. DO NOT discard supernatant.
- **d.** Transfer **150 μl** supernatant to a new tube strip.
- e. Vortex to resuspend SPRIselect reagent. Add 20 μ l SPRIselect reagent (0.8X) to each sample. Pipette mix 15x (pipette set to 150 μ l).
- f. Incubate 5 min at room temperature.
- g. Place on the magnet•High until the solution clears.
- h. Remove 165 μl supernatant. DO NOT discard any beads.
- i. With the tube strip still on the magnet, add 200 μ l 80% ethanol to the pellet. Wait 30 sec.
- j. Remove the ethanol.
- **k.** Repeat steps i and j for a total of 2 washes.
- I. Centrifuge briefly. Place on the magnet Low.
- **m.** Remove the remaining ethanol. DO NOT over-dry beads to ensure maximum elution efficiency.
- n. Remove the tube strip from the magnet. Add 35.5 µl Buffer EB. Pipette mix 15x.
- o. Incubate 2 min at room temperature.
- p. Place on the magnet Low until the solution clears.
- **q.** Transfer $35 \mu l$ sample to a new tube strip.



r. Store at 4°C for up to 72 h or at -20°C for long-term storage.

6.7 GEX Post Library Construction QC

a. Run 1 µl sample at 1:10 dilution on an Agilent Bioanalyzer High Sensitivity chip.



b. Determine the average fragment size from the trace. This will be used as the insert size for library quantification.

Alternate QC Method:

Agilent TapeStation. See Appendix for representative traces

See Appendix for GEX Post Library Construction Quantification

Sequencing

Step 7 Sequencing

Sequencing Libraries

Chromium Single Cell V(D)J enriched libraries and 5' Gene Expression libraries comprise standard Illumina paired-end constructs which begin with P5 and end with P7. 16 bp 10x Barcodes are encoded at the start of Read 1, while sample index sequences are incorporated as the i7 index read. Read 1 and Read 2 are standard Illumina sequencing primer sites used in paired-end sequencing. Read 1 is used to sequence 16 bp 10x Barcodes and 10 bp UMI. Sequencing these libraries produce a standard Illumina BCL data output folder.

Chromium Single Cell V(D)J Enriched Library



Chromium Single Cell 5' Gene Expression Library



Illumina Sequencer Compatibility

The compatibility of the listed sequencers has been verified by 10x Genomics. Some variation in assay performance is expected based on sequencer choice. For more information about performance variation, visit the 10x Genomics Support website.

- MiSeq
- NexSeq 500/550*
- HiSeq 2500 (Rapid Run)
- HiSeq 3000/4000
- NovaSeq

*Sequencing Chromium Single Cell libraries on the NextSeq 500/550 platform may yield reduced sequence quality and sensitivity relative to the MiSeq, HiSeq, and NovaSeq platforms. Refer to the 10x Genomics Support website for more information.

Sample Indices

Each sample index in the Chromium i7 Sample Index Kit (PN-120262) is a mix of 4 different sequences to balance across all 4 nucleotides. If multiple samples are pooled in a sequence lane, the sample index name (i.e. the Chromium i7 Sample Index plate well ID) is needed in the sample sheet used for generating FASTQs with "cellranger mkfastq".

Step 7 Sequencing

Library Sequencing Depth & Run Parameters

Sequencing Depth	Minimum 5,000 read pairs per cell for V(D)J Enriched library Minimum 20,000 read pairs per cell for 5' Gene Expression library
Sequencing Type	Paired-end, single indexing
Sequencing Read	Recommended cycles for all library types – 26×91 bp Recommended cycles for all library type combinations – 26×91 bp

V(D)J Enriched libraries (alone or in combination with 5' Gene Expression libraries) may be sequenced at 150×150 bp.

Library Loading

Once quantified and normalized, V(D)J Enriched libraries and 5' Gene Expression libraries should be denatured and diluted as recommended for Illumina sequencing platforms. Refer to Illumina documentation for denaturing and diluting libraries. Refer to the 10x Genomics Support website, for more information.

Instrument	Loading Concentration (pM)	PhiX (%)
MiSeq	10	1
NextSeq 500	1.5	1
HiSeq 2500 (RR)	10	1
HiSeq 4000	180	1
NovaSeq	200	1

Library Pooling

V(D)J Enriched libraries and the 5' Gene Expression libraries maybe pooled for sequencing, taking into account the differences in depth requirements between the pooled libraries. 5' Gene Expression libraries may be sequenced using enriched library parameters, however the cost of sequencing using enriched library parameters is higher.

Library Pooling Examples:

Libraries	Sequencing Depth (read pairs per cell)	Library Pooling Ratio
Example 1		
V(D)J Enriched library 5' Gene Expression library	5,000 20,000	1 4
Example 2		
V(D)J Enriched library 5' Gene Expression library	5,000 50,000	1 10

Troubleshooting



GEMs

STEP

NORMAL

REAGENT CLOGS & WETTING FAILURES

1.4 d After Chip A is removed from the Controller and the wells are exposed



All 8 Recovery Wells are similar in volume and opacity.



Recovery Well G indicates a reagent clog. Recovery Well C and E indicate a wetting failure. Recovery Wells B, D, and F are normal. Wells A and H contain 50% Glycerol Solution.

The image indicates clogs in the Gel Bead line (orange arrow) and the sample line (yellow arrow) as evidenced by higher than usual volumes in the input wells.



1.4 e Transfer GEMs from Chip A Recovery Wells



All liquid levels are similar in volume and opacity without air trapped in the pipette tips.



Pipette tips C and E indicate a wetting failure. Pipette tip C contains partially emulsified GEMs. Emulsion is absent in pipette tip E. Pipette tip G indicates a reagent clog.

STEP


NORMAL

REAGENT CLOGS & WETTING FAILURES

2.1 a After transfer of the GEMs + Recovery Agent



All liquid levels are similar in the aqueous sample volume (clear) and Recovery Agent/Partitioning Oil (pink).




Tube G indicates a reagent clog has occurred. There is a decreased volume of aqueous layer (clear).

Tube C and E indicate a wetting failure has occurred. There is an abnormal residual volume of Recovery Agent/Partitioning Oil (pink).

2.1 b
After aspiration of
Recovery Agent/
Partitioning Oil




All liquid volumes are similar in the aqueous sample volume (clear) and residual Recovery Agent/Partitioning Oil (pink).




Tube G indicates a reagent clog has occurred. There is a decreased volume of aqueous layer (clear). There is also a greater residual volume of Recovery Agent/Partitioning Oil (pink).

Tube C and E indicate a wetting failure has occurred. There is an abnormal residual volume of Recovery Agent/Partitioning Oil (pink).

2.1 c After addition of Dynabeads Cleanup Mix



All liquid volumes are similar after addition of the Dynabeads Cleanup Mix.



Tube 6 indicates a reagent clog has occurred. There is an abnormal ratio of Dynabeads Cleanup Mix (brown) to Recovery Agent/Partitioning Oil (appears white).

Tube C and E indicate a wetting failure has occurred. There is an abnormal ratio of Dynabeads Cleanup Mix (brown) to Recovery Agent/Partitioning Oil (appears white).

If a channel clogs or wetting failure occurs during GEM generation, it is recommended that the sample be remade. If any of the listed issues occur, take a picture and send it to support@10xgenomics.com for further assistance.

Chromium Controller Errors

- If the Chromium Controller or the Chromium Single Cell Controller fails to start, an error tone will sound and one of the following error messages will be displayed:
- a. Chip not read Try again: Eject the tray, remove and/or reposition the 10x Chip Holder assembly and try again. If the error message is still received after trying this more than twice, contact support@10xgenomics.com for further assistance.
- b. Check gasket: Eject the tray by pressing the eject button to check there is a 10x Gasket on the Chromium Chip. In the case when the 10x Gasket installation was forgotten, install and try again. In the case when a 10x Gasket was already installed, remove, reapply, and try again. If the error message is still received after trying either of these more than twice, contact support@10xgenomics.com for further assistance.

c. Error Detected: Row_Pressure:

- i. If this message is received within a few seconds of starting a run, eject the tray by pressing the eject button and check for dirt or deposits on the 10x Gasket. If dirt is observed, replace with a new 10x Gasket and try again. If the error message is still received after trying this more than twice, contact support@10xgenomics.com for further assistance.
- ii. If this message is received after a few minutes into the run, the Chromium Chip must be discarded. **Do not try running this Chromium Chip again as this may damage the Chromium Controller.**
- d. CAUTION: Chip Holder not Present: Eject the tray by pressing the eject button to check there is a 10x Chip Holder encasing the Chromium Chip. In the case when the 10x Chip Holder was forgotten, install with a 10x Gasket in place, and try again. If the error message is still received after a 10x Chip Holder is confirmed as in place, contact support@10xgenomics.com for further assistance.
- e. Invalid Chip CRC Value: This indicates the Chromium Chip has encountered an error, should not be run, and must be discarded. Contact support@10xgenomics.com for further assistance.

Appendix

Post Library Construction Quantification Agilent TapeStation Traces Oligonucleotide Sequences

Post Library Construction Quantification

- a. Thaw KAPA Library Quantification Kit for Illumina Platforms.
- b. Dilute 1 µl sample with deionized water to appropriate dilutions that fall within the linear detection range of the KAPA Library Quantification Kit for Illumina Platforms. (For more accurate quantification, make the dilution(s) in duplicate).
- c. Make enough Quantification Master Mix for the DNA dilutions per sample and the DNA Standards (plus 10% excess) using the guidance for 1 reaction volume below.

Quantification Master Mix	1X (μl)
SYBR Fast Master Mix + Primer	12
Water	4
Total	16

- d. Dispense 16 μ l Quantification Master Mix for sample dilutions and DNA Standards into a 96 well PCR plate.
- e. Add $4 \mu l$ sample dilutions and $4 \mu l$ DNA Standards to appropriate wells. Centrifuge briefly.
- f. Incubate in a thermal cycler with the following protocol.

Step	Temperature	Run Time
1	95°C	00:03:00
2	95°C	00:00:05
3	67°C	00:00:30
4	Go to Step 2, 29X (Total 30 cycles)	


g. Follow the manufacturer's recommendations for qPCR-based quantification. For library quantification for sequencer clustering, determine the concentration based on insert size derived from the Bioanalyzer/TapeStation trace.

Agilent TapeStation Traces


Agilent TapeStation Traces


Agilent TapeStation High Sensitivity D5000 ScreenTape was used. Protocol steps correspond to the Chromium Single Cell V(D)J Reagent Kits User Guide (CG000086).

Protocol Step 3.3 - cDNA QC & Quantification




Protocol Step 5.6 – Post Library Construction QC







Protocol Step 6.7 – GEX Post Library Construction QC




Oligonucleotide Sequences





Protocol Step 4.1 - Target Enrichment 1 Reverse Outer Primers: (final conc. 1 µM each) Forward Primer: (final conc. 2 µM) Human T Cell Mix 1 PN-2000008 5'-TGAAGGCGTTTGCACATGCA-3' 5'-AATGATACGGCGACCACCGA-GATCTACACTCTTTCCCTACACGACGCTC-3' 5'-TCAGGCAGTATCTGGAGTCATTGAG-3' Human B Cell Mix 1 Forward Primer: (final conc. 1 µM) Reverse Outer Primers: (final conc. 0.5 µM each) Enrichment Outer Primer PN-2000035 5'-CAGGGCACAGTCACATCCT-3' 5'-AATGATACGGCGACCACCGA-GATCTACACTCTTTCCCTACACGACGCTC-3' 5'-TGCTGGACCACGCATTTGTA-3' 5'-GGTTTTGTTGTCGACCCAGTCT-3' 5'-TTGTCCACCTTGGTGTTGCT-3' 5'-CATGACGTCCTTGGAAGGCA-3' 5'-TGTGGGACTTCCACTG-3' 5'-TTCTCGTAGTCTGCTTTGCTCAG-3' Reverse Outer Primers: (final conc. 0.5 µM each) Forward Primer: (final conc. 2 µM) Mouse T Cell Mix 1 PN-2000075 5'-CTGGTTGCTCCAGGCAATGG-3' 5'-TGTAGGCCTGAGGGTCCGT-3' 5'-AATGATACGGCGACCACCGA-GATCTACACTCTTTCCCTACACGACGCTC-3' Forward Primer: (final conc. 1 µM) PCR Prime Reverse Outer Primers: Enrichment Outer Primer Mouse B Cell Mix 1 PN-2000080 5'-TCAGCACGGGACAAACTCTTCT-3' (final conc. 0.375 μM) 5'-AATGATACGGCGACCACCGA-GATCTACACTCTTTCCCTACACGACGCTC-3' 5'-GCAGGAGACAGACTCTTCTCCA-3' (final conc. $0.175~\mu M$) 5'-AACTGGCTGCTCATGGTGT-3' (final conc. 0.1 μ M) 5'-TGGTGCAAGTGTGGTTGAGGT-3' (final conc. 0.3 µM) 5'-TGGTCACTTGGCTGGTGGTG-3' (final conc. $0.25~\mu M$) 5'-CACTTGGCAGGTGAACTGTTTTCT-3' (final conc. $0.25~\mu M$) 5'-AACCTTCAAGGATGCTCTTGGGA-3' (final conc. 0.3 µM) 5'-GGACAGGGATCCAGAGTTCCA-3' (final conc. 0.5 µM) 5'-AGGTGACGGTCTGACTTGGC-3' (final conc. $0.125 \mu M$) 5'-GCTGGACAGGGCTCCATAGTT-3' (final conc. $0.125~\mu M$) 5'-GGCACCTTGTCCAATCATGTTCC-3' (final conc. $0.250~\mu\text{M}$)

5'-ATGTCGTTCATACTCGTCCTTGGT-3' (final conc. $0.1 \mu M$)



Protocol Step 5.2 – Adaptor Ligation

Adaptor (Read 2) PN-220026

Read 2
5'-GATCGGAAGAGCACACGTCTGAACTCCAGTCAC-3'

Ligation Product



