CG000185 Rev D

USER GUIDE

Chromium Single Cell 3' Reagent Kits v3

with Feature Barcode technology for Cell Surface Protein



FOR USE WITH

Chromium Single Cell 3' GEM, Library & Gel Bead Kit v3, 16 rxns PN-1000075 Chromium Single Cell 3' GEM, Library & Gel Bead Kit v3, 4 rxns PN-1000092 Chromium Single Cell 3' Feature Barcode Library Kit, 16 rxns PN-1000079 Chromium Single Cell B Chip Kit, 48 rxns PN-1000153 (America & Asia Pacific), PN-1000073 (Europe, Middle East & Africa) Chromium Single Cell B Chip Kit, 16 rxns PN-1000154 (America & Asia Pacific), PN-1000074 (Europe, Middle East & Africa) Chromium i7 Multiplex Kit, 96 rxns PN-120262



Notices

Document Number

CG000185 • Rev D

Legal Notices

© 2020 10X Genomics, Inc (10x Genomics). All rights reserved. Duplication and/or reproduction of all or any portion of this document without the express written consent of 10x Genomics, is strictly forbidden. Nothing contained herein shall constitute any warranty, express or implied, as to the performance of any products described herein. Any and all warranties applicable to any products are set forth in the applicable terms and conditions of sale accompanying the purchase of such product. 10x Genomics provides no warranty and hereby disclaims any and all warranties as to the use of any third-party products or protocols described herein. The use of products described herein is subject to certain restrictions as set forth in the applicable terms and conditions of sale accompanying the purchase of such product. A non-exhaustive list of 10x Genomics' marks, many of which are registered in the United States and other countries can be viewed at: www.10xgenomics.com/trademarks. 10x Genomics may refer to the products or services offered by other companies by their brand name or company name solely for clarity, and does not claim any rights in those third party marks or names. 10x Genomics products may be covered by one or more of the patents as indicated at: www.10xgenomics.com/patents. The use of products described herein is subject to 10x Genomics Terms and Conditions of Sale, available at www.10xgenomics.com/legal-notices, or such other terms that have been agreed to in writing between 10x Genomics and user. All products and services described herein are intended FOR RESEARCH USE ONLY and NOT FOR USE IN DIAGNOSTIC PROCEDURES.

Instrument & Licensed Software Updates Warranties

Updates to existing Instruments and Licensed Software may be required to enable customers to use new or existing products. In the event of an Instrument failure resulting from an update, such failed Instrument will be replaced or repaired in accordance with the 10x Limited Warranty, Assurance Plan or service agreement, only if such Instrument is covered by any of the foregoing at the time of such failure. Instruments not covered under a current 10x Limited Warranty, Assurance Plan or service agreement will not be replaced or repaired.

Support

Email: support@10xgenomics.com 10x Genomics 6230 Stoneridge Mall Road Pleasanton, CA 94588 USA

Document Revision Summary

Document Number	CG000185
Title	Chromium Single Cell 3' Reagent Kits v3 User Guide with Feature Barcode technology for Cell Surface Protein
Revision	Revision C to D
Revision Date	February 2020

Specific Changes:

Step	Page (in Rev D)	Changes
-	-	Updated to include additional Chromium Single Cell Chip B Kit part numbers
1.2	30	Updated Chip Loading instructions
2.1a	35	Updated incomplete biphasic separation instructions
2.1c	35	Updated Dynabeads handling instructions
2.2e	37	Added stop time Store at 4°C for up to 72 h or or -20 °C for ≤ 1 week, or proceed to the next step.
3.1d	43	Added page describing correlation between cDNA input and library complexity
3.5e	48	Updated recommended cycle numbers
-	65	Added representative post library construction QC trace

General Changes:

• Updates for general minor consistency of language and terms throughout.

Table of Contents

Introduction	6
Chromium Single Cell 3' Reagent Kits v3	7
Chromium Accessories	11
Recommended Thermal Cyclers	11
Additional Kits, Reagents & Equipment	12
Protocol Steps & Timing	14
Stepwise Objectives	15
Cell Surface Protein Labeling Guidelines	19
Tips & Best Practices	20
Step 1	26
GEM Generation & Barcoding	27
1.1 Prepare Master Mix	28
1.2 Load Chromium Chip B	30
1.3 Run the Chromium Controller	31
1.4 Transfer GEMs	31
1.5 GEM-RT Incubation	32
Step 2	33
Post GEM-RT Cleanup & cDNA Amplification	34
2.1 Post GEM-RT Cleanup – Dynabeads	35
2.2 cDNA Amplification	37
2.3 cDNA Cleanup – SPRIselect	39
2.3A Pellet Cleanup	39
2.3B Transferred Supernatant Cleanup	39
2.4 cDNA QC & Quantification	40
Step 3	41
3' Gene Expression Library Construction	42
3.1 Fragmentation, End Repair & A-tailing	44
3.2 Post Fragmentation, End Repair & A-tailing Double Sided Size Selection – SPRIselect	45
3.3 Adaptor Ligation	46
3.4 Post Ligation Cleanup – SPRIselect	47
3.5 Sample Index PCR	48
3.6 Post Sample Index PCR Double Sided Size Selection – SPRIselect	49
3.7 Post Library Construction QC	50

Step 4 Cell Surface Protein Library Construction	51 52
4.1 Sample Index PCR	53
4.2 Post Sample Index PCR Size Selection – SPRIselect	54
4.3 Post Library Construction QC	55
Sequencing	56
Troubleshooting	59
6.1 GEMs	60
6.2 Chromium Controller Errors	62
Appendix	63
Post Library Construction Quantification	64
Agilent TapeStation Traces	65
Oligonucleotide Sequences	66

ТОС

Introduction

Chromium Single Cell 3' Reagent Kits v3 Chromium Accessories Recommended Thermal Cyclers Additional Kits, Reagents & Equipment Protocol Steps & Timing Stepwise Objectives Cell Surface Protein Labeling Guidelines

Chromium Single Cell 3' Reagent Kits v3


Chromium Single Cell 3' GEM, Library & Gel Bead Kit v3, 16 rxns PN-1000075

Single Cell 3' GEM Module			Chromium Single Cell 3' Library Module		
	#	PN		#	PN
RT Reagent	1	2000086	Fragmentation Enzyme	1	2000090
🔵 RT Enzyme C	1	2000085	Fragmentation Buffer	1	2000091
Template Switch Oligo	1	3000228	Ligation Buffer	1	2000092
O Reducing Agent B	1	2000087	😑 DNA Ligase	1	220110
Cleanup Buffer	2	2000088	🥚 Adaptor Oligos	1	2000094
cDNA Primers	1	2000089	😑 SI Primer	1	2000095
🔿 Amp Mix	1	2000047	○ Amp Mix	1	2000047

Chromium Single Cell 3' Gel Bead Kit v3, 16 rxns PN-1000076 (store at -80°C)

Chromium Single Cell 3' v3 Gel Beads	
	# PN
Single Cell 3' v3 Gel Beads	2 2000059
10xGenomics.com	

Dynabeads[™] MyOne[™] SILANE PN-2000048 (store at 4°C)




Chromium Single Cell 3' GEM, Library & Gel Bead Kit v3, 4 rxns PN-1000092

Chromium Single Cell 3 4 rxns PN-1000094 (sto			Chromium Single Cell 3' L 4 rxns PN-1000095 (sto		•
Chromium Single Cell 3' GEM Module			Chromium Single Cell 3' Library Module		
	#	PN		#	PN
RT Reagent	1	2000086	Fragmentation Enzyme	1	2000104
RT Enzyme C	1	2000102	Fragmentation Buffer	1	2000091
Template Switch Oligo	1	3000228	Ligation Buffer	1	2000092
O Reducing Agent B	1	2000087	🛑 DNA Ligase	1	220131
Cleanup Buffer	1	2000088	😑 Adaptor Oligos	1	2000094
cDNA Primers	1	2000089	😑 SI Primer	1	2000095
⊖ Amp Mix	1	2000103			
10xGenomics.com			10xGenomics.com		


Chromium Single Cell 3' Gel Bead Kit v3, 4 rxns PN-1000093 (store at –80°C)

Chromium Single Cell 3' v3 Gel Beads	
	# PN
Single Cell 3' v3 Gel Beads (4 rxns)	1 2000059
10xGenomics.com	10X GENOMICS

Dynabeads[™] MyOne[™] SILANE PN-2000048 (store at 4°C)



Chromium Single Cell 3' Feature Barcode Library Kit, 16 rxns PN-1000079 (store at -20°C)



Chromium Chip B Single Cell Kit, 48 rxns PN-1000153 (America & Asia Pacific) (store at ambient temperature) PN-1000073 (Europe, Middle East & Africa)



Chromium Chip B Single Cell Kit PN is region specific and should be used based on customer's geographical location.

Chromium Chip B Single Cell Kit, 16 rxnsPN-1000154 (America & Asia Pacific)(store at ambient temperature)PN-1000074 (Europe, Middle East & Africa)

Chromium Partitioning Oil # P	N	Chromium Recovery Agent # PN
Partitioning Oil 2 220	088	Recovery Agent 2 220016
Chromium Chip B & Gaskets		
	#	PN
Chip B Single Cell	2 2	2000168 (America & Asia Pacific) 2000060 (Europe, Middle East & Africa)
Gasket, 2-pack	1	3000072
10xGenomics.com		10x genomics

Chromium i7 Multiplex Kit, 96 rxns PN-120262 (store at -20°C)

Chromium i7 Multiplex Kit		
	# PN	
Chromium i7 Sample Index Plate	1 220103	

Chromium Accessories

Product	Part Number (Kit)	Part Number (Item)
10x Vortex Adapter	120251	330002
10x Vortex Clip	120253	230002
10x Chip Holder	120252	330019
10x Magnetic Separator	120250	230003

Recommended Thermal Cyclers

Thermal cyclers used must support uniform heating of 100 μl emulsion volumes.

Supplier	Description	Part Number
BioRad	C1000 Touch Thermal Cycler with 96-Deep Well Reaction Module	1851197
Eppendorf	MasterCycler Pro	North America 950030010 International 6321 000.019
Thermo Fisher Scientific	Veriti 96-Well Thermal Cycler	4375786

Additional Kits, Reagents & Equipment

The items in the table below have been validated by 10x Genomics and are highly recommended for the Chromium Single Cell 3' v3 protocols. Substituting materials may adversely affect system performance.

Supplier	Description	Part Number (US)				
Plastics						
Eppendorf	PCR Tubes 0.2 ml 8-tube strips DNA LoBind Tubes, 1.5 ml DNA LoBind Tubes, 2.0 ml	DNA LoBind Tubes, 1.5 ml Eppendorf.				
USA Scientific	TempAssure PCR 8-tube strip	Thermo Fisher Scientific PCR	1402-4700			
Thermo Fisher Scientific	MicroAmp 8-Tube Strip, 0.2 ml MicroAmp 8 -Cap Strip, clear	8-tube strips.	N8010580 N8010535			
Rainin	Tips LTS 200UL Filter RT-L200FLR Tips LTS 1ML Filter RT-L1000FLR Tips LTS 20UL Filter RT-L10FLR		30389240 30389213 30389226			
Kits & Reagents						
Thermo Fisher Scientific	Nuclease-free Water		AM9937			
	Low TE Buffer (10 mM Tris-HCl pH 8.0, 0.1 m	nM EDTA)	12090-015			
Millipore Sigma	Ethanol, Pure (200 Proof, anhydrous)	Ethanol, Pure (200 Proof, anhydrous)				
Beckman Coulter	SPRIselect Reagent Kit		B23318			
Bio-Rad	10% Tween 20	10% Tween 20				
Ricca Chemical Company	Glycerin (glycerol), 50% (v/v) Aqueous Solut	Glycerin (glycerol), 50% (v/v) Aqueous Solution				
Qiagen	Qiagen Buffer EB		19086			
Equipment						
VWR	Vortex Mixer Divided Polystyrene Reservoirs		10153-838 41428-958			
Eppendorf		Eppendorf ThermoMixer C Eppendorf SmartBlock 1.5 ml, Thermoblock for 24 reaction vessel (alternatively, use a temperature-controlled Heat Block)				
Rainin	Pipet-Lite Multi Pipette L8-50XLS+ Pipet-Lite Multi Pipette L8-200XLS+ Pipet-Lite Multi Pipette L8-10XLS+ Pipet-Lite Multi Pipette L8-20XLS+ Pipet-Lite LTS Pipette L-2XLS+ Pipet-Lite LTS Pipette L-10XLS+ Pipet-Lite LTS Pipette L-20XLS+ Pipet-Lite LTS Pipette L-200XLS+ Pipet-Lite LTS Pipette L-200XLS+		17013804 17013805 17013802 17013803 17014393 17014388 17014392 17014384 17014391 17014382			

Additional Kits, Reagents & Equipment

The items in the table below have been validated by 10x Genomics and are highly recommended for the Chromium Single Cell 3' v3 protocols. Substituting materials may adversely affect system performance.

Supplier	Description	Part Number (US)	
Quantification & Quality Control	L		
Agilent Thermo Fisher Scientific	2100 Bioanalyzer Laptop Bundle High Sensitivity DNA Kit 4200 TapeStation High Sensitivity D1000 ScreenTape/Reagents High Sensitivity D5000 ScreenTape/Reagents Qubit 4.0 Flourometer	Choose Bioanalyzer, TapeStation, or Qubit based on availability & preference.	G2943CA 5067-4626 G2991AA 5067-5592/ 5067-5593 5067-5584/ 5067-5585 Q33226
	Qubit dsDNA HS Assay Kit	Q32854	
Advanced Analytical	Fragment Analyzer Automated CE System - 12 ca Fragment Analyzer Automated CE System - 48/9 High Sensitivity NGS Fragment Analysis Kit	FSv2-CE2F FSv2-CE10F DNF-474	
KAPA Biosystems	KAPA Library Quantification Kit for Illumina Platf	orms	KK4824

Protocol Steps & Timing

Day	Steps	Timing Stop & Store
	Cell Preparation & Labeling	
1 h	Dependent on Cell Type	~1-2 h
	Step 1 – GEM Generation & Barcoding	
	 Prepare Reaction Mix Load Chromium Chip B Run the Chromium Controller Transfer GEMs GEM-RT Incubation 	20 min 10 min 8.5 min 3 min 55 min 500 4°C ≤72 h or −20°C ≤1 week
4h	Step 2 – Post GEM-RT Cleanup & cDNA Amplification	
	 2.1 Post GEM RT-Cleanup – Dynabead 2.2 cDNA Amplification 2.3 cDNA Cleanup – SPRIselect 	45 min 40 min
	2.3A Pellet Cleanup 2.3B Transferred Supernatant Cleanup 2.4 cDNA QC & Quantification	15 min 4°C ≤72 h or −20°C ≤4 weeks 20 min 4°C ≤72 h or −20°C ≤4 weeks 50 min
6h	Step 3 – 3' Gene Expression Library Construction	
	 3.1 Fragmentation, End Repair & A-tailing 3.2 Post Fragmentation, End Repair & A-tailing Double Sided Size Selection – SPRIselect 	45 min 30 min
	 3.3 Adaptor Ligation 3.4 Post Ligation Cleanup- SPRIselect 3.5 Sample Index PCR 3.6 Post Sample Index PCR Double Sided Size Selection- SPRIselect 2.4 Post Library Construction OC 	25 min 20 min 40 min 30 min 50 min 5
8 h Plus	3.6 Post Library Construction QC	50 min
rtus	Step 4 – Cell Surface Protein Library Construction	
	 4.1 Sample Index PCR 4.2 Post Sample Index PCR Size Selection- SPRIselect 4.3 Post Library Construction QC 	40 min 20 min 50 min

Stepwise Objectives




The Chromium Single Cell Gene Expression Solution with Feature Barcode technology upgrades short read sequencers to deliver a scalable microfluidic platform for assessing cell surface protein expression combined with 3' digital gene expression of the same single cell by profiling 500-10,000 individual cells per sample. GemCode Technology samples a pool of ~3,500,000 10x Barcodes to separately index each cell's transcriptome and cell surface protein. It does so by partitioning thousands of cells into nanoliter-scale Gel Beads-in-emulsion (GEMs), where all generated DNA molecules share a common 10x Barcode. Libraries are generated and sequenced from the DNA molecules and 10x Barcodes are used to associate individual reads back to the individual partitions.

This document outlines the protocol for generating Single Cell 3' Gene Expression and Cell Surface Protein libraries from the same cells.

Single Cell 3' v3 Gel Beads


In addition to the poly(dT) primer that enables the production of barcoded, full-length cDNA from poly-adenylated mRNA, the Single Cell 3' v3 Gel Beads also include two additional primer sequences (Capture Sequence 1 and Capture Sequence 2), that enable capture and priming of Feature Barcode technology compatible targets or analytes of interest.

The poly(dT) primers along with one of the capture sequence primers are used in this protocol for generating Single Cell 3' Gene Expression and Cell Surface Protein libraries.



Step 1 GEM Generation & Barcoding

GEMs are generated by combining barcoded Single Cell 3'v3 Gel Beads, a Master Mix with cell surface protein labeled cells, and Partitioning Oil onto Chromium Chip B. To achieve single cell resolution, cells are delivered at a limiting dilution, such that the majority (~90-99%) of generated GEMs contain no cell, while the remainder largely contain a single cell.



Step 1 GEM Generation & Barcoding

Immediately following GEM generation, the Gel Bead is dissolved releasing the three types of primers and any copartitioned cell is lysed. The poly(dT) and one of the capture sequence primers in the gel bead are engaged simultaneously in two different reactions inside individual GEMs (primer with Capture Sequence 2 is not shown in the illustrated example).


- A. Primers containing:
- an Illumina TruSeq Read 1 (read 1 sequencing primer)
- 16 nt 10x Barcode
- 12 nt unique molecular identifier (UMI)
- 30 nt poly(dT) sequence

are mixed with the cell lysate and a Master Mix containing reverse transcription (RT) reagents. Incubation of the GEMs produces barcoded, full-length cDNA from poly-adenylated mRNA.

B. In the same partition, primers containing:

- an Illumina Nextera Read 1 (Read 1N; read 1 sequencing primer)
- 16 nt 10x Barcode
- 12 nt unique molecular identifier (UMI)
- Capture Sequence 1


are mixed with the cell lysate and the Master Mix containing the RT reagents. Incubation of the GEMs produces barcoded DNA from the cell surface protein Feature Barcode.



Step 2 Post GEM-RT Cleanup & cDNA Amplification



After incubation, GEMs are broken and pooled fractions are recovered. Silane magnetic beads are used to purify the cell barcoded products from the post GEM-RT reaction mixture, which includes leftover biochemical reagents and primers. The cell barcoded cDNA molecules are amplified via PCR to generate sufficient mass for library constructions. Size selection is used to separate the amplified cDNA molecules for 3' Gene Expression and Cell Surface Protein library construction.




Step 3 3' Gene Expression Library Construction



full-length cDNA Amplified from poly-adenylated mRNA is used to generate 3' Gene Expression libraries. Enzymatic fragmentation and size selection are used to optimize the cDNA amplicon size. TruSeq Read 1 (read 1 primer sequence) is added to the molecules during GEM incubation. P5, P7, a sample index, and TruSeg Read 2 (read 2 primer sequence) are added via End Repair, A-tailing, Adaptor Ligation, and PCR. The final libraries contain the P5 and P7 primers used in Illumina bridge amplification.






Step 4 Cell Surface Protein Library Construction




Amplified DNA from cell surface protein Feature Barcodes is used for library construction. P5, P7, a sample index, and TruSeq Read 2 (read 2 primer sequence) are added via PCR. The final libraries contain the P5 and P7 primers used in Illumina bridge amplification. Pooled amplified DNA processed in bulk




Step 5 Sequencing

The Single Cell 3' libraries comprise standard Illumina paired-end constructs which begin and end with P5 and P7. The 16 bp 10x Barcode and 12 bp UMI are encoded in Read 1, while Read 2 is used to sequence the cDNA fragment in 3' Gene Expression libraries and the Feature Barcode in the Cell Surface Protein libraries. Sample index sequences are incorporated as the i7 index read. Standard Illumina sequencing primer sites TruSeq Read 1 and TruSeq Read 2 in the 3' Gene Expression libraries and Nextera Read 1 and TruSeq Read 2 in the Cell Surface Protein libraries are used in paired-end sequencing.

Illumina sequencer compatibility, sample indices, library loading and pooling, recommended read depths and run parameters are summarized in step 5.





*Minimum required Read 2 length for Cell Surface Protein libraries is 25 bp


See Appendix for Oligonucleotide Sequences

Cell Surface Protein Labeling Guidelines

Step 1

Overview

Cell surface proteins can be labeled using a Feature Barcode oligonucleotide conjugated to a specific protein binding molecule, such as an antibody. The Feature Barcode cojugated molecule bound to the cell surface protein can be directly captured by the Gel Bead inside a GEM during GEM generation and amplified (see <u>Stepwise Objectives</u> for assay scheme specifics). The amplified DNA generated form the Feature Barcode can be used for Cell Surface Protein Library Construction.



Demonstrated Protocols for cell surface protein labeling



For antibody-oligonucleotide conjugation guidance and cell surface protein labeling protocol, consult Demonstrated Protocol Cell Surface Protein Labeling for Single Cell RNA Sequencing Protocols with Feature Barcoding technology (Document CG000149).



Failure to label cell surface proteins with a Feature Barcode conjugated to a specific protein binding molecule prior to using the cells for GEM Generation & Barcoding will preclude generation of Cell Surface Protein library.

Tips & Best Practices

lcons

Tips & Best Practices section includes additional guidance



Signifies critical step requiring accurate execution

Troubleshooting section includes additional guidance

Version Specific Update



Indicates version specific updates in a particular protocol step to inform users who have used a previous version of the product. The updates may be in volume, temperature, calculation instructions etc.

Emulsion-safe Plastics • Use validated emulsion-safe plastic consumables when handling GEMs as some plastics can destabilize GEMs.

Cell Concentration

- Recommended starting point is to load ~1,600 cells per reaction, resulting in recovery of ~1,000 cells, and a multiplet rate of ~0.8%. The optimal input cell concentration is 700-1,200 cells/µl.
- The presence of dead cells in the suspension may also reduce the recovery rate. Consult the 10x Genomics Single Cell Protocols Cell Preparation Guide and the Guidelines for Optimal Sample Preparation flowchart (Documents CG00053 and CG000126 respectively) for more information on preparing cells.

Multiplet Rate (%)	# of Cells Loaded	# of Cells Recovered
~0.4%	~800	~500
~0.8%	~1,600	~1,000
~1.6%	~3,200	~2,000
~2.3%	~4,800	~3,000
~3.1%	~6,400	~4,000
~3.9%	~8,000	~5,000
~4.6%	~9,600	~6,000
~5.4%	~11,200	~7,000
~6.1%	~12,800	~8,000
~6.9%	~14,400	~9,000
~7.6%	~16,000	~10,000

General	 Fully thaw and thoroughly mix reagents before use.
Reagent Handling	 Keep all enzymes and Master Mixes on ice during setup and use. Promptly move reagents back to the recommended storage.
	 Calculate reagent volumes with 10% excess of 1 reaction values.
	Cover Partitioning Oil tubes and reservoirs to minimize evaporation.
	• If using multiple chips, use separate reagent reservoirs for each chip during loading.
	 Thoroughly mix samples with the beads during bead-based cleanup steps.
50% Glycerol Solution	 Purchase 50% glycerol solution from Ricca Chemical Company, Glycerin (glycerol), 50% (v/v) Aqueous Solution, PN-3290-32.
	Prepare 50% glycerol solution:
	i. Mix an equal volume of water and 99% Glycerol, Molecular Biology Grade.
	ii. Filter through a 0.2 μ m filter.
	iii. Store at –20°C in 1-ml LoBind tubes. 50% glycerol solution should be equilibrated to room temperature before use.
Pipette	Follow manufacturer's calibration and maintenance schedules.
Calibration	Pipette accuracy is particularly important when using SPRIselect reagents.
Chromium Chip Handling	 Minimize exposure of reagents, chips, and gaskets to sources of particles and fibers, laboratory wipes, frequently opened flip-cap tubes, clothing that sheds fibers, and dusty surfaces.
	 Execute steps without pause or delay, unless indicated. When multiple chips are to be used, load, run, and collect the content from one chip before loading the next.
	 Fill all unused input wells in rows labeled 1, 2, and 3 on a chip with an appropriate volume of 50% glycerol solution before loading the used wells. DO NOT add glycerol to the Recovery Wells.
	 Avoid contacting the bottom surface of the chip with gloved hands and other surfaces. Frictional charging can lead to inadequate priming of the channels, potentially leading to either clogs or wetting failures.
	• Minimize the distance that a loaded chip is moved to reach the Chromium Controller.
	 Keep the chip horizontal to prevent wetting the gasket with oil, which depletes the input volume and may adversely affect the quality of the resulting emulsion.

Tips & Best Practices

10 011	10x Chip Holders encase Chromium Chips.
10x Chip Holders	• The holder lid flips over to become a stand, holding the chip at 45 degrees for optimal recovery well content removal.
	• Squeeze the black sliders on the back side of the holder together to unlock the lid and return the holder to a flat position.
Chromium	Align notch on the chip (upper left corner) and the holder.
Chip & Holder Assembly	 Insert the left-hand side of the chip under the guide. Depress the right-hand side of the chip until the spring-loaded clip engages.
	Close the lid before dispensing reagents into the wells.
Chromium Chip	 Place the assembled chip and holder flat on the bench with the lid closed.
Loading	Dispense against the side of the wells.
	Bubble formation is normal and does not affect performance.
	• When dispensing Gel Beads into the chip, wait for the remainder to drain into the bottom of the pipette tips and dispense again to ensure complete transfer.
	 Refer to Load Chromium Chip B for specific instructions.
Gel Bead Handling	Use one tube of Gel Beads per sample. DO NOT puncture the foil seals of tubes not used at the time.
	Equilibrate the Gel Beads strip to room temperature before use.
	• Store unused Gel Beads at –80°C and avoid more than 12 freeze-thaw cycles. DO NOT store Gel Beads at –20°C.
	 Attach a 10x Vortex Adapter to the top of standard laboratory vortexers to vortex the Gel Bead strips.
	 After vortexing, remove the Gel Bead strip from the adapter. Flick the Gel Bead strip in a sharp, downward motion maximize Gel Bead recovery. Confirm there are no bubbles at the bottom of the tubes.
	 If the required volume of beads cannot be recovered, place the pipette tips against the sidewalls and slowly dispense the Gel Beads back into the tubes. DO NOT introduce bubbles into the tubes and verify that the pipette tips contain no leftover Gel Beads.

Withdraw the full volume of beads again by pipetting slowly.

10x Gasket Attachment

- After reagents are loaded, attach the gasket by holding the tongue (curved end, to the right) and hook it on the left-hand tabs of the holder. Gently pull the gasket toward the right and hook it on the two right-hand tabs.
- DO NOT touch the smooth side of the gasket. DO NOT press down on the top of the gasket after attachment.
- Keep the assembly horizontal to avoid wetting the gasket with Partitioning Oil.



10x Magnetic Separator

- Offers two positions of the magnets (high and low) relative to a tube, depending on its orientation. Flip the magnetic separator over to switch between high (magnet•High) or low (magnet•Low) positions.
- If using MicroAmp 8-Tube Strips, use the high position (magnet•**High**) only throughout the protocol.

Magnetic Bead Cleanup Steps

- During magnetic bead based cleanup steps that specify waiting "until the solution clears", visually confirm clearing of solution before proceeding to the next step. See adjacent panel for an example.
- The time needed for the solution to clear may vary based on specific step, reagents, volume of reagents etc.



Magnetic beads mixed with reagent



Separation in progress



Separation continuing




Separation complete; solution is clear



SPRIselect Cleanup & Size Selection

- After aspirating the desired volume of SPRIselect reagent, examine the pipette tips before dispensing to ensure the correct volume is transferred.
- Pipette mix thoroughly as insufficient mixing of sample and SPRIselect reagent will lead to inconsistent results.
- Use fresh preparations of 80% Ethanol.



Enzymatic Fragmentation

 Ensure enzymatic fragmentation reactions are prepared on ice and then loaded into a thermal cycler pre-cooled to 4°C prior to initiating the Fragmentation, End Repair, and A-tailing incubation steps.

Sample Indices in Sample Index PCR

- Choose the appropriate sample index sets to ensure that no sample indices overlap in a multiplexed sequencing run.
- Each well in the i7 Sample Index plate contains a unique mix of 4 oligos.
- The sample indexes can therefore be used in any combination.
- Each sample index set is base-balanced to avoid monochromatic signal issues when it is the sole sample loaded on an Illumina sequencer.

Step 1

GEM Generation & Barcoding

- **1.1** Prepare Single Cell Master Mix
- **1.2** Load Chromium Chip B
- **1.3** Run the Chromium Controller
- 1.4 Transfer GEMs
- 1.5 GEM-RT Incubation

1.0 **GEM Generation 8** Barcoding

1.0 GEM Generation &	GET STARTE	Ð!				
Barcoding	Action		Item	10x PN	Preparation & Handling	Storage
	Equilibrate to Room Temperature		Chromium Single Cell 3' v3 Gel Beads	2000059	Equilibrate to room temperature 30 min before loading the chip.	–80°C
		•	RT Reagent	2000086	Vortex, verify no precipitate, centrifuge briefly.	-20°C
VERSION			Template Switch Oligo	3000228	Centrifuge briefly, resuspend in 80 μ Low TE Buffer. Vortex 15 sec at maximum speed, centrifuge briefly, leave at room temperature for \geq 30 min. After resuspension, store at -80° C.	–20°C
		0	Reducing Agent B	2000087	Vortex, verify no precipitate, centrifuge briefly.	-20°C
	Place on Ice	•	RT Enzyme C	2000085/ 2000102	Centrifuge briefly before adding to the mix.	–20°C
				Protein Labeling for Single Cell Ig technology (CG000149)	RNA	
	Obtain		Partitioning Oil	220088	-	Ambient
			Chromium Chip B Single Cell		nerica & Asia Pacific) rope, Middle East & Africa)	Ambient
				Use the indica	ated region-specific PN only.	
			10x Gasket	370017/ 3000072	See Tips & Best Practices.	Ambient
			10x Chip Holder	330019	See Tips & Best Practices.	Ambient
Firmware Version 3.16 or highe is required in the Chromium	r		10x Vortex Adapter	330002	See Tips & Best Practices.	Ambient
Controller or the Chromium Single Cell Controller used for Single Cell 3' protocols.			50% glycerol solution If using <8 reactions	-	See Tips & Best Practices.	-

Step 1

1.1 a. Prepare Master Mix on ice. Pipette mix 15x and centrifuge briefly. Master Mix Master Mix PN 1X (μl) 10

Master Mix Add reagents in the order listed	PN	1Χ (μl)	4X + 10% (μl)	8X + 10% (μl)
RT Reagent	2000086	20.0	88.0	176.0
Template Switch Oligo	3000228	3.1	13.9	27.7
Reducing Agent B	2000087	2.0	8.7	17.3
RT Enzyme C	2000085/ 2000102	8.3	36.6	73.1
Total	-	33.4	147.1	294.2

b. Add 33.4 µl Master Mix into each tube of a PCR 8-tube strip on ice.

Volume of Labeled Cell Suspension Stock per reaction (µl) Volume of Nuclease-free Water per reaction (µl)											
Cell Stock				·		ed Cell Re					
Concentration (Cells/µl)	500	1000	2000	3000	4000	5000	6000	7000	8000	9000	10000
100	8.0 38.6	16.0 30.6	32.0 14.6	n/a	n/a	n/a	n/a	n/a	n/a	n/a	n/a
200	4.0 42.6	8.0 38.6	16.0 30.6	24.0 22.6	32.0 14.6	40.0 6.6	n/a	n/a	n/a	n/a	n/a
300	2.7 43.9	5.3 41.3	10.7 35.9	16.0 30.6	21.3 25.3	26.7 19.9	32.0 14.6	37.3 9.3	42.7 3.9	n/a	n/a
400	2.0 44.6	4.0 42.6	8.0 38.6	12.0 34.6	16.0 30.6	20.0 26.6	24.0 22.6	28.0 18.6	32.0 14.6	36.0 10.6	40.0 6.6
500	1.6 45.0	3.2 43.4	6.4 40.2	9.6 37.0	12.8 33.8	16.0 30.6	19.2 27.4	22.4 24.2	25.6 21.0	28.8 17.8	32.0 14.6
600	1.3 45.3	2.7 43.9	5.3 41.3	8.0 38.6	10.7 35.9	13.3 33.3	16.0 30.6	18.7 27.9	21.3 25.3	24.0 22.6	26.7 19.9
700	1.1 45.5	2.3 44.3	4.6 42.0	6.9 39.7	9.1 37.5	11.4 35.2	13.7 32.9	16.0 30.6	18.3 28.3	20.6 26.0	22.9 23.7
800	1.0 45.6	2.0 44.6	4.0 42.6	6.0 40.6	8.0 38.6	10.0 36.6	12.0 34.6	14.0 32.6	16.0 30.6	18.0 28.6	20.0 26.6
900	0.9 45.7	1.8 44.8	3.6 43.0	5.3 41.3	7.1 39.5	8.9 37.7	10.7 35.9	12.4 34.2	14.2 32.4	16.0 30.6	17.8 28.8
1000	0.8 45.8	1.6 45.0	3.2 43.4	4.8 41.8	6.4 40.2	8.0 38.6	9.6 37.0	11.2 35.4	12.8 33.8	14.4	16.0 30.6
1100	0.7 45.9	1.5 45.1	2.9 43.7	4.4 42.2	5.8 40.8	7.3 39.3	8.7 37.9	10.2 36.4	11.6 35.0	13.1 33.5	14.5 32.1
1200	0.7	1.3	2.7	4.0	5.3	6.7 39.9	8.0 38.6	9.3 37.3	10.7	12.0 34.6	13.3 33.3
1300	0.6	1.2 45.4	2.5 44.1	3.7 42.9	4.9	6.2 40.4	7.4	8.6 38.0	9.8 36.8	11.1	12.3 34.3
1400	0.6	1.1	2.3	3.4 43.2	4.6	5.7	6.9 39.7	8.0 38.6	9.1 37.5	10.3 36.3	11.4 35.2
1500	0.5 46.1	1.1	2.1 44.5	3.2 43.4	4.3	5.3 41.3	6.4 40.2	7.5	8.5 38.1	9.6 37.0	10.7 35.9
1600	46.1 0.5 46.1	1.0	2.0	3.0	4.0	5.0	6.0	7.0	8.0	9.0	10.0 36.6
1700	0.5	45.6 0.9	44.6 1.9	43.6 2.8	42.6 3.8 (2.8	41.6	40.6 5.6 (1.0	39.6 6.6	38.6 7.5	37.6 8.5	9.4
1800	46.1 0.4	45.7 0.9	44.7 1.8	43.8	42.8 3.6	41.9	41.0 5.3	40.0 6.2	39.1 7.1	38.1 8.0	37.2 8.9
1900	46.2 0.4	45.7 0.8	44.8	43.9 2.5	43.0 3.4	42.2	41.3 5.1	40.4 5.9	39.5 6.7	38.6 7.6	37.7 8.4
2000	46.2 0.4	45.8 0.8	44.9 1.6	44.1 2.4	43.2 3.2	42.4 4.0	41.5 4.8	40.7 5.6	39.9 6.4	39.0 7.2	38.2 8.0
	46.2	45.8	45.0	44.2	43.4	42.6	41.8	41.0	40.2	39.4	38.6

Cell Suspension Volume Calculator Table (for step 1.2)


Grey boxes: Yellow boxes: Blue boxes: Volumes that would exceed the allowable water volume in each reaction

Indicate a low transfer volume that may result in higher cell load variability

Optimal range of cell stock concentration to maximize the likelihood of achieving the desired cell recovery target

1.2 Load Chromium Chip B

See Tips & Best Practices for chip handling instructions. When loading the chip, raising and depressing the pipette plunger should each take ~5 sec. Dispense against the side of the well, as illustrated below. Avoid contact with the bottom of the well. Bubble formation is normal and does not affect performance.





- a. Assemble Chromium Chip B in a 10x Chip Holder. See Tips & Best Practices.
- b. Dispense 50% Glycerol Solution into Unused Chip Wells (if < 8 samples per chip)
- i. **75 µl** to unused wells in **row labeled 1**.
- ii. 40 µl to unused wells in row labeled 2.
- iii. 280 µl to unused wells in row labeled 3.

DO NOT add 50% glycerol solution to the top row of Recovery Wells. DO NOT use any substitute for 50% glycerol solution.

c. Prepare Master Mix + Cell Suspension

Refer to the Cell Suspension Volume Calculator Table and add the appropriate volume of nuclease-free water and corresponding volume of single cell suspension to Master Mix for a total of **80 \mul** in each tube. Gently pipette mix the single cell suspension before adding to the Master Mix.



d. Load Row Labeled 1

Gently pipette mix the Master Mix + Cell Suspension and using the same pipette tip, dispense **75** µl Master Mix + Cell Suspension against the side of each well in **row labeled 1**.

e. Prepare Gel Beads

Snap the Gel Bead strip into a 10x Vortex Adapter. Vortex **30 sec.** Remove the Gel Bead strip and flick in a sharp, downward motion to ensure maximum recovery. Confirm there are no bubbles at the bottom of the tubes and liquid levels look even.

f. Load Row Labeled 2

Puncture the foil seal of the Gel Bead tubes. Slowly aspirate $40 \mu l$ Gel Beads. Dispense against the side of each well in **row labeled 2**.



g. Load Row Labeled 3

Dispense **280** μ l Partitioning Oil against the side of each well in **row labeled 3** by pipetting two aliquots of **140** μ l from a reagent reservoir. Failure to add Partitioning Oil can damage the Chromium Controller.

h. Attach 10x Gasket

Align the notch with the top left-hand corner. Ensure the gasket holes are aligned with the wells. Avoid touching the smooth gasket surface. DO NOT press down on the gasket.



GEM Generation & Barcoding

1.3 Run the Chromium Controller

Step 1

- **a.** Press the eject button on the Controller to eject the tray.
- **b.** Place the assembled chip with the gasket in the tray. Press the button to retract the tray.
- **c.** Confirm the Chromium Single Cell B program on screen. Press the play button.
- d. At completion of the run (~8.5 min), the
 Controller will chime. Immediately proceed to the next step.

Firmware Version 3.16 or higher is required in the Chromium Controller or the Chromium Single Cell Controller used for Single Cell 3' protocols.




1.4 Transfer GEMs

- a. Place a tube strip on ice.
- **b.** Press the eject button of the Controller and remove the chip.
- c. Discard the gasket. Open the chip holder.
 Fold the lid back until it clicks to expose the wells at 45 degrees.
 Ensure that the partitioning oil from the wells does not spill when exposing the wells.
- **d.** Check the volume in rows 1-3. Abnormally high volume in any well indicates a clog.
- e. Slowly aspirate 100 μl GEMs from the lowest points of the Recovery Wells in the top row without creating a seal between the tips and the bottom of the wells.
- f. Withdraw pipette tips from the wells. GEMs should appear opaque and uniform across all channels. Excess Partitioning Oil (clear) in the pipette tips indicates a potential clog.
- **g.** Over the course of **~20 sec**, dispense GEMs into the tube strip on ice with the pipette tips against the sidewalls of the tubes.
- h. If multiple chips are run back-to-back, cap/ cover the GEM-containing tube strip and place on ice for no more than 1 h.



Transfer GEMs



1.5 GEM-RT Incubation

Use a thermal cycler that can accommodate at least 100 μ l volume. A volume of 125 μ l is the preferred setting on Bio-Rad C1000 Touch. In alternate thermal cyclers, use highest reaction volume setting.

a. Incubate in a thermal cycler with the following protocol.

Lid Temperature	Reaction Volume	Run Time
53°C	125 µl	~55 min
Step	Temperature	Time
1	53°C	00:45:00
2	85°C	00:05:00
3	4°C	Hold

b. Store at 4°C for up to 72 h or at -20°C for up to a week, or proceed to the next step.

Step 2

Post GEM–RT Cleanup & cDNA Amplification

- 2.1 Post GEM–RT Cleanup Dynabeads
- 2.2 cDNA Amplification
- 2.3 cDNA Cleanup SPRIselect
- 2.4 cDNA QC & Quantification

2.0 Post GEM-RT Cleanup & cDNA Amplification



GET STARTE	<u>וח</u>			
Action	ltem	10x PN	Preparation & Handling	Storage
Equilibrate to Room Temperature	Reducing Agent B	2000087	Thaw, vortex, verify no precipitate, centrifuge.	-20°C
	Feature cDNA Primers 2 Verify name & PN	2000097	Vortex, centrifuge briefly.	–20°C
	Dynabeads MyOne SILANE	2000048	Vortex thoroughly (≥30 sec) immediately before adding to the mix.	4°C
	Beckman Coulter SPRIselect Reagent	-	Manufacturer's recommendations.	-
	Agilent Bioanalyzer High Sensitivity Kit If used for QC and quantification	-	Manufacturer's recommendations.	-
	Agilent TapeStation ScreenTape and Reagents If used for QC and quantification	-	Manufacturer's recommendations.	-
	Qubit dsDNA HS Assay Kit If used for QC and quantification	-	Manufacturer's recommendations.	-
Place on ice	O Amp Mix	2000047/ 2000103	Vortex, centrifuge briefly.	–20°C
Thaw at 65°C	Cleanup Buffer	2000088	Thaw for 10 min at 65°C at max speed on a thermomixer. Verify no visible crystals. Cool to room temperature.	–20°C
Obtain	Recovery Agent	220016	-	Ambient
	Qiagen Buffer EB	-	Manufacturer's recommendations.	-
	Bio-Rad 10% Tween 20	-	Manufacturer's recommendations.	-
	10x Magnetic Separator	230003	-	Ambient
	Prepare 80% Ethanol Prepare 15 ml for 8 reactions.	-	-	-

Biphasic Mixture

2.1 Post GEM-RT Cleanup – Dynabeads

a. Add **125 μl** Recovery Agent to each sample at room temperature. DO NOT pipette mix or vortex the biphasic mixture. Wait **2 min**.

The resulting biphasic mixture contains Recovery Agent/Partitioning Oil (pink) and aqueous phase (clear), with no persisting emulsion (opaque).


If biphasic separation is incomplete:

Firmly secure the cap on the tube strip, ensuring that no liquid is trapped between the cap and the tube rim. Mix by inverting the capped tube strip 5x, centrifuge briefly, and proceed to step b. DO NOT invert without firmly securing the caps.

A smaller aqueous phase volume indicates a clog during GEM generation.

b. Slowly remove and discard 125 µl Recovery Agent/Partitioning Oil (pink) from the bottom of the tube. DO NOT aspirate any aqueous sample.

c. Prepare Dynabeads Cleanup Mix.




<u>う</u>-

- **d.** Vortex and add **200 μl** to each sample. Pipette mix 10x (pipette set to 200 μl).
- e. Incubate 10 min at room temperature.
 Pipette mix again at ~5 min after start of incubation to resuspend settled beads.







Remove Recovery Agent



- d. Vortex and add 200 µl to each sample. Pipette mix 10x (pipette set to 200 µl).
- e. Incubate 10 min at room temperature. Pipette mix again at ~5 min after start of incubation to resuspend settled beads.
 - f. Prepare Elution Solution I. Vortex and centrifuge briefly.

Elution Solution I Add reagents in the order listed	PN	1Χ (μl)	10X (µl)
Buffer EB	-	98	980
10% Tween 20	-	1	10
O Reducing Agent B	2000087	1	10
Total	-	100	1000

g. At the end of 10 min incubation, place on a 10x Magnetic Separator•High position (magnet•High) until the solution clears.

A white interface between the aqueous phase and Recovery Agent is normal.

- h. Remove the supernatant.
- i. Add 300 µl 80% ethanol to the pellet while on the magnet. Wait 30 sec.
- j. Remove the ethanol.

TIPS

- k. Add 200 µl 80% ethanol to pellet. Wait 30 sec.
- I. Remove the ethanol.
- m.Centrifuge briefly. Place on the magnet•Low.
- n. Remove remaining ethanol. Air dry for 1 min.
- o. Remove from the magnet. Immediately add 35.5 µl Elution Solution I.
- p. Pipette mix (pipette set to 30 µl) without introducing bubbles.
- q. Incubate 2 min at room temperature.
- r. Place on the magnet-Low until the solution clears.
- s. Transfer 35 µl sample to a new tube strip.

2.2 **cDNA** Amplification

• •

a. Prepare cDNA Amplification Mix on ice. Vortex and centrifuge briefly.

cDNA Amplification Reaction Mix Add reagents in the order listed	PN	1Χ (μl)	4X + 10% (μl)	8X + 10% (µl)
O Amp Mix	2000047	50	220	440
• Feature cDNA Primers 2 Verify name & PN Use indicated primer only	2000097	15	66	132
Total	-	65	286	572

- b. Add 65 µl cDNA Amplification Reaction Mix to 35 µl sample.
- c. Pipette mix 15x (pipette set to 90 µl). Centrifuge briefly.
- d. Incubate in a thermal cycler with the following protocol.

Lid Temperature	Reaction Volume	Run Time
105°C	100 µl	~30-45 min
Step	Temperature	Time
1	98°C	00:03:00
2	98°C	00:00:15
3	VERSION SPECIFIC Version Specific Updated Temperature	00:00:20
4	72°C	00:01:00
5	Go to Step 2, see table	below for total # of cycles
6	72°C	00:01:00
7	4°C	Hold

The optimal number of cycles is a trade-off between generating sufficient final mass for library construction and minimizing PCR amplification artifacts. The number of cDNA cycles should also be reduced if large numbers of cells are sampled.

Recommended starting point for cycle number optimization.

Targeted Cell Recovery	Total Cycles
<500	13
500-6,000	12
>6,000	11



e. Store at 4°C for up to 72 h or at -20°C for ≤1 week, or proceed to the next step.



Step Overview (steps 2.2 & 2.3)

Amplification Products Generated in Step 2.2 - cDNA Amplification Post GEM-RT Cleanup Products +Feature cDNA Primers 2 PN-2000097 Read 1N **DNA Amplification** Amplification Products Poly(dT)VN Read 1 TS0 cDNA from poly-adenylated mRNA Capture Feature Read 2 Seg 1 Barcode Read 1N DNA from cell surface protein Feature Barcode Step 2.3 – cDNA Cleanup – SPRIselect Overview SPRIselect Cleanup Transfer 80 µl supernatant to a new tube **Remove remaining** DO NOT discard DO NOT discard supernatant without the pellet the transferred disturbing the pellet supernatant Capture Feature Read 2 Seq 1 Barcode Read 1 Poly(dT)VN TS0 Read 1N cDNA from poly-adenylated mRNA DNA from cell surface protein Feature Barcode 2.3A Pellet Cleanup 2.3B Supernatant Cleanup (for 3' Gene Expression library) (for Cell Surface Protein library)

2.3 cDNA Cleanup – SPRIselect

Step 2

- a. Vortex to resuspend the SPRIselect reagent. Add 60 μ l SPRIselect reagent (0.6X) to each sample and pipette mix 15x (pipette set to 150 μ l).
- b. Incubate 5 min at room temperature.
- c. Place on the magnet•High until the solution clears.
- **d.** Transfer and save **80 μl** supernatant in a new tube strip without disturbing the pellet. Maintain at **room temperature**. DO NOT discard the transferred supernatant (cleanup for Cell Surface Protein library construction).
- e. Remove the remaining supernatant from the pellet without disturbing the pellet. DO NOT discard the pellet (cleanup for 3' Gene Expression library construction). Immediately proceed to Pellet Cleanup (step 2.3A).



2.3A Pellet Cleanup

(for 3' Gene Expression library)

- i. Add $200\,\mu l\,80\%$ ethanol to the pellet. Wait $30\,sec.$
- ii. Remove the ethanol.
- iii. Repeat steps i and ii for a total of 2 washes.
- iv. Centrifuge briefly and place on the magnet•Low.
- v. Remove any remaining ethanol. Air dry for 2 min. DO NOT exceed 2 min as this will decrease elution efficiency.
- **vi.** Remove from the magnet. Add **40.5 μl** Buffer EB. Pipette mix 15x.
- vii. Incubate 2 min at room temperature.
- viii. Place the tube strip on the magnet•High until the solution clears.
- ix. Transfer 40 µl sample to a new tube strip.
- x. Store at 4°C for up to 72 h or at -20°C for up to 4 weeks, or proceed to step 2.4 followed by step 3 for 3' Gene Expression Library Construction.

2.3B Transferred Supernatant Cleanup

(for Cell Surface Protein library)

- i. Vortex to resuspend the SPRIselect reagent. Add 70 μl SPRIselect reagent (2.0X) to 80 μl of the transferred supernatant and pipette mix 15x (pipette set to 150 μl).
- ii. Incubate for 5 min at room temperature.
- iii. Place on the magnet•High until the solution clears.
- iv. Remove supernatant.
- v. Add 200 µl 80% ethanol to the pellet. Wait 30 sec.
- vi. Remove the ethanol.
- vii. Repeat steps v and vi for a total of 2 washes.
- viii. Centrifuge briefly and place on the magnet•Low.
- ix. Remove any remaining ethanol. Air dry for 2 min.
 D0 NOT exceed 2 min as this will decrease elution efficiency.
- **x.** Remove from the magnet. Add **40.5 μl** Buffer EB. Pipette mix 15x.
- xi. Incubate 2 min at room temperature.
- xii. Place the tube strip on the magnet•High until the solution clears.


xiii.Transfer 40 µl sample to a new tube strip.

xiv. STOP Store at 4°C for up to 72 h or at –20°C for up to 4 weeks, or proceed directly to step 4 for Cell Surface Protein Library Construction.

2.4 cDNA QC & Quantification

a. Run **1 μl** of sample from **Pellet Cleanup** (step 2.3A-x; Dilution Factor 1:10) on an Agilent Bioanalyzer High Sensitivity chip. DO NOT run sample from 2.3B Transferred Supernatant Cleanup step.

For input cells with low RNA content (<1pg total RNA/cell), 1 µl undiluted product may be run. Lower molecular weight product (35–50 bp) may be present. This is normal and does not affect sequencing or application performance.




EXAMPLE CALCULATION

ii. Note Concentration [pg/µl]

i. Select Region

Under the "Electropherogram" view choose the "Region Table". Manually select the region of ~200 - ~9000 bp



iii. <u>Calculate</u>

Multiply the cDNA concentration $[pg/\mu l]$ reported via the Agilent 2100 Expert Software by the elution volume (40 μl) of the Post cDNA Amplification Reaction Clean Up sample (taking any dilution factors into account) and then divide by 1000 to obtain the total cDNA yield in ng.

Example Calculation of cDNA Total Yield

Concentration: 1244.06 pg/µl Elution Volume: 40 Dilution Factor: 10

Total cDNA Yield

= <u>Conc'n (pg/µl) x Elution Volume (µl) x Dilution Factor</u> 1000 (pg/ng)

= <u>1244.06 (pg/µl) x 40 (µl) x 10</u> = 497.62 ng 1000 (pg/ng)

Carry forward ONLY 25% of total cDNA yield into 3' Gene Expression Library Construction (step 3) = 0.25 x Total cDNA yield

= 0.25 x 497.62= 124.4ng

Refer to step 3.5 for appropriate number of Sample Index PCR cycles based on carry forward cDNA yield/input cDNA.

Alternate Quantification Methods:

Agilent TapeStation. See Appendix for representative traces

Agilent Bioanalyzer or Agilent TapeStation are the recommended methods for accurate quantification.

(If using Qubit Fluorometer and Qubit dsDNA HS Assay Kit, see Appendix)

Step 3

3' Gene Expression Library Construction

- 3.1 Fragmentation, End Repair & A-tailing
- **3.2** Post Fragmentation End Repair & A-tailing Double Sided Size Selection SPRIselect
- **3.3** Adaptor Ligation
- **3.4** Post Ligation Cleanup SPRIselect
- 3.5 Sample Index PCR
- **3.6** Post Sample Index PCR Double Sided Size Selection SPRIselect
- **3.7** Post Library Construction QC

Step 3

3.0 3' Gene Expression Library Construction




GET STARTI	ED!			
Action	ltem	10x PN	Preparation & Handling	Storage
Equilibrate to Room Temperature	• Fragmentation Buffer	2000091	Vortex, verify no precipitate, centrifuge briefly.	–20°C
	🥚 Adaptor Oligos	2000094	Vortex, centrifuge briefly.	–20°C
	Ligation Buffer	2000092	Vortex, verify no precipitate, centrifuge briefly.	-20°C
	😑 SI Primer	2000095	-	–20°C
	Chromium i7 Sample Index Plate	120262	-	-20°C
	Beckman Coulter SPRIselect Reagent	-	Manufacturer's recommendations.	-
	Agilent TapeStation Screen Tape and Reagents If used for QC		Manufacturer's recommendations.	
	Agilent Bioanalyzer High Sensitivity kit If used for QC	-	Manufacturer's recommendations.	-
Place on Ice	Fragmentation Enzyme	2000090/ 2000104	Centrifuge briefly.	–20°C
	DNA Ligase	220110/ 220131	Centrifuge briefly.	–20°C
	Amp Mix	2000047/ 2000103	Centrifuge briefly.	–20°C
	KAPA Library Quantification Kit for Illumina Platforms	-	Manufacturer's recommendations.	-
Obtain	Qiagen Buffer EB	-	-	Ambient
	10x Magnetic Separator	230003	See Tips & Best Practices.	Ambient
	Prepare 80% Ethanol Prepare 20 ml for 8 reactions	-	Prepare fresh.	Ambient

Step Overview (Step 3.1d)

Correlation between input & library complexity

A Single Cell 3' Gene Expression library is generated using a fixed proportion (10 μ l, 25%) of the total cDNA (40 μ l) obtained at step 2.3m. The complexity of this library will be comparable to one generated using a higher proportion (>25%) of the cDNA. The remaining proportion (30 μ l, 75%) of the cDNA may be stored at 4°C for up to 72 h or at -20°C for longer-term storage (up to 4 weeks).



Note that irrespective of the total cDNA yield (ng), which may vary based on cell type, targeted cell recovery etc., this protocol has been optimized for a broad range of input mass (ng), as shown in the example below. The total number of SI PCR cycles (step 3.5e) should be optimized based on carrying forward a fixed proportion (10 μ l, 25%) of the total cDNA yield calculated during Post cDNA Amplification QC & Quantification (step 2.4).

Cell Type	Targeted	Total cDNA Yield –	cDNA Input into Fragmentation		SI PCR Cycle
	Cell Recovery	very (ng)	Volume (µl)	Mass (ng)	Number
High RNA Content	Low	250 ng	10 µl	62.5 ng	13
	High	1900 ng	10 µl	475 ng	10
****	Low	1 ng	10 µl	0.25 ng	16
	High	200 ng	10 µl	50 ng	12

Example: Library Construction Input Mass & SI PCR Cycles

3.1 Fragmentation, End Repair & A-tailing

a. Prepare a thermal cycler with the following incubation protocol.

Lid Temperature	Reaction Volume	Run Time
65°C	50 μι	~35 min
Step	Temperature	Time
Pre-cool block Pre-cool block prior to preparing the Fragmentation Mix	4°C	Hold
Fragmentation	32°C	00:05:00
End Repair & A-tailing	65°C	00:30:00
Hold	4°C	Hold

b. Vortex Fragmentation Buffer. Verify there is no precipitate.

c. Prepare Fragmentation Mix on ice. Pipette mix and centrifuge briefly.

Fragmentation Mix Add reagents in the order listed	PN	1Χ (μl)	4X + 10% (μl)	8X + 10% (μl)
Fragmentation Buffer	2000091	5	22	44
Fragmentation Enzyme	2000090/ 2000104	10	44	88
Total	-	15	66	132

VERSION SPECIFIC

d. Transfer ONLY 10 μl purified cDNA sample from Pellet Cleanup (step 2.3A-x) to a tube strip.

Note that only 10 μl (25%) cDNA sample transfer is sufficient for generating 3' Gene Expression library.

The remaining 30 μ l (75%) cDNA sample can be stored at 4°C for up to 72 h or at -20°C for up to 4 weeks for generating additional 3' Gene Expression libraries.

- e. Add 25 µl Buffer EB to each sample.
- f. Add 15 µl Fragmentation Mix to each sample.
- g. Pipette mix 15x (pipette set to 35 μ l) on ice. Centrifuge briefly.
- h. Transfer into the pre-cooled thermal cycler (4°C) and press "SKIP" to initiate the protocol.

3.2 Post Fragmentation, End Repair & A-tailing Double Sided Size Selection – SPRIselect

Step 3

- a. Vortex to resuspend SPRIselect reagent. Add **30 µl** SPRIselect **(0.6X)** reagent to each sample. Pipette mix 15x (pipette set to 75 µl).
- b. Incubate 5 min at room temperature.
- c. Place on the magnet•High until the solution clears. DO NOT discard supernatant.



- d. Transfer **75** µl supernatant to a new tube strip.
- e. Vortex to resuspend SPRIselect reagent. Add 10 μl SPRIselect reagent (0.8X) to each sample. Pipette mix 15x (pipette set to 80 μl).
- f. Incubate 5 min at room temperature.
- g. Place on the magnet•High until the solution clears.





- h. Remove 80 µl supernatant. DO NOT discard any beads.
- i. Add 125 µl 80% ethanol to the pellet. Wait 30 sec.
- j. Remove the ethanol.
- k. Repeat steps i and j for a total of 2 washes.
- **I.** Centrifuge briefly. Place on the magnet•Low until the solution clears. Remove remaining ethanol. DO NOT over dry to ensure maximum elution efficiency.
- m. Remove from the magnet. Add 50.5 µl Buffer EB to each sample. Pipette mix 15x.
- n. Incubate 2 min at room temperature.
- o. Place on the magnet•High until the solution clears.
- p. Transfer 50 µl sample to a new tube strip.

3.3 Adaptor Ligation

a. Prepare Adaptor Ligation Mix. Pipette mix and centrifuge briefly.

Adaptor Ligation Mix Add reagents in the order listed	PN	1X (μl)	4X + 10% (μl)	8X + 10% (μl)
Ligation Buffer	2000092	20	88	176
DNA Ligase	220110/ 220131	10	44	88
Adaptor Oligos	2000094	20	88	176
Total	-	50	220	440

b. Add **50 \mul** Adaptor Ligation Mix to **50 \mul** sample. Pipette mix 15x (pipette set to 90 μ l). Centrifuge briefly.

c. Incubate in a thermal cycler with the following protocol.

Lid Temperature	Reaction Volume	Run Time
30°C	100 µl	15 min
Step	Temperature	Time
1	20°C	00:15:00
2	4°C	Hold

3.4 a. Vortex to resuspend SPRIselect Reagent. Add 80 μl SPRIselect Reagent (0.8X) to each sample. Pipette mix 15x (pipette set to 150 μl). b. Incubate 5 min at room temperature.

- $\textbf{c.} \ \ \textbf{Place on the magnet} \textbf{\bullet} \textbf{High until the solution clears}.$
- d. Remove the supernatant.
- e. Add 200 μl 80% ethanol to the pellet. Wait 30 sec.
- f. Remove the ethanol.
- g. Repeat steps e and f for a total of 2 washes.
- h. Centrifuge briefly. Place on the magnet•Low.
- Remove any remaining ethanol. Air dry for 2 min.
 DO NOT exceed 2 min as this will decrease elution efficiency.
- j. Remove from the magnet. Add $30.5\,\mu l$ Buffer EB. Pipette mix 15x.
- k. Incubate 2 min at room temperature.
- $\label{eq:lastice} \textbf{l.} \quad \textbf{Place on the magnet-Low until the solution clears.}$
- m. Transfer 30 μl sample to a new tube strip.

3.5 Sample Index PCR

- a. Choose the appropriate sample index sets to ensure that no sample indices overlap in a multiplexed sequencing run. Record the 10x Sample Index name (PN-220103 Chromium i7 Sample Index Plate well ID) used.
- b. Prepare Sample Index PCR Mix.

Sample Index PCR Mix Add reagents in the order listed	PN	1Χ (μl)	4X + 10% (µl)	8X + 10% (μl)
O Amp Mix	2000047/ 2000103	50	220	440
e SI Primer	2000095	10	44	88
Total	-	60	264	528

- c. Add 60 µl Sample Index PCR Mix to 30 µl sample.
- **d.** Add **10 μl** of an individual Chromium i7 Sample Index to each well and record the well ID used. Pipette mix 5x (pipette set to 85 μl). Centrifuge briefly.
- e. Incubate in a thermal cycler with the following protocol.

Lid Temperature	Reaction Volume	Run Time		
105°C	100 µl	~25-40 min		
Step	Temperature	Time		
1	98°C	00:00:45		
2	98°C	00:00:20		
3	54°C	00:00:30		
4	72°C	00:00:20		
5	Go to step 2, see below	/ for # of cycles		
6	72°C	00:01:00		
7	4°C	Hold		
		Recommended cycle numbers		
The total cycles should be optimized ba on 25% carry forward cDNA yield/input	cDNA Input	Total Cycles		
calculated during cDNA QC & Quantifica (step 2.4)	ation 0.25-25 ng	14-16		
	25-150 ng	12-14		
	150-500 ng	10-12		
f. Store at 4°C for up to 72 h or	500-1,000 ng	8-10		
proceed to the next step.	1,000-1,500 ng	6-8		
	>1500 ng	5		




3.6 Post Sample Index PCR Double Sided Size Selection – SPRIselect

- a. Vortex to resuspend the SPRIselect reagent. Add **60 µl** SPRIselect Reagent **(0.6X)** to each sample. Pipette mix 15x (pipette set to 150 µl).
- b. Incubate 5 min at room temperature.
- c. Place the magnet•High until the solution clears. DO NOT discard supernatant.
- d. Transfer 150 µl supernatant to a new tube strip.
- e. Vortex to resuspend the SPRIselect reagent. Add **20 µl** SPRIselect Reagent **(0.8X)** to each sample. Pipette mix 15x (pipette set to 150 µl).
- f. Incubate 5 min at room temperature.
- g. Place the magnet•High until the solution clears.
- h. Remove 165 µl supernatant. DO NOT discard any beads.
- i. With the tube still in the magnet, add 200 µl 80% ethanol to the pellet. Wait 30 sec.
- j. Remove the ethanol.
- k. Repeat steps i and j for a total of 2 washes.
- I. Centrifuge briefly. Place on the magnet•Low. Remove remaining ethanol.
- m. Remove from the magnet. Add 35.5 µl Buffer EB. Pipette mix 15x.
- n. Incubate 2 min at room temperature.
- o. Place on the magnet•Low until the solution clears.
- **p.** Transfer **35** µl to a new tube strip.
- **q.** Store at 4°C for up to 72 h or at -20°C for long-term storage.



Step 3

Run 1 µl sample at 1:10 dilution on an Agilent Bioanalyzer High Sensitivity chip.



Determine the average fragment size from the Bioanalyzer trace. This will be used as the insert size for library quantification.

Alternate QC Method:

• Agilent TapeStation. See Appendix for representative traces

See Appendix for Post Library Construction Quantification

Step 4

Cell Surface Protein Library Construction

- 4.1 Sample Index PCR
- **4.2** Post Sample Index PCR Size Selection SPRIselect
- **4.3** Post Library Construction QC

4.0 Cell Surface Protein Library Construction

GET START	ED!			
Action	ltem	10x PN	Preparation & Handling	Storage
Equilibrate to Room Temperature	Feature SI Primers 2	2000099	-	-20°C
	Chromium i7 Sample Index Plate	120262	-	–20°C
	Beckman Coulter SPRIselect Reagent	-	Manufacturer's recommendations.	-
	Agilent TapeStation Screen Tape and Reagents If used for QC		Manufacturer's recommendations.	
	Agilent Bioanalyzer High Sensitivity kit If used for QC	-	Manufacturer's recommendations.	-
Place on Ice	O Amp Mix	2000047	Centrifuge briefly.	–20°C
	KAPA Library Quantification Kit for Illumina Platforms	-	Manufacturer's recommendations.	-
Obtain	Qiagen Buffer EB	-	-	Ambient
	10x Magnetic Separator	230003	See Tips & Best Practices.	Ambient
	Prepare 80% Ethanol Prepare 20 ml for 8 reactions	-	Prepare fresh.	Ambient

4.1 Sample Index PCR

- a. Choose the appropriate sample index sets to ensure that no sample indices overlap in a multiplexed sequencing run. Record the 10x Sample Index name (PN-220103 Chromium i7 Sample Index Plate well ID) used.
- b. Prepare Sample Index PCR Mix.

Sample Index PCR Mix Add reagents in the order listed	PN	1Χ (μl)	4X + 10% (μl)	8X + 10% (μl)
O Amp Mix	2000047	50	220	440
Feature SI Primers 2	2000099	35	154	308
Total	-	85	374	748

c. Transfer ONLY 5 μl DNA sample from the Transferred Supernatant Cleanup (step 2.3B-xiv) to a new tube strip.

Note that only **5 µl** DNA sample is sufficient for generating Cell Surface Protein library. The remaining **35 µl** DNA sample can be stored at **4°C** for up to **72 h** or at **-20°C** for up to **4 weeks** for generating additional Cell Surface Protein libraries.


- d. Add 85 µl Sample Index PCR Mix to each sample.
- e. Add 10 μ l of an individual Chromium i7 Sample Index to each well and record their assignment. Pipette mix 5x (pipette set to 90 μ l). Centrifuge briefly.
- f. Incubate in a thermal cycler with the following protocol.

Lid Temperature	Reaction Volume	Run Time
105°C	100 µl	~25-40 min
Step	Temperature	Time
1	98°C	00:00:45
2	98°C	00:00:20
3	54°C	00:00:30
4	72°C	00:00:20
5	Go to step 2, repeat 9X for a total of 10 cycles*	
6	72°C	00:01:00
7	4°C	Hold

*Optimization of cycle number may be needed based on target protein expression levels and number of antibodies used for labeling.

4.2 Post Sample Index PCR Size Selection -SPRIselect a. Vortex to resuspend the SPRIselect reagent. Add 120 μl SPRIselect Reagent (1.2X) to each sample. Pipette mix 15x (pipette set to 150 μl). b. Incubate 5 min at room temperature. c. Place on the magnet•High until the solution clears.

- d. Remove the supernatant.
- e. Add 300 µl 80% ethanol to the pellet. Wait 30 sec.
- f. Remove the ethanol.
- g. Add 200 µl 80% ethanol to the pellet. Wait 30 sec.
- h. Remove the ethanol.
- i. Centrifuge briefly. Place on the magnet•Low. Remove remaining ethanol.
- j. Remove from the magnet. Add 40.5 µl Buffer EB. Pipette mix 15x.
- k. Incubate 2 min at room temperature.
- I. Place on the magnet-Low until the solution clears.
- m. Transfer 40 µl to a new tube strip.
- n. Store at 4°C for up to 72 h or at -20°C for long-term storage.



Run 1 µl sample at 1:10 dilution on an Agilent Bioanalyzer High Sensitivity chip.

Determine the average fragment size from the Bioanalyzer trace. This will be used as the insert size for library quantification.

Alternate QC Method:

• Agilent TapeStation. See Appendix for representative traces

See Appendix for Post Library Construction Quantification

Post Library Construction


4.3

QC

Sequencing

Sequencing Libraries

Chromium Single Cell 3' Gene Expression and Cell Surface Protein libraries comprise standard Illumina paired-end constructs which begin with P5 and end with P7. These libraries include 16 bp 10x Barcodes at the start of TruSeq Read 1 and Nextera Read 1 (Read 1N) respectively while 8 bp sample index sequences are incorporated as the i7 index read. TruSeq Read 1 and TruSeq Read 2 are standard Illumina sequencing primer sites used in paired-end sequencing of Single Cell 3' Gene Expression libraries. Nextera Read 1 (Read 1N) and TruSeq Read 2 are used for paired-end sequencing of Single Cell 3' Cell Surface Protein libraries. Sequencing these libraries produce a standard Illumina BCL data output folder.



Chromium Single Cell 3' Gene Expression Library

Illumina Sequencer Compatibility

The compatibility of the listed sequencers has been verified by 10x Genomics. Some variation in assay performance is expected based on sequencer choice. For more information about performance variation, visit the 10x Genomics Support website.

- MiSeq
- NextSeq 500/550*
- HiSeq 2500 (Rapid Run)
- HiSeq 3000/4000
- NovaSeq

*Sequencing Chromium Single Cell libraries on the NextSeq 500/550 platform may yield reduced sequence quality and sensitivity relative to the MiSeq, HiSeq, and NovaSeq platforms. Refer to the 10x Genomics Support website for more information.

Sample Indices

Each sample index in the Chromium i7 Sample Index Kit (PN-120262) is a mix of 4 different sequences to balance across all 4 nucleotides. If multiple samples are pooled in a sequence lane, the sample index name (i.e. the Chromium i7 Sample Index plate well ID, SI-GA-) is needed in the sample sheet used for generating FASTQs with "cellranger mkfastq". Samples utilizing the same sample index should not be pooled together, or run on the same flow cell lane, as this would not enable correct sample demultiplexing.

	Sequencing Depth	Minimum 20,000 read pairs per cell
3' Gene Expression Library Sequencing Depth & Run Parameters	Sequencing Type	Paired-end, single indexing
	Sequencing Read	Recommended Number of Cycles
	Read 1 i7 Index i5 Index Read 2	28 cycles 8 cycles 0 cycles 91 cycles
Call Curfees Destain	Sequencing Depth	Minimum 5,000 read pairs per cell
Cell Surface Protein Library Sequencing Depth & Run Parameters	Sequencing Type	Paired-end, single indexing
	Sequencing Read	Recommended Number of Cycles
	Read 1 i7 Index i5 Index Read 2	28 cycles 8 cycles 0 cycles 91 cycles

Library Loading

Once quantified and normalized, the 3' Gene Expression and Cell Surface Protein libraries should be denatured and diluted as recommended for Illumina sequencing platforms. Refer to Illumina documentation for denaturing and diluting libraries. Refer to the 10x Genomics Support website, for more information.

Instrument	3' Gene Expression libraries only or 3' Gene Expression + Cell Surface Protein libraries		Cell Surface Protein libraries only	
	Loading Concentration (pM)	PhiX (%)	Loading Concentration (pM)	PhiX (%)
MiSeq	11	1	11	1
NextSeq 500/550	1.8	1	1.8	1
HiSeq 2500 (RR)	11	1	11	1
HiSeq 4000	240	1	240	1
NovaSeq	150*/300	1	150*/300	1

* Use 150pM loading concentration for Illumina XP workflow.

Library Pooling

The 3' Gene Expression and the Cell Surface Protein libraries maybe pooled for sequencing, taking into account the differences in cell number and per-cell read depth requirements between each library. Samples utilizing the same sample index should not be pooled together, or run on the same flow cell lane, as this would not enable correct sample demultiplexing.

Library Pooling Example:

Libraries	Sequencing Depth (read pairs per cell)	Library Pooling Ratio
3' Gene Expression library	20,000	4
Cell Surface Protein library	5,000	1

Troubleshooting

6.1 GEMs

STEP NORMAL REAGENT CLOGS & WETTING FAILURES

After Chip B is removed from the Controller and the wells are exposed



All 8 Recovery Wells are similar in volume and opacity.


NO FLL A B C D E F G H

Recovery Well G indicates a reagent clog. Recovery Well C and E indicate a wetting failure. Recovery Wells B, D, and F are normal. Wells A and H contain 50% Glycerol Solution.


The image indicates clogs in the Gel Bead line (orange arrow) and the sample line (yellow arrow) as evidenced by higher than usual volumes in the input wells.



1.4 f Transfer GEMs from Chip E Recovery Wells




All liquid levels are similar in volume and opacity without air trapped in the pipette tips.




Pipette tips C and E indicate a wetting failure. Pipette tip C contains partially emulsified GEMs. Emulsion is absent in pipette tip E. Pipette tip G indicates a reagent clog. 2.1 a After transfer of the GEMs + Recovery Agent

NORMAL



All liquid levels are similar in the aqueous sample volume (clear) and Recovery Agent/Partitioning Oil (pink).


REAGENT CLOGS & WETTING FAILURES




Tube G indicates a reagent clog has occurred. There is a decreased volume of aqueous layer (clear). Tube C and E indicate a wetting failure has

occurred. There is an abnormal residual volume of Recovery Agent/Partitioning Oil (pink).

2.1 b After aspiration of Recovery Agent/ Partitioning Oil




All liquid volumes are similar in the aqueous sample volume (clear) and residual Recovery Agent/Partitioning Oil (pink).




Tube G indicates a reagent clog has occurred. There is a decreased volume of aqueous layer (clear). There is also a greater residual volume of Recovery Agent/Partitioning Oil (pink). Tube C and E indicate a wetting failure has occurred. There is an abnormal residual volume of Recovery Agent/Partitioning Oil (pink).

2.1 d After addition of Dynabeads Cleanup Mix



All liquid volumes are similar after addition of the Dynabeads Cleanup Mix.



Tube G indicates a reagent clog has occurred. There is an abnormal ratio of Dynabeads Cleanup Mix (brown) to Recovery Agent/Partitioning Oil (appears white).

Tube C and E indicate a wetting failure has occurred. There is an abnormal ratio of Dynabeads Cleanup Mix (brown) to Recovery Agent/Partitioning Oil (appears white).

If a channel clogs or wetting failure occurs during GEM generation, it is recommended that the sample be remade. If any of the listed issues occur, take a picture and send it to support@10xgenomics.com for further assistance.

6.2 Chromium Controller Errors

If the Chromium Controller or the Chromium Single Cell Controller fails to start, an error tone will sound and one of the following error messages will be displayed:

- a. Chip not read Try again: Eject the tray, remove and/or reposition the 10x Chip Holder assembly and try again. If the error message is still received after trying this more than twice, contact support@10xgenomics.com for further assistance.
- b. Check gasket: Eject the tray by pressing the eject button to check if there is a 10x Gasket on the Chromium Chip. In the case when the 10x Gasket installation was forgotten, install and try again. In the case when a 10x Gasket was already installed, remove, reapply, and try again. If the error message is still received after trying either of these more than twice, contact support@10xgenomics.com for further assistance.
- c. Error Detected: Row_Pressure:
 - i. If this message is received within a few seconds of starting a run, eject the tray by pressing the eject button and check for dirt or deposits on the 10x Gasket. If dirt is observed, replace with a new 10x Gasket and try again. If the error message is still received after trying this more than twice, contact support@10xgenomics.com for further assistance.
 - ii. If this message is received after a few minutes into the run, the Chromium Chip must be discarded. Do not try running this Chromium Chip again as this may damage the Chromium Controller.
- d. CAUTION: Chip Holder not Present: Eject the tray by pressing the eject button to check there is a 10x Chip Holder encasing the Chromium Chip. In the case when the 10x Chip Holder was forgotten, install with a 10x Gasket in place, and try again. If the error message is still received after a 10x Chip Holder is confirmed as in place, contact support@10xgenomics.com for further assistance.
- e. Invalid Chip CRC Value: This indicates the Chromium Chip has encountered an error, should not be run, and must be discarded. Contact support@10xgenomics.com for further assistance.

Appendix

Post Library Construction Quantification Agilent TapeStation Traces Oligonucleotide Sequences

Post Library Construction Quantification

- a. Thaw KAPA Library Quantification Kit for Illumina Platforms.
- b. Dilute 2 µl sample with deionized water to appropriate dilutions that fall within the linear detection range of the KAPA Library Quantification Kit for Illumina Platforms. (For more accurate quantification, make the dilution(s) in duplicate).
- **c.** Make enough Quantification Master Mix for the DNA dilutions per sample and the DNA Standards (plus 10% excess) using the guidance for 1 reaction volume below.

Quantification Master Mix	1X (μl)
SYBR Fast Master Mix + Primer	12
Water	4
Total	16

- **d**. Dispense **16 μl** Quantification Master Mix for sample dilutions and DNA Standards into a 96 well PCR plate.
- e. Add 4 µl sample dilutions and 4 µl DNA Standards to appropriate wells. Centrifuge briefly.
- f. Incubate in a thermal cycler with the following protocol.

Step	Temperature	Run Time
1	95°C	00:03:00
2	95°C	00:00:05
3	67°C	00:00:30
4	Go to Step 2, 29X (Total 30 cycles)	


g. Follow the manufacturer's recommendations for qPCR-based quantification. For library quantification for sequencer clustering, determine the concentration based on insert size derived from the Bioanalyzer/TapeStation trace.


Agilent TapeStation Traces


Agilent TapeStation Traces

Agilent Tape Station High Sensitivity D5000 ScreenTape was used. Protocol steps correspond to the Chromium Single Cell 3 v3 Reagent Kits User Guide with Feature Barcode technology for Cell Surface Protein (CG000185)


Protocol Step 2.4 - cDNA QC & Quantification







Protocol Step 4.3 – Post Library Construction QC (Cell Surface Protein library)



Alternate QC Method:

Qubit Fluorometer and Qubit dsDNA HS Assay Kit

Multiply the cDNA concentration reported via the Qubit Fluorometer by the elution volume (40 µl) to obtain the total cDNA yield in ng. To determine the equivalent range using the Agilent 2100 Expert Software, select the region encompassing 35-10,000 bp.

Oligonucleotide Sequences

