

Wood Float Frame: Canvas Installation & Finishing Instructions

Scan the QR Code for
Online Instructions



Included Hardware:

- 2 Wire Hangers
- 2 Wall Protectors
- Wire
- Courtesy Hanger

Needed Materials:

- Phillips Screwdriver
- Drill with Phillips Screwdriver Tip
- 1/8" Drill Bit
- Soft Cloth, Towel, or Protective Surface
- Cardboard or Wood Shims
- Screws Suitable for Your Canvas Stretcher Bars

Before Assembly

- Screws for attaching the canvas are not included.
- Use screws appropriate for your stretcher bar thickness.
- Work on a soft surface to avoid scratching the frame.
- Do not overtighten screws. Take care when attaching the canvas to avoid damaging the frame or artwork.



1. Position and Center Your Canvas

Lay the frame face up on a protected work surface and place the stretched canvas into the frame opening, maintaining even spacing on all sides. Measure from outside edge of the frame to the middle of your canvas' stretcher bar.

Once you have found the measurement to the center of the stretcher bar, remove the canvas before proceeding to the next step, and turn the frame face down. Mark screw locations on the back of the frame to the width just measured from the outside edge, typically placing one near each corner and one along each side.

2. Attach the Canvas

Using a drill bit, drill pilot holes into the frame where marked. Re-center the canvas in the frame. Either slide the frame to the edge of the table or carefully flip it over to access the back. Secure the canvas to the frame by inserting screws through the pilot holes into the stretcher bars of your canvas using a drill set to low speed.



3. Tighten and Align

Check that the canvas sits evenly within the frame with consistent spacing on all sides. Adjust as needed.

Tighten all screws firmly. Do not overtighten, as this may damage the frame or stretcher bars.

4. Prepare for Hanging

Attach one wire hanger to each side of the frame, positioned approximately one-third of the distance down from the top. Tighten screws securely. Thread wire through the loops of the hangers, then twist the ends tightly to secure.

Adhere wall protectors to the bottom corners of the frame. Your frame is now ready to hang.

