


How to connect your charger to the Wi-Fi


To ensure the steps below run smoothly, **ensure your charger and myWallbox app have the latest available software version.**

Fast Roaming must be disabled in your router settings as this feature is incompatible with Wallbox chargers. The charger must be connected to your app via Bluetooth to configure a Wi-Fi connection.



To connect your app and charger via Bluetooth follow these instructions.

1. Log in to the myWallbox app.
2. Select your charger from the list.
3. Wait until the Bluetooth connection between your charger and the app is established.
4. Tap the **Settings gear icon**.
5. Go to **CONNECTIVITY**.
6. Tap **WIFI**.
7. Activate the Wi-Fi feature to display the list of available networks.
8. Tap your Wi-Fi name to connect to it. Enter the Wi-F password if requested.
9. Once connected, a **network icon will appear next to your charger's name**.



If you need some more help, call us on **0333 202 4417**.

**e.on
next**