

# How to connect your charger to the WiFi.



To ensure the steps below run smoothly, **ensure your charger and myWallbox app have the latest available software version.**

**Fast Roaming must be disabled in your router settings** as this feature is incompatible with Wallbox chargers. The charger must be connected to your app via Bluetooth to configure a WiFi connection.



**To connect your app and charger via Bluetooth follow these instructions.**

1. Log in to the myWallbox app.
2. Select your charger from the list.
3. Wait until the Bluetooth connection between your charger and the app is established.
4. Tap the **Settings gear icon**.
5. Go to **CONNECTIVITY**.
6. Tap **WiFi**.
7. Activate the WiFi feature to display the list of available networks.
8. Tap your WiFi name to connect to it. Enter the WiFi password if requested.
9. Once connected, a **network icon will appear next to your charger's name**.



If you need some more help, call us on **0333 202 4417**.

**e.on  
next**