

EBBA BOOKSHELF

Assembly Instructions

URBAN OUTFITTERS

TOOLS REQUIRED BUT NOT INCLUDED:

Phillips head screwdriver, hammer

WARNINGS:

Do not throw away packing materials and carton until after assembly. Assemble all parts on a clean smooth surface

CARE INSTRUCTIONS:


Avoid direct exposure to sunlight. Do not place overheat or air conditioning vents. Adjust levelers so that the furniture sits flat on uneven floors.

Blot spills do not rub, with a clean white cloth.


Do not use harsh chemicals.

Before cleaning any part test a small spot in a hidden area.


You may need to re-tighten all bolts after initial use.




PARTS INCLUDED




(A) Metal bracket
x 1




(B) Nylon glide
x4




(C) Screw
[5/32" x 1/2"] x2




(D) Nylon strip
x1



(E) Bracket
x2





(F) Screw
[M3 x 32mm] x2



(G) Grub screw
[M3 x 19mm] x2



STEP 1

Lay the Bookshelf out onto a clean smooth surface such as carpet or cardboard. Use a hammer to tap the glides into the base of the bookshelf as shown.



STEP 2

Use the metal bracket (A) provided with each bookshelf to attach multiple shelves. Place the metal bracket (A) on the back edges of the side panels as shown. Insert screws (G) and tighten with a phillips head screw driver. Do not screw the brackets into the back panel of the case.



STEP 4

- Align the Anti Tip Brackets (E) to the Top back of the Case. Insert Screws (F) and tighten completely. Do not over-tighten.
- Contact your local hardware store to purchase the correct anchors for your wall-type.
- Align the bracket to the wall and make sure they line up with the brackets on the back of the case from step (a).
- Screw the bracket to the wall using the correct anchors.
- Slide the case to the wall leaving a little bit of room between the case and the wall.
- Feed the Nylon Strap through both brackets as shown and pull tight.

NOTE:

Anti-tip hardware should be installed on single high unit(s) as well as stacked units to prevent tipping hazard

