

Rue Shelf

Assembly Instructions

URBAN OUTFITTERS

TOOLS REQUIRED BUT NOT INCLUDED:

Phillips head screwdriver / drill bit, Drill, Hammer, Pencil

WARNINGS:

Do not discard packing materials and the carton until assembly is complete.

Ensure all parts are present prior to assembly.

Contact customer service immediately if any parts are missing.

Assemble all parts on a clean, smooth surface.

CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.

Blot spills with a clean, white cloth; do not rub.


Do not use harsh chemicals.

Before cleaning any part, test a small spot in a hidden area.


Do not place over heat or air conditioning vents.

Do not over-tighten the parts.


The parts may loosen after initial use; re-tighten as necessary.




PARTS INCLUDED:




1) Top Panel x 1




2) Upper Shelf x 1




3) Lower Shelf x 1



4) Leg x 6



5) Cabinet x 1



A) Bolt
(D 0.47 / 0.24 x 1.38") x 12
or
(D 12 x 35 mm)



B) Spring Washer
(D 0.47 / 0.24 x 0.08") x 13
or
(D 12 / 6 x 2 mm)




C) Flat Washer
(D 0.63 / 0.24 x 0.08") x 14
or
(D 16 / 6 x 2 mm)



D) Allen Key
(D 0.16 x 2.32") x 1
or
(D 4 x 59 mm)



E) Bolt
(D 0.47 / 0.24 x 0.59") x 19
or
(D 12/6 x 15 mm)



F) Metal Bracket
(D 2.95 x 0.79 x 0.08") x 1
or
(75 x 20 x 2 mm)



G) Plastic Anchor
(D 0.35 x 1.38") x 1
or
(D 9 x 35 mm)



H) Screw
(D 0.16 x 1.18") x 1
or
(D 4 x 30 mm)


Rue Shelf

Assembly Instructions

URBAN OUTFITTERS


STEP 1

Attach legs (4) to the top panel (1) with bolts (E), using Allen key (D) as shown.




STEP 2

Attach the upper shelf (2) to the bottom of legs (4) with bolts (A), spring washers (B), and flat washers (C), using Allen key (D) as shown.




STEP 3

Repeat STEPS 1&2 using the additional legs (4) and the lower shelf (3) as shown.



STEP 4

Fully extend the top drawer and press the plastic tabs on either side in opposite directions, as indicated on the slides, or as shown below. Pull the drawer out of the cabinet and off the portion of the glides attached within the cabinet while the plastic tabs are pressed. The drawer should slide off /on the glides easily when plastic tabs are properly engaged, do not force them off / on.




Rue Shelf

Assembly Instructions

URBAN OUTFITTERS


STEP 5

With help, align the partially assembled shelf with the cabinet (5). Ensure the hole in the bottom center of shelf (3) faces the back of the cabinet (5). Insert bolts (A), spring washers (B), flat washers (C) as shown then, use the Allen key (D) to tighten the bolts.




STEP 6

With help, flip the furniture upright. Carefully, slide the upper drawer back into place on the portion of the glides attached to the cabinet (5).



STEP 7

Attach the metal bracket (F) to the lower shelf (3) with bolt (E), spring washer (B), and flat washer (C), using Allen Key (D) as shown.



Rue Shelf

Assembly Instructions


URBAN OUTFITTERS

STEP 8

With help, place the furniture against the wall in a preferred location and ensure the furniture is level. Mark the location of the mounting hole in the metal bracket (F) on the wall, then remove the furniture from the wall.


Stud Installation:

Drill a 1/8" or 3mm hole in the wall at the marked location. With help, move the furniture back to the preferred location.




Drywall Installation:

Drill a 5/16" or 8mm hole in the wall in the marked location. Insert the plastic anchor (G) into the wall at the marked location using a hammer then, with help, move the furniture back to the preferred location.



STEP 9

Insert screw (H) through the washer (C) and metal bracket (F) into the wall or plastic anchor (G). Tighten with a Phillips head screwdriver or drill bit / drill to complete the installation.



The included hardware is intended for attachment to drywall or wooden wall surfaces, contact your local hardware store to find the correct anchor for alternative wall-types such as stone or brick.