


## ADURA® Transition Installation Guidelines Waterproof T-Molding

### Profile Specs

T-Moldings are used to bridge the gap between floors of equal or slightly different height. While maintaining a 1/4" to 5/16" expansion gap.

**Used with floors ranging from 2.0 - 5.5mm.**

**SURFACE:** Ultra wear-resistant  
**CORE MATERIAL:** Rigid PVC



### INSTALLATION GUIDE

**STEP 1**

1. Install the flooring leaving a 1-1/8" gap between the two floors for the t-molding installation.

**STEP 2**

2. Measure and trim to fit.

**STEP 3**

3. Center the track between the flooring leaving a 1/4" to 5/16" spacing between the track and floor planks. Screw track to subfloor using included screws (or glue down with Mannington Triple Stick adhesive).

**STEP 4**

4. Starting at one end, press the molding into the track inching along the length of the molding. *It will NOT snap in all at once.*  
**You may also use a rubber mallet.**

# ADURA® Transition Installation Guidelines


## Waterproof T-Molding

### Profile Specs

T-Moldings are used to bridge the gap between floors of equal or slightly different height. While maintaining a 1/4" to 5/16" expansion gap.

**Used with floors ranging from 6.0 - 8.0mm.**

**SURFACE:** Ultra wear-resistant  
**CORE MATERIAL:** Rigid PVC



### INSTALLATION GUIDE

**STEP 1**

1. Install the flooring leaving a 1-1/8" gap between the two floors for the t-molding installation.

**STEP 2**

2. Measure and trim to fit.

**STEP 3**

3. Center the track between the flooring leaving a 1/4" to 5/16" spacing between the track and floor planks. Screw track to subfloor using included screws (or glue down with Mannington Triple Stick adhesive).

**STEP 4**

4. Starting at one end, press the molding into the track inching along the length of the molding. *It will NOT snap in all at once.*  
**You may also use a rubber mallet.**

# ADURA® Transition Installation Guidelines

## Waterproof Multipurpose Reducer


### Profile Specs

Multipurpose reducers are used to bridge the gap between two floors of unequal heights. While maintaining a 1/4" to 5/16" expansion gap.

**Used with floors ranging from 2.0 - 5.5mm.**

**SURFACE:** Ultra wear-resistant

**CORE MATERIAL:** Rigid PVC



### INSTALLATION GUIDE

**STEP 1**

1" gap between the two floors for the surface reducer installation.

1. Install the flooring leaving a 1" gap between the two floors for the surface reducer installation.

**STEP 2**

2. Measure and trim to fit.

**STEP 3**

5/16" spacing between the track and floor planks.

3. Center the track between the flooring leaving a 1/4" to 5/16" spacing between the track and floor planks. Screw track to subfloor using included screws (or glue down with Mannington Triple Stick adhesive).

**STEP 4**

4. Starting at one end, press the molding into the track inching along the length of the molding. *It will NOT snap in all at once.*  
**You may also use a rubber mallet.**

## ADURA® Transition Installation Guidelines Waterproof Multipurpose Reducer


### Profile Specs

Multipurpose reducers are used to bridge the gap between two floors of unequal heights. While maintaining a 1/4" to 5/16" expansion gap.

**Used with floors ranging from 6.0 – 8.0mm.**

**SURFACE:** Ultra wear-resistant

**CORE MATERIAL:** Rigid PVC



### INSTALLATION GUIDE

**STEP 1**

1. Install the flooring leaving a 1" gap between the two floors for the surface reducer installation.

**STEP 2**

2. Measure and trim to fit.

**STEP 3**

3. Center the track between the flooring leaving a 1/4" to 5/16" spacing between the track and floor planks. Screw track to subfloor using included screws (or glue down with Mannington Triple Stick adhesive).

**STEP 4**

4. Starting at one end, press the molding into the track inching along the length of the molding. *It will NOT snap in all at once.*  
**You may also use a rubber mallet.**


## ADURA® Transition Installation Guidelines Waterproof End Cap

### Profile Specs

End caps are used to fill the gap between the floor and carpet, hearths or against sliding doors. While maintaining a 1/4" to 5/16" expansion gap on the Adura side..

**Used with floors ranging from 2.0 - 5.5mm.**

SURFACE: Ultra wear-resistant  
CORE MATERIAL: Rigid PVC



### INSTALLATION GUIDE

**STEP 1**

1. Install the flooring leaving a 1" gap between the two floors for the end cap installation

**STEP 2**

2. Measure and trim to fit.

**STEP 3**

3. Center the track between the flooring leaving a 1/4" to 5/16" spacing between the track and floor planks. Screw track to subfloor using included screws (or glue down with Mannington Triple Stick adhesive).

**STEP 4**

4. Starting at one end, press the molding into the track inching along the length of the molding. *It will NOT snap in all at once.*  
**You may also use a rubber mallet.**


## ADURA® Transition Installation Guidelines Waterproof End Cap

### Profile Specs

End caps are used to fill the gap between the floor and carpet, hearths or against sliding doors. While maintaining a 1/4" to 5/16" expansion gap on the Adura side..

**Used with floors ranging from 6.0 - 8.0mm.**

SURFACE: Ultra wear-resistant  
CORE MATERIAL: Rigid PVC



### INSTALLATION GUIDE

**STEP 1**

1. Install the flooring leaving a 1" gap between the two floors for the end cap installation

**STEP 2**

2. Measure and trim to fit.

**STEP 3**

3. Center the track between the flooring leaving a 1/4" to 5/16" spacing between the track and floor planks. Screw track to subfloor using included screws (or glue down with Mannington Triple Stick adhesive).

**STEP 4**

4. Starting at one end, press the molding into the track inching along the length of the molding. *It will NOT snap in all at once.*  
**You may also use a rubber mallet.**

# ADURA® Transition Installation Guidelines

## Waterproof Stair Nose


### Profile Specs

Stair noses are used to finish the end of a step.

\* Use as an overlap stair nose on top step by installing enclosed shim directly to the underside of stair nose.

\* Adhere shim using Mannington MSS-20 sealer.

Used with floors ADURA®APEX/Max 8mm floors (ADURA®APEX/Max 8mm floors (+/- .5mm)).



### INSTALLATION GUIDE

**STEP 1**

**1.** Measure the width of the step and cut to length.

**STEP 2**

**2.** Apply a generous bead of Mannington Triple Stick adhesive along the underside of the stair nose.

**STEP 3**

**3.** A high-quality polyurethane adhesive is required. Carefully roll the stair nose into place against the front of the step, making sure the transition is in place. Once the transition is in its desired position, press down firmly over the entire stair nose, making certain the transition is in place and tight against the riser. For added security, brad/finish nails can be used and puttied.

Let the adhesive cure according to directions.

The illustration shows a hand pressing the stair nose into place. Labels include: **Riser**, **Tread**, **Flooring**, **Overlap Installation**, **Shim**, **Floating Floor**, and **Subfloor**.

# ADURA® Transition Installation Guidelines

## Waterproof Stair Nose


### Profile Specs

Stair noses are used to finish the end of a step.

\* Use as an overlap stair nose on top step by installing enclosed shim directly to the underside of stair nose.

\* Adhere shim using Mannington MSS-20 sealer.

Used with ADURA®Rigid, REALTA®, and Essentials floors ranging from 4-6mm.



### INSTALLATION GUIDE

**STEP 1**

**1.** Measure the width of the step and cut to length.

**STEP 2**

**2.** Apply a generous bead of Mannington Triple Stick adhesive along the underside of the stair nose.

**STEP 3**

**3.** A high-quality polyurethane adhesive is required. Carefully roll the stair nose into place against the front of the step, making sure the transition is in place. Once the transition is in its desired position, press down firmly over the entire stair nose, making certain the transition is in place and tight against the riser. For added security, brad/finish nails can be used and puttied.

Let the adhesive cure according to directions.




# ADURA® Transition Installation Guidelines

## Waterproof Stair Nose

### Profile Specs

Stair noses are used to finish the end of a step.

ADURA®Flex is top-set only. Do not use the plastic shim with ADURA®Flex (2.5mm).



### INSTALLATION GUIDE

**STEP 1**

**1.** Measure the width of the step and cut to length.

**STEP 2**

**2.** Apply a generous bead of Mannington Triple Stick adhesive along the underside of the stair nose.

**STEP 3**

**3.** A high-quality polyurethane adhesive is required. Carefully roll the stair nose into place against the front of the step, making sure the transition is in place. Once the transition is in its desired position, press down firmly over the entire stair nose, making certain the transition is in place and tight against the riser. For added security, brad/finish nails can be used and puttied.

Let the adhesive cure according to directions.

Labels in the illustration: **Riser**, **Tread/Subfloor**, and **ADURA®Flex Flooring**.