Installation Guide External Cladding

EasyLap[™] Panel EasyTex[™] Panel

EXTERIORS

Australia November 2019

Make sure your information is up to date.

When specifying or installing James Hardie[™] products, ensure that you have the current technical information and guides. If in doubt, or you need more information, visit www.jameshardie.com.au or Ask James Hardie[™] on 13 11 03.



CONTENTS

1	INTRODUCTION Scope	2 2
2	SAFE WORKING PRACTICES Warning Recommended safe working practices Storage and handling	3 3 3
3	DESIGN CONSIDERATIONS Framing Fasteners	3 4 4
4	PRODUCTS AND ACCESSORY DETAILS Components Fasteners, Battens and Tapes	5 5
5 6	PANEL INSTALLATION - DIRECT FIX PANEL INSTALLATION - CAVITY FIX	7 8
7	INSTALLATION DETAILS - DIRECT FIX Junction Details External Corner Details Internal Corner Details Window Details	9 9 10 10
7	INSTALLATION DETAILS - CAVITY FIX Junction Details External Corner Details Internal Corner Details Window Details	11 11 11 12 12
9	FINISHES AND MAINTENANCE Finishing Painting Maintenance	13 13 13 13
10	PRODUCT INFORMATION	13

1 Introduction

EasyLap[™] is a strong fibre cement panel featuring a ship-lapped joint on both vertical edges. Panels are finished on-site using a roll on textured acrylic paint.

EasyTex[™] is a strong fibre cement panel featuring a ship-lapped, v-groove joint on both vertical edges. Panels are embedded with a fine modern render texture and are finished on-site using a quality exterior acrylic paint.

Both EasyLap[™] and EasyTex[™] panels are suitable for use as an external wall cladding in residential single and medium density buildings, including alterations and additions, where a uniform broadwall cladding is required. They are ideal for full wrap or composite construction designs on either timber or light gauge steel framed buildings.

If you are a specifier...

or other responsible party for a project, ensure the information in these specifications is appropriate for the application you are planning and that you undertake specific design and detailing for areas which fall outside the scope of these specifications.

If you are an installer...

Ensure that you follow the design, moisture management and associated details and material selection provided by the designer and the EasyLap[™] and EasyTex[™] Panel Installation Guide.

IMPORTANT NOTES

- 1. Failure to install, finish or maintain this product in accordance with applicable building codes, regulations, standards and James Hardie's written application instructions may lead to personal injury, affect system performance, violate local building codes, and void James Hardie's product warranty.
- 2. All warranties, conditions, liabilities (direct, indirect or consequential) and obligations whether arising in contract, tort or otherwise other than those specified in James Hardie's product warranty are excluded to the fullest extent allowed by law. For James Hardie's product warranty information and disclaimers about the information in this guide, visit www.jameshardie.com.au.
- 3. The builder must ensure the product meets aesthetic requirements before installation. James Hardie will not be responsible for rectifying aesthetic surface variations following installation.

SCOPE

General

This guide covers the use of both EasyLap[™] and EasyTex[™] panels in a residential wall application over a seasoned timber wall frame or a light-gauge steel frame installed in a vertical upright application.

MADE IN AUSTRALIA

2 Safe Working Practices

WARNING - DO NOT BREATHE DUST AND CUT ONLY IN WELL VENTILATED AREA

James Hardie products contain sand, a source of respirable crystalline silica which is considered by some international authorities to be a cause of cancer from some occupational sources. Breathing excessive amounts of respirable silica dust can also cause a disabling and potentially fatal lung disease called silicosis, and has been linked with other diseases. Some studies suggest smoking may increase these risks. During installation or handling: (1) work in outdoor areas with ample ventilation; (2) minimise dust when cutting by using either 'score and snap' knife, fibre cement shears or, where not feasible, use a HardieBlade™ Saw Blade (or equivalent) and dust-reducing circular saw attached to an appropriate, well maintained, M-class vacuum or greater with appropriate filter; (3) warn others in the immediate area to avoid breathing dust; (4) wear a properly-fitted, approved dust mask or respirator (minimum P1) in accordance with applicable government regulations and manufacturer instructions to further limit respirable silica exposures. During clean-up use a M-class vacuum or greater with appropriate filter, both of which are well maintained and appropriate for capturing fine (respirable) dust. Alternatively, use wet clean-up methods - never dry sweep. For further information, refer to our installation instructions and Safety Data Sheets available at www.jameshardie.com.au. FAILURE TO ADHERE TO OUR WARNINGS. SAFETY DATA SHEETS, AND INSTALLATION INSTRUCTIONS MAY LEAD TO SERIOUS PERSONAL INJURY OR DEATH.

James Hardie Recommended Safe Working Practices

CUTTING OUTDOORS

- 1. Position cutting station so wind will blow dust away from the user or others in working area.
- 2. Use one of the following methods based on the required cutting rate: Best • Villaboard knife • Hand guillotine • Fibreshear
- Better Position the cutting station in a well-ventilated area. Use a dust reducing circular saw equipped with HardieBlade[™] Saw Blade or comparable fibre cement blade and well maintained M-class vacuum or greater with appropriate filter appropriate for capturing fine (respirable) dust. Wear a properly-fitted, approved dust mask or respirator (minimum P1).

CUTTING INDOORS

- Cut only using Villaboard knife, hand guillotine or fibreshears (manual, electric or pneumatic).
- Position cutting station in a well-ventilated area

DRILLING / OTHER MACHINING

When drilling or machining you should always wear a P1 dust mask and warn others in the immediate area.

IMPORTANT NOTES

- 1. For maximum protection (lowest respirable dust production) James Hardie recommends always using best practice cutting methods where feasible.
- 2. NEVER use a power saw indoors.
- ALWAYS use a circular saw blade that carries the HardieBlade[™] logo or is of at least comparable performance.
- NEVER dry sweep Use wet suppression, or an M class vacuum or greater with appropriate filter.
- 6. ALWAYS follow tool manufacturers' safety recommendations.

DUST MASKS AND RESPIRATORS

As a minimum, an AS/NZS1716 P1 respirator must be used when doing any activity that may create dust. For more extensive guidance and options for selecting respirators for workplaces please refer to Australian/New Zealand Standard 1715:2009 "Selection, Use and Maintenance of Respiratory Protective Equipment". P1 respirators should be used in conjunction with the above cutting practices to minimise dust exposure.

For further information, refer to Safety Data Sheet (SDS) available at www. jameshardie.com.au. If concern still exists about exposure levels or you do not comply with the above practices, you should always consult a qualified industrial hygienist or contact James Hardie for further information.

STORAGE AND HANDLING

To avoid damage, all James Hardie[™] building products should be stored with edges and corners of the product protected from chipping. James Hardie[™] building products must be installed in a dry state and protected from weather during transport and storage. The product must be laid flat under cover on a smooth level surface clear of the ground to avoid exposure to water, moisture, etc.

3 Design Considerations

All design and construction must comply with the appropriate requirements of the current National Construction Code (NCC) and other applicable regulations and standards.

Slab and Footings

The slab and footings on which the building is situated must comply with AS 2870 'Residential slabs and footings – Construction' and the requirements of the NCC.

Ground Clearances

Install James Hardie[™] external cladding with a minimum 150mm clearance to the earth on the exterior of the building or in accordance with local building codes if greater than 150mm is required. Maintain a minimum 50mm clearance between James Hardie[™] external cladding and roofs, decks, paths, steps and driveways.

Adjacent finished grade must slope away from the building in accordance with local building codes, typically a minimum slope of 50mm over the first metre.

Do not install external cladding such that it may remain in contact with standing water.

NOTE

Greater clearance may be required in order to comply with termite protection provisions, see below for more information.

Termite Protection

The NCC specifies the requirements for termite barriers. Where the exposed slab edge is used as part of the termite barrier system, a minimum of 75mm of the exposed slab edge must be visible to permit ready detection of termite entry.

Structural Bracing

EasyLap[™] and EasyTex[™] panels can be installed to provide wall bracing against lateral forces due to wind. For further information, Ask James Hardie on 13 11 03.

Fire Rated Walls

EasyLap[™] and EasyTex[™] panels can achieve fire ratings of 60/60/60 and 90/90/90 when constructed with additional fire rated linings as specified in James Hardie's Fire and Acoustically Rated Design Manual and Construction of Fire and Acoustically Rated Walls Technical Specification. The length of fasteners must be increased for the additional linings.

Moisture Management

It is the responsibility of designer or specifier to identify moisture related risks associated with any particular building design. Wall construction design must effectively manage moisture, accounting for both the interior and exterior environments of the building, particularly in buildings that have a higher risk of wind driven rain penetration or that are artificially heated or cooled.

In addition, all wall openings, penetrations, junctions, connections, window sills, heads and jambs must incorporate appropriate flashing and waterproofing. Materials, components and their installation that are used to manage moisture in framed wall construction must, at a minimum, comply with the requirements of relevant standards and the NCC.

Weather Barrier

A suitable water control membrane must be installed under James Hardie™ cladding in accordance with the AS/NZS 4200.2 'Pliable building membranes and underlays – Installation' and NCC requirements.

James Hardie has tested and certified the use of HardieWrap[™] weather barrier for Climate Zones 2-8 within Australia. HardieWrap[™] weather barrier is a Class 4 vapour permeable membrane that delivers a triple-shield of protection to help against external weather penetration, internal condensation management and external heat penetration through its safe-glare reflective layer.

If using an alternate product in lieu of HardieWrap[™] weather barrier or the project is located in a hot, humid area (Climate Zone 1), the designer must ensure that the product is fit for purpose and it has the following classification in accordance with AS/NZS 4200.1:2017 'Pliable building membranes and underlays – Materials':

TABLE 1

Weather Barrier Classification						
Climate Zone	Water Control Classification	Vapour Control Category				
2-8	· Water Barrier	Vapour Permeable (Class 3 or 4)				
1	water Barner	Vapour Barrier (Class 1 or 2)				

Soft compressible insulation installed between the front of the wall studs and directly behind the external cladding can cause installation issues and is thus not recommended.

Flashing

All wall openings, penetrations, intersections, connections, window sills, heads and jambs must be flashed prior to cladding installation.

FRAMING

General

Easylap[™] & Easytex[™] panels are installed vertically either directly fixed to frame or installed to vertically oriented Scyon[™] Cavity Trim to provide a vented cavity, this can be done over either timber or steel frames. The general framing requirements for installation are given in Table 2.

Maximum stud, Scyon[™] Cavity Trim and fastener spacing for EasyLap[™] and EasyTex[™] panels for wind load classifications of AS 4055 'Wind Loads for Housing' are given in Table 3.


FASTENERS

General

All nails must be driven flush. Before fixing to steel frame, ensure the aesthetic finish of EasyTex[™] panels when using HardieDrive[™] screws is of acceptable quality prior to installation, see Important Note 3 on page 2 of this guide. Brad nails are recommended for best aesthetic finish. For more information and advice, Ask James Hardie[™] on 13 11 03.

Fastener Durability (Including Coastal Areas)

Fasteners must have the appropriate level of durability and be fully compatible with all other materials required for the intended project. In areas within 1km of a coastal area, areas subject to salt spray and other corrosive environments, class 4 fasteners must be used.



NAIL FASTENER DEPTH

General Framin	g Requirements						
Туре	Timber		Steel				
Design		ust be in accordance with AS anufacturer's specifications	Use of steel framing must be in accordance with NASH standard for Residential and Low- Rise Steel Framing Part 1: Design Criteria and the framing manufacturer's specifications.				
Durability	durability appropriate for	construction must have the level of the relevant climate and expected \$ 1684.2 'Residential timber-framed	The steel framing must have the appropriate level of durability required to prevent corrosion, particularly in coastal areas.				
Tolerances	Ensure frame is square a frame will give best resu		A suggested maximum tolerance of between 3mm and 4mm in any 3000mm length of				
Thermal Break Requirement	Not required.		For steel frames, the NCC Sections J1.5 and 3.12.1 Volumes 1 and 2 respectively, state for both residential and commercial buildings a thermal break such as HardieBreak [™] with an R 0.2m2 K/W must be installed behind external cladding where the cladding and internal lining make direct contact with the same steel frame. Alternatively, off-stud vented cavity installation using Scyon [™] Cavity Trim can be used in these applications.				
Framing specifi	cations						
	Direct Fix	Cavity Fix	Direct Fix	Cavity Fix			
BMT	Ν	IA	From 0.55 to 1.6mm.				
Min. Stud Width	h 45mm at sheet edges. 35mm 35mm at intermediates.		45mm at sheet edges. 42mm at intermediates.	Min. 32mm			
Min. Stud Depth	70mm 70mm		64mm	64mm			
Max. Nogging spacing	1350mm	1350mm for on stud batten fixing. 800mm for off stud batten fixing.	1350mm	800mm off stud batten fixing only.			

TABLE 3

Maximum Stud, Scyon™ Cavity Trim & Fastener Spacing for Easylap™ and EasyTex™ Panel Cladding in AS4055 Wind Classification												
Wind Classification	General Areas of Walls (mm)					Within 1200mm of Building Edges (mm)						
	Only required for cavity fix		Sheet	_Sheet Sheet		Only required for cavity fix		Sheet	Sheet			
	Stud Spacing	Scyon™ Cavity Trim Spacing	Can be fixed off stud?	Scyon™ Cavity Trim Fastener Spacing	(Excent	Fastener Spacing (Brad Nails)	Stud Spacing	Scyon™ Cavity Trim Spacing	Can be fixed off stud?	Scyon™ Cavity Trim Fastener Spacing	Fastener Spacing (Except Brad Nails)	Fastener Spacing (Brad Nails)
N1, N2, N3/C1	600	600	Yes	300	200	125	600	600	Yes	300	200	125
N4/C2	600	600	Yes	300	200		450	450	No	200	150	
N5/C3	600	600	No	200	200		300	300	No	200	150	
N6/C4	450	450	No	200	150		300	300	No	200	125	

NOTE: When using brad nails:


Refer to the accessories page for brad nails options.

NOTE: Off-stud cavity installation

• When fixing Scyon Cavity Trims offstud, noggings must be spaced at 800mm maximum.

TABLE 2

4 Products and Accessory Details



COMPONENTS

1 EasyLap [™] and EasyTex [™] Panels (8.5mm thick)								
EasyLap [™] Panel		Product Code	Length (mm)	Width (mm)	Mass (kg)	Pack Size		
	Pre-primed sheet with a ship lap edge joint along the two vertical edges.	404186	3000	900	33	40		
		404184	2440	1200	36	40		
		404185	3000	1200	44	40		
-		404980	3600	1200	52	30		
EasyTex™ Panel	Pre-primed textured sheet	405123	2440	1200	36	40		
	with a ship-lapped V-Groove	405124	3000	1200	44	40		
	joint along the two vertical	405121	3000	1350	49	30		
	edges.	405125	3600	1200	52	30		

		Horizontal fla		
2 James Hardie™ Joint Sealant	3 HardieWrap™ Weather Barrier	4 James Hardie™ Horizontal T Flashing	4 James Hardie™ Horizontal h Flashing	5 HardieEdge™ Trim
Contraction				
General purpose polyutherane exterior grade joint sealant. Pack Size: 20/Box. Product Code: 305534 300ml Cartridge Product Code: 305672 600ml Sausage Coverage: 2.67m/100ml (5mm dia bead)	High water barrier and vapour permeable membrane. Unit size: 2.75 x 30m. Pack Size: 1 Each. Product Code: 305664 Coverage: 85.5m2 per roll	Aluminium extrusion used along horizontal control joints. Product Codes: T flashing 3000mm (5/pack) 306040 Coverage: Length of horizontal joints / 3000mm	Aluminium extrusion used along horizontal control joints. Product Codes: h flashing 3000mm (5/pack) 305613 h flashing jointer (10/pack) 305614 Coverage: Length of horizontal joints / 3000mm	Powder coated aluminium architecturalslab edge solution. Product Codes:HardieEdge™ Trim(4/pack)Base Trim Jointer(12/pack)Internal Comer(4/pack)305913External Corner(4/pack)305914


		Alternative corner options —			
6 James Hardie™ 9mm Internal Corner	7 James Hardie™ 9mm External Corner	James Hardie™ Corner Flashing	Scyon™Axent™ Trim		
Aluminium extrusion to be used in internal corners. 3000mm long. Pack Size: 5 Product Code: 305520 Coverage: Height of wall x no. of internal corners / 3000mm	Aluminium extrusion to be used in external corners. 3000mm long. Pack Size: 5 Product Code: 305521 Coverage: Height of wall x no. of external corners / 3000mm	A corner flashing, manufactured using COLORBOND® steel, used behind cladding at internal and external corners. 75 x 75mm. 3000mm long. Pack Size: 5. Product Code: 305564 Coverage: Height of clad walls x no. of corners / 3000mm	Material composite trim used for box corners and for trim around windows and doors. Pack Size: 1. For internal corners: 45 x 38mm. 4200mm long. Product Code: 403626 For external corners: 45 x 19mm. 4200mm long. Product Code: 404662		

4 Products and Accessory Details cont.


FASTENERS, BATTENS AND TAPES

EasyLap[™] and EasyTex[™] panels can be fixed either to timber or steel frames, which can be done directly or over Scyon[™] cavity trim. Depending on the fixing method and substructure, there will be different components required, these are:

DIRECT FIX - TIMBER FRAME



DIRECT FIX - STEEL FRAME




CAVITY FIX - TIMBER FRAME

Gun Nails 14 Fibre Cement Nail' 12 Scvon^{**} 13 14 25mm DA **Cavity Trim** Brad Nails to fix trim to frame' 13/20 , 12 25mm DA 16 gauge 304 stainless 2.8 x 30mm corrosion resistant Fibre cement trim used to fix 2.8 x 65mm long ring shank nail or 75 x 2.8mm D or round head external cladding to steel or timber brad nails. Not supplied by James fibre cement nail Scyon™ Not supplied by James Hardie[™]. frame. Size: 70 x 19 x 2450mm. galvanised smooth shank nail used to Hardie™ cavity trim fix Scyon[™] cavity trim to timber stud. Pack Size: 96 . 14 Product Code: 403840 Not supplied by James Hardie™.

Fastener to fix EasyLap[™] and EasyTex[™] to Scyon[™] Cavity Trim

CAVITY FIX - STEEL FRAME Only suitable in wind classifications up to N3/C1



Accessories


Ha



† All dimensions and masses are approximate and subject to manufacture tolerances.


* In coastal areas and other corosive enviroments class 4 fasteners must be used. All other areas require minimum class 3.

5 Panel Installation Process* - Direct Fix



*This is an overview of the installation process only. It is not a substitute for reviewing this document in its entirety prior to installation.

6 Panel Installation Process* - Cavity Fix



*This is an overview of the installation process only. It is not a substitute for reviewing this document in its entirety prior to installation.

7 Construction Details - Direct Fix

JUNCTION DETAILS




FIGURE 1 SLAB/EAVE JUNCTION DETAIL




FIGURE 3 VERTICAL BUTT JOINT





FIGURE 5 UPPER FLOOR JUNCTION OPTION 1

NOTE: Join the James Hardie 9mm Aluminium Horizontal h flashings on intermediate studs and not off stud or behind sheet joins.

EXTERNAL CORNER DETAILS






FIGURE 2 LOWER FLOOR JUNCTION




FIGURE 4 HORIZONTAL JUNCTION 2




FIGURE 6 UPPER FLOOR JUNCTION OPTION 2





FIGURE 7 SEALANT FILL OPTION

FIGURE 8 TRIM CORNER OPTION

EASYLAP™ AND EASYTEX™ PANEL INSTALLATION GUIDE PAGE 9 OF 16








FIGURE 11 TRIM CORNER OPTION

WINDOW DETAILS






FIGURE 13 WINDOW HEAD AND SILL - TRIM PAGE 10 OF 16 EASYLAP" AND EASYTEX" PANEL INSTALLATION GUIDE


INTERNAL CORNER DETAILS













8 Construction Details - Cavity Fix

JUNCTION DETAILS




FIGURE 15 ALTERNATIVE SLAB EDGE DETAILS




FIGURE 17 ABUTMENT DETAIL




FIGURE 19 FACADE/SOFFIT JUNCTION

EXTERNAL CORNER DETAILS




FIGURE 21 TRIM CORNER OPTION - CAVITY TRIM




FIGURE 16 FLOOR LEVEL JUNCTION





FIGURE 18 PARAPET CAPPING DETAIL










FIGURE 22 SEALANT FILL OPTION - CAVITY TRIM

EASYLAP™ AND EASYTEX™ PANEL INSTALLATION GUIDE PAGE 11 OF 16


INTERNAL CORNER DETAILS














WINDOW DETAILS





9 Finishes and Maintenance

FINISHING

Sealant

Application and use of sealants must comply with manufacturer's instructions. Sealants, if coated, must be compatible with the paint system.

PAINTING

EasyLap™ Panel

EasyLap[™] panels are ready for texture. All sheets must be dry before painting.

Refer to the project specification for paint requirements. EasyLap[™] panels must be finished with texture paint within 3 months of being fixed. In areas within 1km of a coastal area or corrosive environment, the EasyLap[™] panels must be painted immediately after fixing sheets to minimise contamination build up on the heads of the fasteners, as it may lead to fastener corrosion.

James Hardie[™] recommends the application of a roll on exterior texture coat system over the panels in accordance with the paint manufacturer's specifications. Some environments require special coatings including coastal areas. Painting selection and specifications are dependent on the paint chosen. Refer to Dulux[®], Taubmans[®] or Wattyl[®] for further information, product suitability, specifications, maintenance and details of their warranty.

EasyTex[™] Panel

Any slightly overdriven brad nails (1mm max.) may be repaired using a suitable external grade filling agent and blended with the surrounding texture using a sponge or utility pad if required. EasyTex[™] panels must be dry before painting.

Refer to the project specification for paint requirements. EasyTex[™] panels must be finished with a quality exterior acrylic paint within 3 months of being fixed. In areas within 1km of a coastal area or corrosive environment, the EasyTex[™] panels must be painted immediately after fixing sheets to minimise contamination build up on the heads of the fasteners, as it may lead to fastener corrosion.

James Hardie recommends the application of a quality exterior acrylic paint over the panels in accordance with the paint manufacturer's specifications. A suitable nap roller of 12mm or greater is recommended for optimal finish.

Staining

Stains containing linseed oil are specifically designed for wood and may not be suitable for James Hardie™ cladding products, primed or un-primed.

Semi-transparent stains can vary in uniformity of appearance depending on method of application and conditions and will require a high level of skill and craftsmanship to achieve a uniform appearance. Clear coats have not proven durable in exterior exposure and James Hardie™ considers them a maintenance item that may require application of a refurbishing sealer at regular intervals. James Hardie does not warrant the appearance or durability of semi-transparent stains and clear coats.

MAINTENANCE

The extent and nature of maintenance will depend on the geographical location and exposure of the building. As a guide, it is recommended that basic normal maintenance tasks shall include but not be limited to:

- Washing down exterior surfaces every 6-12 months*
- Periodic inspections should be made to ensure fasteners are adequately securing the sheets to framing.
- Re-applying of exterior protective finishes*
- Maintaining the exterior envelope and connections including joints, penetrations, flashings and sealants that may provide a means of moisture entry beyond the exterior cladding.
- Cleaning out gutters, blocked pipes and overflows as required.
- Pruning back vegetation that is close to or touching the building.

*Refer to your paint manufacturer for washing down and recoating requirements related to paint performance.

10 Product Information

PRODUCT INFORMATION

Material

The basic composition of James Hardie™ building products is Portland cement, ground sand, cellulose fibre, water and proprietary additives.

James Hardie™ building products are manufactured to AS/NZS 2908.2 'Cellulose-Cement Products-Flat Sheet'. These are also compliant with equivalent standard ISO 8336 'Fibre-cement flat sheets - Product specification and test methods'. For product classification refer to the relevant Physical Properties Data Sheet.

Durability

Resistance to Moisture/Rotting

EasyLap[™] and EasyTex[™] panels have demonstrated resistance to permanent moisture induced deterioration (rotting) by passing the following tests in accordance with AS/NZS 2908.2:

- Water permeability (Clause 8.2.2)
- Heat rain (Clause 6.5)
- Warm water (Clause 8.2.4)
- Soak dry (Clause 8.2.5)

Resistance to fire

The EasyLap[™] and EasyTex[™] panel is suitable where non-combustible materials are required in accordance with C1.9 of the National Construction Code (NCC).

James Hardie[™] building products have been tested by CSIRO in accordance with AS/NZS 3837 and are classified as conforming to Group 1 material (highest and best result possible), with an average specific extinction area far lower than the permissible 250m²/kg, as referenced in Specification C1.10a of the National Construction Code (NCC).

Resistance to Termite Attack

Based on testing completed by CSIRO Division of Forest Products and Ensis Australia James Hardie[™] building products have demonstrated resistance to termite attack.

Alpine Regions

In regions subject to freeze/thaw conditions, all James Hardie fibre cement external cladding must be installed and painted in the warmer months of the year where the temperature does not create freeze and thaw conditions or paint issues. The cladding must be painted immediately after installation. In addition, fibre cement cladding must not be in direct contact with snow and/or ice build up for extended periods, e.g. external walls in alpine regions subject to snow drifts over winter.

Furthermore, a reputable paint manufacturer must be consulted in regards to a suitable product, specifications and warranty. The paint application must not be carried out if the air temperature or the substrate temperature is outside the paint manufacturer's recommendation including the specified drying temperature range

James Hardie[™] external cladding products are tested for resistance to frost in accordance with AS/NZS 2908.2 Clause 8.2.3.



For information and advice call 13 11 03 | jameshardie.com.au

Australia November 2019



© 2019 James Hardie Australia Pty Ltd ABN 12 084 635 558 ™ and ® denote a trademark or registered mark owned by James Hardie Technology Limited. Colorbond® Selleys®, Polyfilla®, Megapoxy®, Hitachi, Makita®, Dulux®, Taubmans®, Wattyl® and Hilti are trademarks or registered trademarks of their respective owners and are not owned by James Hardie Technology Limited.