

## FUSE TABLE

### Time Square Basic

Depending on which length and variant of luminaire you would like to use, see below table in order to find which fuse table you should use. Fuse tables will be found on page 2.

Luminaire length	Type	Fuse table to use
1140	(All variants)	1
2260	(All variants)	2

## FUSE TABLE 1

### Time Square Basic

Maximum loading of automatic of circuit breakers

	Automatic circuit breaker type:	C10	C13	C16	C20	C25	B10	B13	B16	B20	B25	Inrush current
<b>Driver:</b>	Xitanium 36W 0.3-1A 54V TD 230V											$I_{max}$ time
	<b>Number of drivers/fuse:</b> There are 1 driver / DALI address in each luminaire	37	49	61	75	94	23	29	36	45	56	26 A 140 $\mu^*$

\* Input voltage 230V, Time measured at 50% Ipeak

## FUSE TABLE 2

### Time Square Basic

Maximum loading of automatic of circuit breakers

	Automatic circuit breaker type:	C10	C13	C16	C20	C25	B10	B13	B16	B20	B25	Inrush current
<b>Driver:</b>	Xitanium 75W 0.7-2A 54V TD 230V											$I_{max}$ time
	<b>Number of drivers/fuse:</b> There are 1 driver / DALI address in each luminaire	25	32	41	50	62	15	19	24	30	37	24,9 A 215 $\mu^*$

\* Input voltage 230V, Time measured at 50% Ipeak