

Let's get together.


Upgrade to the Classic Headboard

THUMA

Step 1


Disassemble the Classic Bed.

A-B. Set the **Pillowboard** and the **mattress** aside.



Step 2


Roll the **slats** up and set aside.



Step 3


A-B. Remove **long screws**.

C. Then remove **center rail**.
You can keep the **center leg** attached.




Step 4

Remove the **short rail** on the front first.



Step 5


A-B. Carefully remove one leg at a time. Hold the long rail while removing leg. Gently rest long rails on the floor.



Step 6

A. Remove second short rail. Ensure **long rail** and legs do not fall to floor.

B-C. Then remove long rails from the legs.



Unsecured pieces can tip over during assembly. For safety, follow assembly instructions by holding pieces in place until fully secured. Avoid balancing pieces. Do not bend over around unsecured pieces and keep out of the way of children.

Pieces


Top board x1



Bottom board x1



Long rail x2



Short rail x2



Center rail x1



Short leg x4



Long leg x2



Center leg x1




Short screw x4



Long screw x2




Slats x1



Pin



Pin hole



Screws side




Slat stop



"U" joint



Rounded corner



Horseshoe

Step 1



Lay out the pieces at desired location.

Arrange long rails (sides) with “U” joints facing out and short rails (wall and foot) with “U” joints facing in.

Step into the center of the frame.

Keep the slats on the sideline for now.


Set aside two of the short legs for future optionality.



Step 2




Left long leg





Right long leg

Begin with the **left long leg** to start assembly.
Long legs face front during assembly.

Step 3




Insert long rail into left long leg
with screws side facing inward,
“U” joints facing up.




Hold pieces in place while
moving on to the next step.


Step 4




A. While holding long rail and long leg in place, insert short rail into left long leg, on top of long rail, "U" joints facing down.



B. Angle long leg and long rail towards short rail for smoothest fit.




C. Push short rail down fully.




Step 5

Insert remaining long rail into **right long leg** with screws side facing inward, "U" joints facing up .




Hold pieces in place while moving on to the next step.


Step 6




A. Lift the end of the short rail.



B. Insert short rail into right long leg.



C. Push short rail down fully.




Step 7

A. Move towards the foot of the bed.


Place short leg under long rail.

B. Repeat for the other side.



Step 8


Place the remaining short rail into short legs, “U” joints facing down, and press it down fully.



Step 9

A. Screw center leg into center rail. The center leg doubles as a leveler. Adjust up and down, as needed.


B. Place center rail into the horseshoes on the inside of the frame.





C-D. Use two **long screws** to secure short rails into center rail. Tighten by hand.

Step 10

A-B. Place **bottom board** between long legs. The pin holes should face up with the board's curvature facing the inside of the frame.




View from back





Step 11

A-B. Use **short screws** behind long legs to secure bottom board on each side. Tighten by hand.




Step 12

Place **top board** on top of the bottom board, lining up the pins with the pin holes. Ensure top board's curvature is facing the inside of the frame.



Step 13

A-B. Use the remaining two short screws behind long legs to secure top board in place. Tighten by hand.




Step 14

A. Lay rolled slats down at the head of the bed.
Place the first slat between short rail and slat stops to hold in place.

B. Roll down to the foot of the bed and place the last slat between short rail and slat stops.

Slats should be tight and secured.



Step 15

Place the mattress on top of the bed.

And you're all set.

