

# Let's get together.

Essential Bed + Headboard + Cushion


THUMA



Take care during assembly. Do not dispose of any packaging or contents of the shipping carton until assembly is complete to avoid accidentally discarding small parts or hardware. Avoid balancing unsupported pieces and do not bend over around unsecured pieces. Keep children out of the way during assembly.



# Pieces




# Step 1

Lay out the pieces at desired location.

Arrange **long rails** (sides) with “U” joints facing in, **headboard** and **short rail** (wall and foot) with “U” joints facing out.


Step into the center of the frame.

Keep slats on the sideline for now.




## Step 2

- A. Stand the headboard up, with horseshoe facing inward. Take care to balance the unsupported headboard so it does not tip over during assembly.
- B. Insert short screw in the left **cushion** strap ring. Align with the corresponding hole at the back of the headboard. Tighten screw by hand. Repeat for all other straps.
- C. Place the headboard at desired location.



## Step 3


While holding the headboard slightly tilted inward, insert the long rail with “U” joint facing down and screws side facing inward.






## Step 4

- A. Lift the other end of long rail.
- B. While holding the short rail slightly tilted inward, insert the long rail with "U" joint facing down.



## Step 5

Place the remaining long rail into the headboard joinery and the short rail joinery, with "U" joints facing down. Press it down fully.




Keep the long rail parallel with the floor while installing.

## Step 6

A. Screw **center leg** into **center rail**. The center leg doubles as a leveler. Adjust up and down, as needed.

B. Place the center rail inside the frame and press each end into the horseshoes, one at a time.

C-D. Use two **long screws** to secure the center rail into the short rail and headboard through openings. Tighten by hand.




# Step 7

A. Lay rolled **slats** down at the head of the bed. Place the first slat between headboard and slat stops to hold in place.

B. Roll down to the foot of the bed and place the last slat between short rail and slat stops.


Slats should be tight and secured.



## Step 8

Place the mattress on top of the bed.

And you're all set.



# Enjoy.

Light a candle, play some jams, pour a refreshment.

Share moments of oasis on Instagram @thuma.co.

[www.thuma.co](http://www.thuma.co) | [help@thuma.co](mailto:help@thuma.co) | [@thuma.co](https://www.instagram.com/thuma.co) | [#thuma](https://www.instagram.com/explore/tags/thuma)

---

For help & more to love, scan the QR code below.

