





ELEVATION 1: PERPENDICULAR INSTALLATION OF PYRAMAT® 75 HPTRM IN A CHANNEL




DETAIL 5: BREAK IN SLOPE INTERFACE




DETAIL 2: INITIAL CHANNEL (IC) TRENCH (DOWNSTREAM)



DETAIL 3: TERMINAL CHANNEL (TC) TRENCH (UPSTREAM)



DETAIL 6: PIN



DETAIL 3: PIN PATTERN

PIN SCHEDULE	
SECURING DEVICE	PIN
HORIZONTAL PIN SPACING	PER MANUFACTURER'S DESIGN
VERTICAL PIN SPACING	PER MANUFACTURER'S DESIGN
EMBEDMENT DEPTH	PER MANUFACTURER'S DESIGN

NOTE: THE STANDARD DETAILS ILLUSTRATED IN THESE DRAWINGS ARE FOR INFORMATION AND EVALUATION PURPOSES ONLY AND ARE NOT FOR CONSTRUCTION. PROJECT SPECIFIC CALCULATIONS, SHOP DRAWINGS AND SPECIFICATIONS, SIGNED AND SEALED BY A REGISTERED LICENSED ENGINEER, ARE REQUIRED FOR CONSTRUCTION.

CONCEPTUAL INSTALLATION DETAILS

PYRAMAT® 75 FOR CHANNEL PROTECTION

DATE:	06/03/2024	SCALE:	NTS	SHEET	1	OF	1
-------	------------	--------	-----	-------	---	----	---

PYRAMAT® 75 FOR EROSION CONTROL GENERAL INSTALLATION GUIDELINES

1. GENERAL NOTES

- PYRAMAT® 75 High Performance Turf Reinforcement Mat (HPTRM) is a three-dimensional, lofty, woven polypropylene geotextile that is available in green or tan which is specially designed for erosion control applications on steep slopes and vegetated waterways. The matrix is composed of polypropylene monofilament yarns featuring X3® technology woven into a uniform configuration of resilient pyramid-like projections. The material exhibits very high interlock and reinforcement capacity with both soil and root systems, demonstrates superior UV resistance, and enhances seedling emergence.
- The 12", 18", and 24" Securing Pins are composed of a wire, mushroomed at the top. A washer is then placed on the wire and the wire is crimped or swaged about 3-1/2" below the top so the washer will not slide off. The end of the wire is cut at a 45 degree angle for easy penetration of the soil. These Pins with washers conform to industry standards for erosion control pins with washers.
- LANDLOK® S2 Erosion Control Blankets consist of 100% wheat straw mechanically bound and covered on both sides by netting. The straw is homogeneously blended and evenly distributed throughout the blanket. The netting is photodegradable polypropylene with mesh openings of approximately 3/8 in. by 3/8 in. (11 mm by 11 mm). The blanket is sewn on approximately 2 in. (51 mm) centers with photodegradable polypropylene thread. This product is NTPPEP approved for AASHTO standards.

2. VEGETATION ESTABLISHMENT

- Prepare seedbed by loosening/scarifying top 2 to 3 in. (50 to 75 mm) of the soil surface.
- Apply any necessary soil amendments needed to promote healthy vegetation.
- Sow 25-35% of the total permanent seed mixture to the prepared seedbed. Note this seed mixture amount is in addition to the 100% total seed mixture being applied in further steps.
- Install PYRAMAT® 75 per guidelines and specifications.
- Soil-fill the PYRAMAT® 75 with 1 to 2 in. (25 to 50 mm) of amended topsoil or fill with a biotic soil media. Do not place excessive soil above the PYRAMAT® 75 material.
- Apply 100% of the total permanent seed mixture onto the topsoil/biotic soil media by broadcasting. Sown seed may need to be raked into place to ensure good contact between seed and soil.
- Install surficial protection with LANDLOK® S2 Erosion Control Blanket (ECB). LANDLOK® S2 ECB is to be secured using 6" U-shaped staples with a frequency of 1.7 staples per square yard (2.0 staples per square meter).
- Water and/or irrigate seeded areas as needed to establish and maintain vegetation until the desired vegetative density has been achieved. Frequent, light irrigation will need to be applied to seeded areas if natural rain events have not occurred within two weeks of seeding.
- Rubber-tired or rubber-tracked vehicles shall be used, and sharp turns avoided. No heavy and/or metal tracked equipment or sharp turns shall be permitted on the installed PYRAMAT® 75. Foot traffic and construction equipment shall be avoided over the PYRAMAT® 75 if loose or wet soil conditions exist.

BEFORE INSTALLATION BEGINS

- Coordinate with a Propex Representative: A pre-construction meeting is suggested with the construction team and a representative from Propex. This meeting should be scheduled by the contractor with at least a two week notice.
- Gather the Tools Needed: Tools that you will need to install PYRAMAT® 75 include a pair of industrial shears to cut PYRAMAT® 75, tape measure, and hammer/palm driver for installation of securing pins.
- Determine how to Establish Vegetation: The method of vegetation establishment should be determined prior to the start of installation. Different vegetation establishment methods require different orders of installation. Refer to Establish Vegetation for further guidance.
- A site specific soil test should be conducted to determine the recommended soil amendments required to establish permanent vegetation.
- Please consult the Propex Website for the most up to date installation guidelines.