




Introduction to: SmartBox[®] + Installation



This document introduces the SmartBox+ system installation process. For more complete details, please visit: SIMPAS.com/resources

SmartBox is a registered trademark of AMVAC Chemical Corporation


Installation:

The installation process for the SmartBox+ system can be completed in the following steps:

1. Bracket
2. Cradle and Base Unit
3. Meter
4. Furrow Tube
5. ECU
6. Harnessing – power
7. Harnessing – communication
8. Display harnessing and cab installation (if required)

1 Bracket

- The brackets bolt directly onto the row unit, using supplied hardware.
- On planters with Central Fill, the ladder brackets will bolt onto the central fill ladder or platform.



2 Cradle, Base Unit and Quick-Attach latch

- The cradle bolts to the bracket and supplies the mount for the Base Unit.
- Before installing the base unit, the meter quick-attach assembly will be installed onto the bottom side of the base unit.



3 Meter

- The Meter attaches to the bottom of the base unit. The ISO VT (virtual terminal) display is used to control the system.
- The quick attach cone is mounted to the meter before installation



4 Furrow tube

- The furrow tube runs from the bottom of the meter down to the furrow.
- It is critical to ensure that the tube remains as vertical as possible, to ensure product flow.



5 ECU (Electronic Control Unit)

- The ECU will mount directly onto the planter tool bar, at about row 5-8 depending upon the size of the planter.



6 POWER Harnessing

- The power harness begins at the tractor battery, runs out onto the planter tool bar and terminates at 1-2 locations on the tool bar using a tee harness as a splitter.
- It is recommended that the power harness is installed onto the power disconnect on the tractor, to ensure the system is fully powered down when the disconnect is off.



7 COMMUNICATION Harnessing

- The communication harness starts at the ECU and runs to row 1 initially.
- Starting at row 1, the communication harness forms a daisy chain along the rest of the planter.



8 Display – harnessing and cab installation

- When a PLANTER display is being used, display harness installation is NOT REQUIRED (*other than simply connecting to the ISO connector*).
- When an aftermarket display is being used, the display harness must be installed, following manufacturers guidance

