



GPS • Heli-pad Elev.= 769 m/2523 ft • 51° 03' 34.75" N 116° 39' 15.17" W

START

Banff, Alberta

Get on Trans-Canada Hwy/AB-1 W in Improvement District No. 9 from Mt Norquay Rd
4 min (1.9 km)

- ↑ Head west on Wolf St toward Bear St
240 m

- ↗ Turn right onto Lynx St
140 m

- ↑ Continue onto Gopher St
250 m

- ↑ Continue onto Mt Norquay Rd
950 m

- ↙ Turn left onto the AB-1/Trans Canada Highway ramp to Lake Louise
270 m

Directions continued on Page 2 >

Continue on Trans-Canada Hwy to Parson
1 h 55 min (172 km)



Merge onto Trans-Canada Hwy/AB-1 W
64.2 km



Continue onto Trans-Canada Hwy/BC-1 W
71.0 km



Turn left onto BC-95 S
750 m



Turn right to stay on BC-95 S
36.4 km

Follow Parson River Crossing to Crestbrook Rd
3 min (1.8 km)



Turn right onto Parson River Crossing
1.7 km



Continue onto Crestbrook Rd (Sign for Bobbie Burns helipad)
Destination will be on the left

END / ARRIVAL

CMH Bobbie Burns Helipad

[View helipad location on Google Maps >](#)

For more information about your trip visit cmhsummer.com

Questions? Contact our transportation team at 1.403.762.7809 • cmhtransportation@cmhheli.com